


User Manual

WIRED HEADSET

PRODUCT KEY



- 1. Adjustable Headband
- 2. Rotating Microphone
- 3. Volume Control Button
- 4. Comfort Fit Ear Cups
- 5. 3.5mm Aux plug

* Microphone rotates up into standby mode when not in use.
* Turn the Volume control button up to decrease volume and down to increase it.

SPECIFICATIONS


Frequency: 2402~2480MHz
Sensitivity: 108dB/mW
Impedance: 32ohm
Max input power: 45mW

Cord length: 1.7M
Plug: 3.5mm plug
Drive unit: 40mm

CONNECTING

Plug the 3.5mm aux plug into the audio output port on your media-playing device.

WIRELESS MOUSE



INSTALLATION

PRODUCT KEY

TROUBLE SHOOTING

If the cursor doesn't move when you move the mouse...
- Check the Wireless USB Connector connection. Try inserting it into another USB port on your computer.
- Take the batteries out and reinstall it. Replace the batteries with two that has a full charge.

IMPORTANT NOTE: The battery should not be opened or burned. Exposure to the ingredients contained within or their combustion products could be harmful.

Storage: Store in a cool, well ventilated area. Elevated temperatures can result in shortened battery life.

Mechanical Containment: Designers of any water or air-tight device should be aware of the normal evolution of hydrogen gas from alkaline batteries. This gas must be either absorbed or allowed to escape to avoid a potential safety issue.

Handling: Accidental short circuit for a few seconds will not seriously affect the battery. Prolonged short circuit will cause the battery to lose energy through heating, and can cause the safety release vent to open. Sources of short circuits include jumbled batteries in bulk containers, metal jewelry, metal covered tables or metal belts used for assembly of batteries into devices.

Soldering directly to a battery is not recommended. If welding to the battery is required, consult your Energizer sales representative for proper precautions to prevent seal damage or short circuit.

Charging: This battery is manufactured in a charged state. It is not designed for recharging. Recharging can cause battery leakage or, in some cases, high pressure rupture. Inadvertent charging can occur if a battery is installed backwards.

Labeling: The label acts as an electrical insulation for the

battery can. Damage to the label can increase the potential for a short circuit.

WARNING: Do not install backwards, charge, put in fire, or mix with other battery types as it may explode or leak causing injury. **Replace all batteries at the same time.**

Ingestion: Do not induce vomiting or give food or drink. Seek medical attention immediately. CALL NATIONAL BATTERY INGESTION HOTLINE for advice and follow-up (202-625-3333) collect day or night.

The following instructions apply to exposure of internal components.

Inhalation: Provide fresh air and seek medical attention. **Skin Contact:** Remove contaminated clothing and wash skin with soap and water. If a chemical burn occurs or if irritation persists, seek medical attention.

Eye Contact: Immediately flush eyes thoroughly with water for at least 15 minutes, lifting upper and lower lids, until no evidence of the chemical remains. Seek medical attention.

In case of fire, it is permissible to use any class of extinguishing medium on these batteries or their packing material. Cool exterior of batteries if exposed to fire to prevent rupture.

Dispose of in accordance with all applicable federal, state and local regulations. Appropriate disposal technologies include incineration and land filling.

Contact Info: contact@culturefly.com

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. This equipment is designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced audio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

US Company Name: Oasis Company, Inc.
US Company Address: 331 Valley Dr, San Jose, CA 95111
Telephone Number: (01) 202628330

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.