Q31-智能手表使用说明书(英文版)

产品型号: Q31


产品名称: 智能手表

零件图号: -

规格:成形后 83x53mm (风琴折); 105g哑粉纸



01 Product Introduction



Note

n the operation guide are for illustration purpose only and

LED Smartwatch User Manual

02 Wearing

Wear your watch one finger from the wrist bone and adjust the strap tightness to ensure the heart rate sensor collects data properly

Too loose wearing may affect the accuracy of heart rate monitoring data.



02

07 Safety Information

Electronic device:

Flammable and explosive area:

Do not use the device in any flammable or explosive areas such as petrol station (service station) or near flammable chemicals, and observe all graphic or written instructions. This device may cause explosion or fire in or around storage and transport areas of fuel and chemicals or explosive sites. Operation Environment:

1. Do not use the device in humid or near magnetic places as it may cause the internal

 $2.\,Do$ not use the device during thunderstorm which may lead to device failure or electric shocks.

3. Use this device within the temperature range of -20 $\mathbb C$ ~45 $\mathbb C$. When the ambient temperature is too high or too low, it may cause device to malfunction.

08

Scan QR code or search "GloryFit" in AppStore (IOS) or Google Play (Android) to download and install the app



03



WeChat scan QR code on the watch

4. Do not place the device in direct sunlight, such as car dashboard or window ledge.

5. Do not place the device near heat source or naked flames, such as electric heaters, microwave ovens, ovens, water heaters, candles and other places where high temperature may be generated. Water and dust resistant:

This device shows water-resistant and dust-proof performance under specific environments after being tested.

Children Health:

This device and its accessories may contain some small parts, please keep the device and its accessories out of the reach of children. Children may inadvertently damage this device and its accessories, or swallow small part that may result in a gastric shock or other hazards.


2. This device is not a toy and children should use it under the supervision of an adult.

Using unauthorized third party software to upgrade your device's firmware and system may cause the device to malfunction or lead to the security risks such as leaking your personal information. It is recommended to use online upgrade or consult official customer service for the upgrade.

09

04 Using

- **Screen Operation**
- 1. Enable shortcut menu 2. Enable message notifications.
- 3. Switch functional card. 4. Enter functional menu
- 5. Return to the last level. 6. Select other watch face setting.



04

08 Limitation of Liability

Disclaimer of Liability:

The contents of this manual are provided by "as is" and, except as required by applicable laws, Ultra Easy Health Technology (Guangzhou) Co., Ltd, does not disclaim any expressed or implied warranties, including but not limit to warranties to marketability or fitness for a particular purpose with respect to the contents of this manual.

To the extent permitted by applicable laws, Ultra Easy Health Technology (Guangzhou) Co., Ltd., shall in not event be liable for any special, incidental, indirect or consequential damages, nor for any loss of profit, data or anticipated savings, arising out of the use of the relevant contents of this manual, and the product described in this manual.

To the extent permitted by relevant laws, in any event, the maximum liability of Ultra Easy Health Technology (Guangzhou) Co., Ltd for damages arising from using the product described in this manual (except for damages under applicable law in cases involving personal injury) is limited to the product price paid by you.

05 Recharging

When the watch indicates that battery is low, please charge it promptly. The watch is magnetic charging. Please match the charging pins of the charging cable to the watch's charging port until the watch screen shows the recharging reminder.

1. Please use Please use the exclusive charging cable to charge. The charging way is unidirectional, s please pay attention to the charging direction, correct charging will absorb, while wrong direction will repel, please do not force charging.

2. When charging, to ensure stable charging, the watch screen will be off and users can click the button to wake up the screen. When the watch power is too low, it will take 3 to 5 minutes to charge before waking up the watch, which is normal. Please wait for 5 minutes and then check the watch charging status.

05

09 Warranty Service

Warranty Notice

In normal use, if there are product quality problems caused by manufacturing, materials, design, etc. one year free warranty for the motherboard and six months warranty for the battery and charger from the date of purchase.

No free warranty will be provided for failures caused by user's personal reasons, as follows:


•Failures caused by unauthorized disassembly and modification of the watch •Failures caused by dropping while use.

•All man-made damage or damage caused by third party's negligence or misuse (e.g. water in the body, external shocks, scratches on peripheral parts, etc.) is not covered by the warranty.

2. When requesting a free warranty, please provide warranty card with the date of purchase date and the seal of the purchase store. 3. When repairing the product, the user should take the product to our company or to our distribution site.

4. All functions of the product are based on the actual product.

3.Please connect charging socket to power adapter (5V/0.5A) or PC with USB cable.



10 Basic Parameters

Product name: smartwatch Product model: Q31 Display screen size: 1.43 Amoled

Resolution: 466*466 Battery capacity: 300mAh Standby time: 5-15 days Product weight: about 52g Working environment: 0°C~45°C Product size: 52.5*46*11.3mm Wristband material: silicon

Master control chip: single chip, dual mode Bluetooth: Bluetooth BLE5.2+BT3.0 $\textbf{Compatible system:} \ \, \textbf{Android5.0+IOS9.0}$ Packing list: device, charging cable and User Manual

06 Strap adjustment and disassembly

Strap adjustment

Adjust the watch buckle according to your wrist to ensure the strap and watch cling to your wrist. Strap disassembly and assembly

1. Pull the buckle of the strap and lift the strap to remove it. Insert one side of the strap into the lugs, pull the buckle of the strap, align the other side with the lugs and release the buckle, then the strap is fitted with a click.

3. Pull and tug the strap to ensure it is well-installed.

11 Three-guarantee Service

Three-guarantee Service Customer Data Customer Phone Model Sales Store Purchase Date Contact Phone Sales Phone Sales Address Abstract Failure Phenomenon Inspection & Repair Remark

Warnings

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.

 $\ \, \textbf{(2) This device must accept any interference received, including} \\$ interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate Note: This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

- by turning the equipment off and on, the user is encouraged to try to $% \left(1\right) =\left(1\right) \left(1$ correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.
- to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

-Connect the equipment into an outlet on a circuit different from that

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

12 Precautions

1. It is forbidden to use a power adapter with a charging voltage greater than 5V and a charging current greater than 2A. Charging hour is 2 to 3 hours. 2. It is forbidden to charge in the presence of water damage.

3. This device is not for medical use, the data and information provided are for reference only. $4. \, Do \, not \, use \, this \, device \, in \, places \, where \, the \, use \, of \, wireless \, devices \, is \, expressly \, prohibited, \, as \, this \, may \, interfere \, with \, other \, electronic \, devices \, or \, cause \, other \, hazards.$

 $5. \ Do \ not \ place \ the \ device \ in \ direct \ sunlight, such \ as \ car \ dashboard \ or \ window \ ledge.$

6. Do not place the device near heat source or naked flames, such as induction cookers, microwave ovens, ovens, water heaters, fires, candles and other places where high temperature may be generated.

7. Do not allow children or pets to swallow the device or its accessories, as this may cause injury to them or lead to device failure.

8. This device is not a toy and children should use it under the supervision of an adult. 9. This device is equipped with a non-removable built-in battery, please do not replace the battery by yourself. $$\rm 14$

Product name: smartwatch

Wireless connection: Bluetooth BLE5.2+BT3.0

Manufacturer: Ultra Easy Health Technology (Guangzhou) Co., Ltd Office address: 228 Huadi Avenue Middle, Liwan District, Guangzhou China 51000

User Guide version no.V1.0