

# S8 Plus-智能手表使用说明书 (英文版)

产品型号: S8 Plus

产品名称: 智能手表


零件图号: -

规格: 成形后 83x53mm (风琴折); 105g哑粉纸



## 01 Product Introduction

Please read this operation guide carefully before using the watch and keep it properly.



Note:

Product pictures such as products, accessories, user interfaces shown on the operation guide are for illustration purpose only and actual product may vary due to product update and enhancement.


01

## 02 Wearing

Wear your watch one finger from the wrist bone and adjust the strap tightness to ensure the heart rate sensor collects data properly.

Note:



Too loose wearing may affect the accuracy of heart rate monitoring data.



02

## 03 Connection

Scan QR code or search "GloryFit" in AppStore (iOS) or Google Play (Android) to download and install the app




03

Scan the QR code on the watch

## 04 Using

### Screen Operation

1. Enable shortcut menu.
2. Enable message notifications.
3. Switch functional card.
4. Enter functional menu.
5. Return to the last level.
6. Select other watch face setting.



04

05

## 05 Recharging

When the watch indicates that battery is low, please charge it promptly.


The watch is magnetic charging. Please match the charging pins of the charging cable to the watch's charging port until the watch screen shows the recharging reminder.

1. Please use the exclusive charging cable to charge. The charging way is unidirectional, so please pay attention to the charging direction, correct charging will absorb, while wrong direction will repel, please do not force charging.

2. When charging, to ensure stable charging, the watch screen will be off and users can click the button to wake up the screen. When the watch power is too low, it will take 3 to 5 minutes to charge before waking up the watch, which is normal. Please wait for 5 minutes and then check the watch charging status.

06

3. Please connect charging socket to power adapter (5V/0.5A) or PC with USB cable.



06


## 06 Strap adjustment and disassembly

### Strap adjustment

Adjust the watch buckle according to your wrist to ensure the strap and watch cling to your wrist.

### Strap disassembly and assembly

1. Pull the buckle of the strap and lift the strap to remove it.
2. Insert one side of the strap into the lugs, pull the buckle of the strap, align the other side with the lugs and release the buckle, then the strap is fitted with a click.
3. Pull and tug the strap to ensure it is well-installed.



07

## 07 Safety Information

### Electronic device:

Please do not use this device in places where the use of wireless devices is expressly prohibited, as this may interfere with other electronic devices or cause other hazards.

### Flammable and explosive area:

Do not use the device in any flammable or explosive areas such as petrol station (service station) or near flammable chemicals, and observe all graphic or written instructions. This device may cause explosion or fire in or around storage and transport areas of fuel and chemicals or explosive sites.

### Operation Environment:

1. Do not use the device in the humid or near magnetic places as it may cause the internal circuit malfunction of the device.

2. Do not use the device during thunderstorm which may lead to device failure or electric shocks.

3. Use this device within the temperature range of -20°C~45°C. When the ambient temperature is too high or too low, it may cause device to malfunction.

08

Product name: smartwatch

Product model: S8 Plus

Wireless connection: Bluetooth 5.2

Manufacturer: Ultra Easy Health Technology (Guangzhou) Co., Ltd

Office address: 228 Huadi Avenue Middle, Liwan District, Guangzhou, China 510000

User Guide version no. V1.0

### FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

15

-Reorient or relocate the receiving antenna.  
-Increase or relocate the receiving antenna.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.  
The device can be used in portable exposure to meet general RF exposure requirement. The device

16