




05 / DO A FILTER CLEANING

Press the filter cover handle and lift the cover up.




Note:

1. You should ensure the device is power off when open the top cover.
2. You need to clean the filter basket after each use.



Empty all debris and rinse them with clean water.




After rinsing, put the filter basket and ultra-fine filter into the cleaner and close the cover.


Note:

1. As electric components inside the cleaner, store the cleaner in a cool and ventilated place, away from direct sunshine or any heat source.
2. Charge the cleaner prior to being stored for a long time (over 6 months) to maintain an optimal battery life.

06 / PUT BACK TO DOCKING STATION




Hold the handle of the cleaner, and shake off inside air. Put it into the pool vertically. Wait until the robot has completed self-calibration.




Press the home button on the solar kit to call the robot back to the docking station.


If your robot is powered off because of the low battery, you can put it onto the docking station manually.



Shake the cleaner horizontally to empty trapped air inside.



Put the robot onto the docking station carefully.



Start to fully charge itself automatically and keep standing by for next cleaning cycle.

07 / DEVICE SPECIFICATION

Model	WYBOT S2 Solar Vision
Pool Size	Up to 300m ² (3229.173ft ²)
Depth	9.8ft (3m)
Device Dimension	400(L)*390(W)*255(H) mm
Weight	8.5 Kg (Robot)+8.0Kg (Solar+Station)
Runtime	2.5 hours
Charging Time	3 hours (DC charging)
Voltage	Battery/25.9V
Power	90W
Charger Input	100-240V, 47-63Hz
Charger Output	29.4V/3A
Battery Capacity	5200mAh
Filtration	Double-level
Flow Rate	14m ³ /H (3962GPH)
Moving Speed	10m/min.
Water Resistance	IPX8
OTA upgrading	Available
App Connection	Available

08 / LIMITED WARRANTY

1. All WYBOT pool cleaners in the market have been inspected and licensed to be sold as per local laws.
2. The warranty applies only to original buyers, and not valid to resale and any other kinds of transfer.
3. Any damages to the unit caused by improper use, unauthorized repair or disassembly are not covered by WYBOTICS Co., Ltd.'s warranty.
4. The order number or record must be presented for any claim or repair within the warranty period.



Scan the QR code for the warranty policy.

09 / HOW TO MAINTAIN YOUR DEVICE

You should follow the steps to store your cleaner to maintain good performance.

- a) Ensure the device is power off
- b) Dry out the cleaner
- c) Fully charge the battery
- d) Store the cleaner in a cool and ventilated place, away from direct sunshine, heat source, frost and squeezing with an ambient temperature between 5°C / 41°F and 45°C / 113°F.
- e) Charge the cleaner every three months to ensure an optimal battery life.
- f) Keep the solar kit away from any pressure

Note:

If your device do not work after a long-term low battery life or being off, please contact after-sale team for help. For your safety, do not try to disassemble it without authorization.