

Mibro Earbuds 3 Pro User Manual

mibro

FCC Warning:
This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Thank you for choosing our product, hope the fashionable appearance and high quality stereo can enrich your life.

Note: After you receive this product, please tear off the insulation film of the earphone charging pin, charge the earphone for 10 minutes before taking it out and using.

Product Overview

Charging

Please put the buds into the box before the first use, and connect the charging cable with the charging box to fully charge the earbuds.

Getting Starts

Getting Off

The earbuds turn off automatically if:

- ① You put earbuds back to the charging case.
- ② When earbuds leave the charging case, but have not paired any devices within 5 minutes.
- ③ When the earphone battery is low (please charge it in time).

Safety Instructions

- Avoid dripping and dropping.
- Please use a certified charging adapter with an output voltage not exceeding 5v.
- Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.
- Keep the earbuds dry and do not submerge it in water.
- Keep out of reach of children, small parts included may be a choking hazard, and avoid using the LED indicator close to the eyes of children or animals.
- Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

Functions

You can operate MFB to get certain functions as below:

- 1. Play / Pause**
When playing music, double-click MFB(R or L) to pause, double-click again to resume.
- 2. Previous Track / Next Track**
When playing music, Quick triple-click MFB(L) to previous track, Quick triple-click MFB(R) to next track.
- 3. Volume Increase Or Decrease**
When playing music, Click MFB(L) once to decrease the volume, Click MFB(R) once to increase the volume.
- 4. Start voice assistant**
In the Bluetooth connection state, press and hold MFB for 2 seconds to activate the voice assistant.
- 5. Answer/拒接电话**
When there's an incoming call, double-click MFB once to answer, you can end it by double-click MFB again.
- 6. Reject An Incoming Call**
When there's an incoming call, press and hold the MFB for 2 seconds to reject.

Charge your phone

The package contains a C-C charging cable, and the charging case can charge other type-C-interface electronic devices such as mobile phones. (Apple phones need to bring their own charging cable)

Hearing Safety

- To avoid hearing damage, do not listen for long time at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use with caution or temporarily discontinue using in potentially hazardous situations.

Getting Starts

Getting Off

The earbuds turn off automatically if:

- ① You put earbuds back to the charging case.
- ② When earbuds leave the charging case, but have not paired any devices within 5 minutes.
- ③ When the earphone battery is low (please charge it in time).

Safety Instructions

- Avoid dripping and dropping.
- Please use a certified charging adapter with an output voltage not exceeding 5v.
- Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.
- Keep the earbuds dry and do not submerge it in water.
- Keep out of reach of children, small parts included may be a choking hazard, and avoid using the LED indicator close to the eyes of children or animals.
- Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

Functions

You can operate MFB to get certain functions as below:

- 1. Play / Pause**
When playing music, double-click MFB(R or L) to pause, double-click again to resume.
- 2. Previous Track / Next Track**
When playing music, Quick triple-click MFB(L) to previous track, Quick triple-click MFB(R) to next track.
- 3. Volume Increase Or Decrease**
When playing music, Click MFB(L) once to decrease the volume, Click MFB(R) once to increase the volume.
- 4. Start voice assistant**
In the Bluetooth connection state, press and hold MFB for 2 seconds to activate the voice assistant.
- 5. Answer/拒接电话**
When there's an incoming call, double-click MFB once to answer, you can end it by double-click MFB again.
- 6. Reject An Incoming Call**
When there's an incoming call, press and hold the MFB for 2 seconds to reject.

Charge your phone

The package contains a C-C charging cable, and the charging case can charge other type-C-interface electronic devices such as mobile phones. (Apple phones need to bring their own charging cable)

Hearing Safety

- To avoid hearing damage, do not listen for long time at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use with caution or temporarily discontinue using in potentially hazardous situations.

Getting Starts

Getting Off

The earbuds turn off automatically if:

- ① You put earbuds back to the charging case.
- ② When earbuds leave the charging case, but have not paired any devices within 5 minutes.
- ③ When the earphone battery is low (please charge it in time).

Safety Instructions

- Avoid dripping and dropping.
- Please use a certified charging adapter with an output voltage not exceeding 5v.
- Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.
- Keep the earbuds dry and do not submerge it in water.
- Keep out of reach of children, small parts included may be a choking hazard, and avoid using the LED indicator close to the eyes of children or animals.
- Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

Functions

You can operate MFB to get certain functions as below:

- 1. Play / Pause**
When playing music, double-click MFB(R or L) to pause, double-click again to resume.
- 2. Previous Track / Next Track**
When playing music, Quick triple-click MFB(L) to previous track, Quick triple-click MFB(R) to next track.
- 3. Volume Increase Or Decrease**
When playing music, Click MFB(L) once to decrease the volume, Click MFB(R) once to increase the volume.
- 4. Start voice assistant**
In the Bluetooth connection state, press and hold MFB for 2 seconds to activate the voice assistant.
- 5. Answer/拒接电话**
When there's an incoming call, double-click MFB once to answer, you can end it by double-click MFB again.
- 6. Reject An Incoming Call**
When there's an incoming call, press and hold the MFB for 2 seconds to reject.

Charge your phone

The package contains a C-C charging cable, and the charging case can charge other type-C-interface electronic devices such as mobile phones. (Apple phones need to bring their own charging cable)

Hearing Safety

- To avoid hearing damage, do not listen for long time at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use with caution or temporarily discontinue using in potentially hazardous situations.

Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Earbuds	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Charge Box	○	○	○	○	○	○
Charge Cable	○	○	○	○	○	○
Eartips	○	○	○	○	○	○

This table is prepared in accordance with SJ/T 11364-2014.

Non warranty regulations

- Wear and tear caused by use such as scratches and color changes; As well as damage caused by chemicals, sharp objects, falling, explosion and deformation.
- The earbuds is placed in the charging compartment and still connected to the mobile phone.
- Please check whether the earbuds is in good contact with the charging chamber, or the charging chamber is not powered.
- I have established connection with my smartphone, but I am not hearing any sounds.
- Please make sure that you have turned up the volume of both devices Smartphone requires you to set up the Bluetooth earbuds as an audio output devices before transmission of sound. Please check the instruction of your smartphone for details. If you are using a music player or other Bluetooth devices, please make sure it sets the Bluetooth earbuds as the audio output devices, please make sure there is no radio or WiFi interference nearby.
- Why the connection is not stable and cuts out intermittently?
- It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.

This product meets the ROHS environmental protection requirements: there is no mature technology in the world to replace or reduce the lead content of some electronic components of circuit components, steel and copper alloy.

FAQ

- One of the earbud is silent while another is playing.
 1. It may be that the buds can't be connected normally, which may occur in extreme cases. Please put the buds back into the charging box, and then take the buds out again after 5 seconds.
 2. The silent buds may be out of power. Please put your buds back into the charging box to fully charge them and then take them out for reuse.
- The earbuds didn't turn on when I get them from the charging case, it can't turn on automatically.
 1. Please check the power of charging case, if there is no power the earbuds can't turn on automatically.
 2. During the call, the other party cannot hear the sound.
 3. Unable to charge, the charging indicator is not on.
- The earbuds is placed in the charging compartment and still connected to the mobile phone.
 1. Please check whether the earbuds is in good contact with the charging chamber, or the charging chamber is not powered.
- I have established connection with my smartphone, but I am not hearing any sounds.
 1. Please make sure that you have turned up the volume of both devices Smartphone requires you to set up the Bluetooth earbuds as an audio output devices before transmission of sound. Please check the instruction of your smartphone for details. If you are using a music player or other Bluetooth devices, please make sure it sets the Bluetooth earbuds as the audio output devices, please make sure there is no radio or WiFi interference nearby.
- Why the connection is not stable and cuts out intermittently?
 1. Please make sure there are no obstacles between the earbuds and your Bluetooth device; please make sure there is no radio or WiFi interference nearby.
- The sound is not very clear or the caller cannot hear my voice clearly.
 1. Please adjust the volume on your phone and earbuds. Make sure there is no source of interference nearby. Stay close to your smartphone check if there's any improvement.

Basic Parameters

Earbuds Basic Parameters:

BT Model	XPEJ007
BT Version	V5.3
BT Range	<10m/33ft
Battery Capacity	40mAh/Per Earbud
Charging Time	About 1.5 hours
Play Time	About 6.5 hours
Stand By	About 40 hours
Input	5V ==40A
Battery Type	Lithium ion polymer
Weight	About 3.5g/Per Earbud
Waterproof	IPX4

Charge Box Basic Parameters:

Battery Capacity	2000mAh
Input	5V == 1A
Output	5V == 1A (Per earbud)
Charging Time	About 3 hours
Battery Type	Lithium ion polymer
Weight	About 72g

Package Contents

Charging Box X1, Earbuds X2, Charging cable X2(A-C/C-C), User Manual X1, 3 pairs of ear tips(M size has been pre-installed)

Trouble shooting and after sales regulations

Name	Trouble shooting
Earbuds	1. The earbuds is silent during use. 2. During the call, the other party cannot hear the sound. 3. Unable to charge, the charging indicator is not on.

FAQ

- One of the earbud is silent while another is playing.

1. It may be that the buds can't be connected normally, which may occur in extreme cases. Please put the buds back into the charging box, and then take the buds out again after 5 seconds.
2. The silent buds may be out of power. Please put your buds back into the charging box to fully charge them and then take them out for reuse.

Non warranty regulations

1. Wear and tear caused by use such as scratches and color changes; As well as damage caused by chemicals, sharp objects, falling, explosion and deformation.

2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.

3. Damage caused by force majeure.

4. Non compliance with performance faults listed in the performance fault table.

5. The charging case is not waterproof!

Attention:

The illustrations of products and accessories in the manual are schematic diagrams for users' reference only. Due to the update and upgrading of this product, the actual product may be different from the schematic diagram. Please take the actual product as the standard.

● Mibro brand owns the final right to interpret the goods.

Basic Parameters

Earbuds Basic Parameters:

BT Model	XPEJ007
BT Version	V5.3
BT Range	<10m/33ft
Battery Capacity	40mAh/Per Earbud
Charging Time	About 1.5 hours
Play Time	About 6.5 hours
Stand By	About 40 hours
Input	5V ==40A
Battery Type	Lithium ion polymer
Weight	About 3.5g/Per Earbud
Waterproof	IPX4

Charge Box Basic Parameters:

Battery Capacity	2000mAh
Input	5V == 1A
Output	5V == 1A (Per earbud)
Charging Time	About 3 hours
Battery Type	Lithium ion polymer
Weight	About 72g

Package Contents

Charging Box X1, Earbuds X2, Charging cable X2(A-C/C-C), User Manual X1, 3 pairs of ear tips(M size has been pre-installed)

Manufacturer:

ZhengShi Information Technology (Shenzhen) Co., Ltd

Address:

RM1505, Tower C, Galaxy World, Minzhi Street, Longhua District, Shenzhen, China

Phone:

0755-26660000

FAQ

1. The earbuds is silent during use.

2. During the call, the other party cannot hear the sound.

3. Unable to charge, the charging indicator is not on.

FAQ

1. The earbuds is silent during use.

2. During the call, the other party cannot hear the sound.

3. Unable to charge, the charging indicator is not on.

FAQ

1. The earbuds is silent during use.

2. During the call, the other party cannot hear the sound.

3. Unable to charge, the charging indicator is not on.

FAQ

<div