


4 in


  
*Hearth & Hand*  
 WITH MAGNOLIA

# Portable Radio



## Include

- Portable Radio
- Micro USB Charging Cable
- AUX Cable

## Power on/off

- Toggle Power switch to turn the power on/off. In Bluetooth® mode, the voice will be heard.

## FM Mode

- Turn BT/AM/FM Tuning control to FM mode.
- Rotate FM/AM Tuning control to find your favorite FM radio stations.
- Rotate Volume control to adjust the volume.

NOTE : To ensure maximum FM tuner reception, fully extend the FM TELESCOPIC ANTENNA and rotate it for the best FM radio reception.

## AM Mode

- Turn BT/AM/FM Tuning control to AM mode.
- Rotate FM/AM Tuning control to find your favorite AM radio stations.
- Rotate Volume control to adjust the volume.

NOTE : The AM antenna is located inside the cabinet of the unit. If AM reception is weak, change position of unit until the internal antenna picks up the strongest signal.

## Bluetooth® Mode

- Turn BT/AM/FM Tuning control to Bluetooth® mode, the voice will be heard, the white light flashes in Bluetooth® mode during pairing.
- Use Bluetooth® settings on your device to pair with "Hearth & Hand 08".
- The white light in Bluetooth® mode turns solid white when connected successfully, the voice will be heard.
- Rotate Volume control to adjust the volume.
- Disconnect Bluetooth® settings on your device or without a certain range, Bluetooth® will be unpaired.
- Within a certain range, Bluetooth® will automatically return to the last connected device.
- It will automatically power off within 10 minutes if no operation, the voice will be heard.

NOTE : Please keep the distance between the connected Bluetooth® devices less than 33 feet to ensure working properly.

Front

5.9 in

## AUX Mode

- In any BT/AM/FM mode, insert AUX cable, the radio will play the input audio
- Rotate Volume control to adjust the volume .

## Charging

- Plug micro USB end of charging cable into charging port
- Plug USB end of charging cable into a DC 5V 1A power adaptor
- Full charge requires approximately 3 hours
- Red light is always on when charging, and will turn off when the device is fully charged.
- Suggest to fully charged for first use

## Troubleshooting and Tips

- If the device is not working correctly, toggle Power switch to power on again.
- If the device won't turn on, recharge the battery and try again
- If the device won't charge, make sure the supply works is 5V 1A, and not damaged
- If the device makes no sound, adjust the volume
- If the device makes no sound or do not show as an available device in Bluetooth® Mode, make sure it is not paired to another device. If so, unpair the device and re-pair the desired device.
- If Noise or sound distorted on AM or FM broadcast, retune the AM or FM broadcast station. Or fully extend the FM telescopic antenna. Reposition the unit until the best reception is obtained.

## SPECIFICATIONS:

- Power Input: 5V==1A
- Built-In Li-ion Battery: 3.7V DC,1200 mAh
- Bluetooth® Pairing Name: Hearth & Hand 08

## Need some help?

Can't get it to pair? Not accepting phone calls? Just have a question?



Call us at: 1-833-TGT-Tech

## Safety

- Do not use near any water source
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. The device has been evaluated to meet general RF exposure requirement.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Target Corp.Mpls.MN,55403 Phone:1-833-TGT-Tech

Back