



尺寸：90*136mm



3D
Sound Sleep mask

MANUAL

Usage Method

1.How to power on/off and activate the Voice Control function?

1 Power Button


Power On:
Press the power button about 3 seconds.
Long press the button about 3 seconds or use the voice command "Power off".

2 Voice-Activate

Press the power button to activate the voice control function.After 2 beeps, you can start using voice commands.The voice control function is active for 30 seconds.
Please press the power button again to reactivate the voice control function after 30 seconds.

3


The device defaults to white noise mode when Power on.
Voice command:
Previous Track/Next Track
Volume up / Volume down



2.How to properly wear the Sleep Mask

1 Adjust the buckle to fit your head size.


2 Please put on the eye mask, then make further adjustments based on specific needs.



Usage Method

3.How to adjust the Ear Cups

1 If the ear cups are not snug, please move them to the left or right until they are in the proper position.



4.How to use the Remote Control

Please point the remote at the eye mask's control switch to operate. (Remote Control Range: 50CM)

Track Control Buttons:

Up arrow: Play the previous track.
Down arrow: Play the next track.

Volume Control Buttons:



Press the right button to increase the volume.
Press the left button to decrease the volume.
Pause/Play Buttons:Press to pause or resume music playback.

Bluetooth On/Off Button:

Press to toggle Bluetooth mode.

Timer Button:

Press to activate the timer function.



*Remote Control Range: 50CM

Usage Method

5.How to connect mask's Bluetooth earphones and play music?

1

Voice command:
Bluetooth mode

2

Search Bluetooth name:FS201 and click to pair

3

After connected, the eye mask will indicate that the Bluetooth connection is successful, and you can start playing music by your phone.

4

If you want to switch to white noise mode, please say the command: "Turn off Bluetooth."

*If the volume is too low when first connecting to Bluetooth, increase your phone's volume (recommended above 50%). This will be the default volume for future connections.

6.How to set a Timer?

Voice command:
Timer 15 minutes
Timer 30 minutes
Timer 45 minutes

Voice command:
Cancel Timer

Voice Timer and Cancel Timer

Product Advantages

- Built-in 12 types of white noise musics to help users to relax and fall asleep quickly.
- The innovative design of the eye cup can blocks light effectively enhancing sleep comfort.
- The ear cups reducing environmental noise and improving sleep quality.
- Ultra-thin,portable Bluetooth earphones delivering high-quality audio.
- Supports voice commands,users can easily use play, pause, and other functions through voice.
- Made with breathable materials for long-term wear,ensuring comfort for the eyes.
- Unique eye cups contour to facial features for comfortable, pressure-free side sleeping.
- Timer function.
- Bluetooth earphones with adjustable positioning for clearer, balanced sound quality.
- With a full charge, the eye mask can standby for up to 60 hours.

FAQS

Q:Can it be used in water?
A:No,it's not waterproof.Please avoid submerging in water to prevent damage to electronics.

Q:Battery life of the eye mask?
A:With a full charge,the normal play time is 8-10 hours.

Q:Can it pair with multiple Bluetooth devices simultaneously?
A:One Bluetooth device at a time.Disconnect and pair with another device.

Q:Time of the fully charge?
A:Takes about 1 hour to fully charge from 0% to 100%.

Q:How to charge?
A:Open the charging port, plug in the charging cable.


Q:How to confirm when the battery is fully charged?
A:A red light indicates charging, and it turns off when fully charged.

Q:Can the strap tightness/eye mask and ear cup positions be adjusted?
A:Yes, the ear cups can be moved left or right, and the strap can be tightened or loosened to adjust to a comfortable position.

Q:Can the eye mask wash by machine?
A:No, machine washing is not recommended.Please use a wet wipe to clean if needed.

Q: How does the device notify when the battery is low?
A: When the battery is low, it will emit two "beep" sounds and automatically shut down after three minutes. Please recharge it in time.

Product Description



Product Specifications

Product Model	FS201
Product Name	3D sound Sleep
Product Power	5V1A
Product Size	190mmX90mmX48mm
Product Weight	360g
Product Colors	Black/Brown/Pink
Battery Capacity	200mAh

Trouble Shooting

1.Eye mask won't work?
Maybe the battery is run out. Please charge it and try to turn on again.

2.During use, suddenly no sound or sound decreases?
Due to low battery.Please recharge the eye mask before continuing use.

3.During use, voice control responds but doesn't execute commands?
Due to out of battery. Please charge before continuing.

4.No sound after connecting Bluetooth?
If the volume is too low when first connecting to Bluetooth, increase your phone's volume (recommended above 50%). This will be the default volume for future connections.

5.Bluetooth can't connect to other devices?
Previous device may still be paired.Please disconnect and pair with another device.

6.No response to voice commands during use?
The voice control standby time may have ended. Pressing the power button will allow normal use.

7.The remote control is not working?
If this is your first use, please remove the battery tab. If this issue occurs after six months of use, please replace the battery (Battery model: CR2032 3V).

Maintenance And Cleaning

Maintenance:

- Please take measures to prevent moisture, rodents, and pollution.
- Please charge regularly once a month if not used long time.
- For malfunctions,Please contact technicians for repairs Do not dismantle the product by yourself.
- After using,Please put the product in a safe place.Please don't place heavy objects on it to prevent damage.
- If not used for a long time,Please put the product and accessories in the packaging in a dry, ventilated environment to avoid dust.Don't expose them to sunlight to prevent fading or cracking.

Cleaning:

- Please clean and protect the product carefully to avoid damage and pollution.
- Please clean by a soft, damp sponge or cloth.Don't get the product wet.
- During the cleaning process, please prevent water or other liquids from entering the machine to avoid short-circuiting during use.
- Do not use abrasive agents, brushes, gasoline, kerosene, glass/furniture polish, paint thinner, or other corrosive chemical cleaners to clean the product, as these chemicals may cause damage.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

FCC ID:2BB2B-FS201

Warranty Card

Please keep this card properly. The company will take this card as the warranty certificate. Thank you for purchasing this product. The warranty period of this product is 12 months from the date of purchase. Please keep it properly and fill in detailed relevant information for warranty use.

Product model: _____ Date of purchase: _____

Dealer name: _____

User name: _____ Contact number: _____

Address: _____

Explain the reason: ☐ Return goods ☐ Exchange goods ☐ Guarantee

Warranty conditions

When warranty service is required, please show this card and fill in the relevant contents in detail. The company provides users with a 12-month warranty period from the date of purchase.

Warranty scope

The quality problem under normal use is not the damage caused by external damage, the company assumes the responsibility for repair. In principle, the users of the product during the warranty period do not need to pay fees, but due to human damage, the cost of testing or spare parts shall be charged as appropriate. Products beyond the warranty period will be charged.
(Fabric is not covered under warranty)

Warranty is not available under the following circumstances

Man-made damage: for example, due to damage caused improper use and incorrect use, abnormal wear and tear of appearance, falling damage, circuit destruction, extr usion deformation, entry of foreign matters, moisture, alteration or tearing of sealing labels on products, and any other visible man-made damage, and other conditions, such as the user's own reasons.
(unauthorized disassembly and modification, unafraid use, improper operation, water ingress, etc.)
Damage caused by force majeure, such as earthquake, flood, fire, typhoon or war.

MADE IN CHINA