

MINISO

USER MANUAL

使用說明書

User Manual : Cool Style Wireless Headset Manuel d'Utilisation : Casque Audio sans Fil سماعات لاسلكية بتصميم رانج بلبل المستخدم Manual de Usuario : Auriculares de Diadema Inalámbricos Estílo Cool 美拉德絮列頭戴式無線耳機

MODEL: MLD99

使用说明書請仔細閱讀本使用說明書，並請妥善保管。
PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Cautions

1. Do not store or use the product in an environment where the temperature is lower than -10 ° C or higher than +5 ° C. If the ambient temperature is too high or too low, faults may occur.
2. Please place the device and its accessories in a ventilated, cool place away from direct sunlight.
3. Control the volume and time when using the product to avoid hearing damage.
4. Do not pull or twist the product, and avoid contact with liquid and sweat.
5. Do not disassemble, hit, crush the product or throw the device fire to avoid explosion. If the battery edges are sharp, stop using it.
6. When using this device, please keep at least 15 m away from implanted medical devices (such as pacemakers, etc.)
7. Due to the features of BT technology, the strength of the signal is related to the specific environment. If there are more overlapping wireless signals nearby, or there is strong electromagnetic interference, the signal received by the BT speaker will become weaker or even disconnected.
8. If not used for a long time, please charge the pre-product once every three months to avoid weak over-discharge damage;
9. Stop using the equipment before charging or maintaining the equipment. Please wipe the equipment with a clean dry soft cloth.
10. It is recommended to use a brand manufacturer, certified charger with an output voltage of 5V to charge this product. Please avoid using fast-charging chargers with output voltages exceeding 5V to avoid excessive charging voltage damage to the product"

Product Parameters

Wireless Version: 5.4
Pairing Name: MINISO-MLD99
Features: Wireless S, Music Playback; Wireless Calling; Voice Assistant Support; Auto Recognition
Charging Input: 5V=300mA
Battery Capacity: 300mAh
Music Playback Time: Approx. 15h (Volume 50%)
Impedance: 32Ω

Frequency Range: 2402-2480MHz
Sensitivity: 107dB±3dB(A) 1K Hz)
Charging Port: USB-C
Transmission Distance: 10m (indoor, obstacle-free)
Charging Time: Approx. 1.5h
Talk Time: Approx. 13h

Product Structure

① Multifunction Button
② "+" Button
③ "-" Button
④ Indicator Light
⑤ USB-C Port

Functions

Function	Operation Instructions
Wireless Pairing Name	MINISO-MLD99
Power On	Press multifunction button for 3 seconds
Power Off	Press multifunction button for 5 seconds Automatically shuts down if not connected for over 3 minutes
Reconnect	Automatically reconnects to the last connected device after powering on
Play/Pause	Press multifunction button
Answer/End Call	Press multifunction button
Reject Call	Long press multifunction button
Previous Track	Long press "+" button
Next Track	Long press "-" button
Volume Down	Press "+" button
Volume UP	Press "-" button
Voice Assistant	Press multifunction button three times
Restore/Reset to Factory	Long press both the "+" and "-" buttons while in a connected state

Main Accessories

Headphones x 1, Charging Cable x 1, User Manual x 1

Troubleshooting

1. Fail to pair the wireless earphones with your cellphone.
Solution: Check if the earphones are in pairing mode, and whether the phone BT function is on. Check the list of phone, remove the earphones from the phone's Bluetooth list, and follow the instructions of user manual to pair the earphones with your phone again.
2. Cannot turn on the wireless earphones.
Solution: Check the battery level.
3. Can the battery of the wireless earphones be replaced?
Answer: No. The lithium polymer battery in the earphones is irreplaceable.
4. The wireless earphones got disconnected with the phone within 10 meters.
Solution: BT is wireless so it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.
5. Cannot hear audio playing when the earphones are connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.
6. Can I operate the Apps of my phone through the earphones after connecting the wireless earphones to the phone?
Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Précautions à prendre

1. Ne pas conserver ou utiliser le produit dans un environnement où la température est inférieure à -10°C ou supérieure à 45°C. Si la température ambiante est trop élevée ou trop basse, des dysfonctionnements peuvent survenir.
2. Veuillez placer l'appareil et ses accessoires dans un endroit ventilé, frais et à l'abri de la lumière directe du soleil ; 3. Contrôler le volume et la durée d'utilisation de l'appareil afin d'éviter tout dommage auditif.
4. Ne pas tirer ou tordre le produit, et éviter tout contact avec les liquides et la saur.
5. Ne pas démonter, frotter, écraser le produit ou le jeter au feu afin d'éviter toute explosion. Si la batterie est bombée ou fuir, cessez de l'utiliser. 6. Lors de l'utilisation de cet appareil, il convient de respecter une distance d'au moins 15 m par rapport aux dispositifs médicaux implantés (tels que les stimulateurs cardiaques, etc.).
7. En raison des caractéristiques de la technologie BT, la force du signal est liée à l'environnement spécifique. S'il y a plus de signaux sans fil qui se chevauchent à proximité, ou s'il y a de fortes interférences électromagnétiques, le signal reçu par le haut-parleur BT sera plus faible ou même déconnecté. 8. En cas de non-utilisation prolongée, veuillez recharger le produit une fois tous les trois mois pour éviter un sur-déchargement excessif.
9. Cessez d'utiliser l'appareil avant de le nettoyer ou de l'entretenir. Essayez l'appareil avec un chiffon doux, propre et sec.
10. Il est recommandé d'utiliser un chargeur certifié par le fabricant avec une tension de sortie de 5V pour charger ce produit. Évitez d'utiliser des chargeurs à chargement rapide dont la tension de sortie est supérieure à 5 V afin d'éviter que la tension de charge excessive n'endommage l'appareil."

Paramètres du produit

Version sans Fil: 5.4
Nom d'Appareil Sans Fil: MINISO-MLD99
Caractéristiques: Sans Fil 5.4; Lecture de Musique/Appels sans Fil; Prise en charge de l'Assistant Vocal; Reconexion Automatique
Entrée de Charge: 5V=300mA
Capacité de la Batterie: 300mAh
Temps de Lecture de la Musique: Environ 15h (Volume 50%)
Impédance: 32Ω

Structure du Produit

① Bouton multifonction
② Bouton "+"
③ Bouton "-"
④ Indicateur lumineux
⑤ Port USB-C

ISPD Warning:

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(ES). Operation is subject to the following two conditions:
(1) This device may not cause harmful interference,
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Accessoires Principaux

Résolution des problèmes

Les écouteurs sans fil ne peuvent pas être appariés au téléphone.
Solution : Vérifiez si les écouteurs sont en mode d'appairage et si la fonction BT du téléphone est activée. Vérifiez la liste sur votre téléphone, retirez les écouteurs de la liste, suivez les instructions du manuel d'utilisation pour apparaître à nouveau les écouteurs avec votre téléphone.
2. Impossible d'allumer les écouteurs sans fil.
Solution : Vérifier la batterie pour voir si elle est faible.Solution : Vérifier la batterie pour voir si elle est faible.
3. La batterie des écouteurs sans fil peut-elle être remplacée ?
Réponse : Non ; Non. La batterie au lithium polymère des écouteurs est irremplaçable.
4. Les écouteurs sans fil ont été déconnectés du téléphone dans un rayon de 10 mètres.
Solution : La technologie BT étant sans fil, elle est très sensible aux objets situés entre les écouteurs et l'appareil apparié. Vérifiez s'il y a des objets entre eux ou autres qui peuvent affecter l'appariage dans la distance effective.
5. Impossible d'entendre la lecture audio lorsque les écouteurs sont appariés à l'ordinateur ou au téléphone.
Solution : Vérifiez si la sortie audio de l'ordinateur est déjà apparue à une périphérique sans fil et si le Bluetooth de l'ordinateur prend en charge le protocole A2DP. Assurez-vous que le volume est élevé sur votre téléphone ou votre ordinateur.
6. Pouvez-vous utiliser les applications de mon téléphone avec les écouteurs après avoir apparié les écouteurs sans fil au téléphone ?
Réponse : Il se peut que certaines applications ne puissent pas être utilisées via les écouteurs en raison de leurs paramètres.

Avertissement d'ISDE :

Cet appareil contient un (des) émetteur(s)/récepteur(s) exempté(s) de licence qui est (sont) conforme(s) au(x) RSS(ES) exempté(s) de licence du ministère de l'Innovation, des Sciences et Développement Économique du Canada. Le fonctionnement est soumis aux deux conditions suivantes :
(1) Cet appareil ne doit pas causer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.
Cet émetteur ne doit pas être installé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.
4. L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux radiofréquences. L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables.

[illegible]

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.