


User Manual

Made in China

In the course of using the machine, the TFT LCD display sometimes appears bright spots (white, black, red or green) with a diameter of about 0.2 mm. This is a normal phenomenon of active matrix TFT LCD display, and it is not a fault of machine or display. The main reason for bright spots is: TFT LCD displays large and delicate color images, requiring up to hundreds of thousands of pixels throughout the display screen, whose pixels are 1200 (X)*234 (Y)=280800 (280,000 pixels). This phenomenon occurs when each pixel approaches or overlaps, so Toshiba, Panasonic, Hitachi, Sharp, and other companies generally stipulate that LCD screens with three bright dots whose diameter is less than 0.2mm are qualified products.

Wish you a pleasant use!

1)、Instructions



The way to turn on the machine is to press the button. Please press the power button to turn on it. Please click "power off" in the OS to turn off the machine. Pressing the power button for several seconds by force to turn off the machine can only be used in special circumstances. What customers need to pay attention is that frequent power-off by force may cause system files missing or crashing of the PC.

2)、The attentions

Since this PC belongs to the high precision electronic products, please do not disassemble it on your own.
Please avoid a strong throw or a collision of the machine.
Please avoid using the machine in the environments of high/low temperature, humidity, dust, strong magnetic field and long-term exposure to the sun.
Gently wipe the case of the machine with the wrung-out cotton cloth. Don't clean it with chemical solution.
Avoid droplets or splashes on the machine. Don't place it beside a full glass of water or other liquid.
Please use an appropriate volume to avoid hearing impairment.
Please use the battery, power adaptor and other accessories allowed by manufacturers. Use any other type of accessories would violate the warranty ordinance, and lead to possible failure.
Please keep the machine connected in the formatting, uploading or downloading process, otherwise, the program error may appear.
Please dispose of abandoned machines and accessories in accordance with local environmental regulations.
If you have any question about the machine, please contact the local dealer or directly contact our company's customer service center.
For those erasing memory loss caused by product damage, maintenance or other reasons, our company does not pay any responsibility. Please refer to the manual for standardized operation.
Because of the large charging voltage and current required by the machine, after connected with other devices, it can only be used for storage and copying.
Charging can only be conducted with the original charger.
The company reserves the right to upgrade the products, change the specifications or design without notice.

3)、The solution to common problems

1. Incapability of being turned on.
a. Check whether the battery is fully charged.
b. Check the machine again after being connected with a power adapter.
C. If it is still unable to boot after charging, please contact our distributors.

2. Incapability of being connected to WIFI.

a. Please confirm whether there is a WiFi hotspot.
b. Make sure the machine is connected to WiFi (to enter the settings interface).
C. Please check the WiFi signal strength and the permission for connection.

4)、Technical specifications

Brand	Zwide
Model	NA105H
Operating System	Windows 11
CPU Brand	Intel N150
Screen size	10.5 inch
Screen scale	3:2
Screen Resolution	1920*1280
Net work	WiFi6 (802.11ax1)
Function	HOST、Bluetooth5.2
Sensor	Gravity sensor
Other interface	3.5mm headphone jack, TYPE-C *2
Camera	Front : 2MP
Battery capacity	7.6V/3800mAh
Charger	Input: AC100-240V, 50-60Hz Output: 12V=3A
Size	243.0x177.6x17.7 mm
Play format	Voice format: OGG, ACC, M4A, FLAC, AMR etc Video format: AVI, MKV, MP4, M4V, WEBM, 3GP, MPEG4 etc

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Introduction

Dear customers, thank you for purchasing Zwide products. This PC is elaborately manufactured by Zwide to enable you freely surf on the Internet. Please read this user manual carefully before using the machine to ensure the proper usage of it!

Disclaimer:

1. Please be sure to use Zwide's original chargers of 12V/3A. For problems or faults caused by not using the original power adapter, the company does not undertake any responsibility.
2. PC belongs to the high-tech product, which includes software and hardware. You can use the music, video, pictures or software provided by the third part, but we don't take any responsibility for the copyright issue or product failure.
3. If the product breaks down, we will repair it according to the strict warranty terms. We will take no responsibility for the possible property damage or economic loss caused by the users themselves during usage.
4. The device has built-in software, which can be normally used after the actual test at the factory. However, if you find compatibility or other issues of the software, you can delete or ignore it, which will neither have any impact on the machine nor belong to the issue of product quality.
5. The company reserves the right to improve or upgrade the products, change the specifications or design! Please take actual product shall prevail.
Please note the following in using:
 1. Since the machine will consume a lot of power in playing video, WiFi surfing and playing heavy games, resulting in the high temperature of it, so please don't continuously use the machine for a long time, to avoid the abnormal phenomena such as halted system caused by high temperature.
 2. Please charge the machine fully around once a week if you don't use it for a long time, in order to prevent the machine from being too useless to start for a long time.
 3. USB line and power charger must use the original one of the company, otherwise there may be a phenomenon that the battery can not be charged.
 4. Please charge the machine under the following circumstances:
 - A, the battery ICONS shows no electricity
 - B, Automatic shut down or incapability of being turned on.
 5. If the performance of the machine needs to be upgraded, please enter Chuwi's official website to download the latest firmware and upgrade the machine according to the instructions.