


Identify QR codes to learn more about the company



# TWS耳机 说明书



# KONIYCOI®

KONIYCOI<sup>6</sup>

#### 让耳朵舒适地享受音乐

- 1.遵从听力专家的意见根据自身情况不要把您的音乐播放器调到很高的音量,不要连续长时间使用耳机,注意适当地让耳朵休息。
- 2.如果你感到声音刺耳,请降低音量或停止使用耳机。

#### 充电

- ①使用 Type-C 充电线给充电盒充电。
- 1.充电盒接入充电线后,插入Type-C充电头或者运行状态下的电脑USB接口。
- 2.充电过程中,充电盒LED红色指示灯闪烁。
- 3.当充满电时,充电盒LED指示灯恒亮。

#### 4.使用充电盒给耳机充电

- ①将耳机准确放入盒中位置并盖上盒盖。充电过程中, 耳机LED红色指示灯长亮。
- ②当充满电时,耳机LED指示灯停止闪烁。

#### 匹配

- 1.确保耳机和无线设备距离相近(1米内)。
- 2.耳机从充电仓拿起自动开机,自动匹配,此时红蓝色LED 指示灯快闪。
- 3.打开手机上的无线功能并搜索附近的无线设备。
- 4.连接成功后,LED指示灯停止闪烁。



KONIYCOI\*

Face The World And Say: I Have My Strength!

#### 产品说明



### 参数

| 型号:  无线:         | V5.3<br>4-6小时<br>5-30小时<br>400mAh<br>16Ω<br>1.5h<br>5V==0.5A<br>40mAh<br>230hrs<br>Type-C |
|------------------|---|
| 充电口:HSP\HFP\A2DI |   |

# KONIYCOI®


#### 按键控制

| 功能      | 操作                               |
|---------|----------------------------------|
| 开关机     | 耳机从充电仓拿起自动开机                     |
| 播放/暂停   | 左耳或者右耳短按                         |
| 音量 加/减  | 右耳三击或左耳三击                        |
| 上一曲/下一曲 | 左耳双击或者右耳双击                       |
| 接听/挂断   | 左耳或者右耳短按                         |
| 回拨电话    | 无                                |
| 对耳配对    | 耳机从充电仓拿起自动开机<br>自动配对             |
| SIRI    | 长按左耳或右耳,听到beep<br>一声后松手,打开siri功能 |

| LED 指示灯 | 状态   |
|---------|------|
| 红蓝灯交替闪烁 | 配对模式 |
| 亮蓝灯     | 开机   |
| 亮红灯     | 关机   |
| 红灯常亮    | 正在充电 |
| 红灯灭     | 充电完成 |



# TWS earbuds



## ENJOY MUSIC COMFORTABLY

Please follow the suggestions of audiologist. Do not listen to music at high/max volume, do not use earphone for a long time.

2. If the sound is too piercing, please turn down the volume or stop using the earbuds.

### CHARGING

Charge the charging case with Type-C cable

- Charge the charging case via an adaptor or a working computer through it's USB port.
- when charging, the red LED light indicator of the charging case blinks
- When charging is completed, all LED light indicators of
- the charging case turns on without blinking.

  4. Charge the earphones with the case
- ①Put the earphones in correct slot and close the charging case, the earphones will be charged automatically and
- light indicator turns red

  ②When earphones charging is completed, earphone light indicator is off

#### PAIRING

- 1. Make sure the earphones and your wireless device are next to each other ( within 1 meter)
- Take out the earbuds from charging case, they will automatically power on and paired, the earphone light indicator flash red and blue alternately
- 3. Activate the bluetooth function on your phone and search for device name NK6
- 4. Once connected, the earphone red light will flash slowly.

### PRODUCT MANUAL



#### PARAMETER

| model:  |                           |
|---|---------------------------|
| Wireless:                                     | V5.3                      |
| Music time (earphone full power state):       | 4-6hrs                    |
| Music time (earphone full power + charging bo | ox full power condition): |
|   | 25-30hrs                  |
| Charging box battery capacity:                | 400mAh                    |
| Trumpet impedance:                            | 16Ω                       |
| Headset charging time:                        | 1.5h                      |
| Enter:  | 5V== 0.5A                 |
| Headphone battery capacity (single):          | 40mAh                     |
| Standby time:                                 | 230hrs                    |
| Charging port:                                | Type-C                    |
| Support:                                      | . HSP\HFP\A2DP\AVRCP      |



#### BUTTON CONTROL

| Function                      | Operation   |
|-------------------------------|---|
| Power on/off                  | Take out from/put in the charging case                        |
| Pairing Mode                  | Automatically pairing when taken out from<br>charging case    |
| Play/Pause                    | Short touch left/right side                                   |
| Next song                     | Touch the right side 2 times                                  |
| Previous song                 | Touch the left side 2 times                                   |
| Volume+                       | Touch the right side 3 times                                  |
| Volume-                       | Touch the left side 3 times                                   |
| Answer phone Call/<br>Hang up | Short touch left/right side                                   |
| SIRI                          | Long touch on left/right side,until<br>hearing the 'beep'tone |

| LED Indicator             | Status                        |
|---------------------------|-------------------------------|
| Red light flashes quickly | / In pairing mode             |
| Red light flashes slowly  | Paired with a wireless device |
| Red light flashes quickly | / Power on                    |
| Red light on              | Power off                     |
| Light off                 | Charging complete             |





# **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.