


Appendix II


Internal Photographs

SIF30-I0750/120-277/T/D1/F/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector




Antenna



SIF50-I1250/120-277/T/D1/F/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3



Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector



Antenna



SIF30-I0750/120-277/T/D1/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector



Antenna




SIF50-I1250/120-277/T/D1/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector



Antenna



SIF30-I0750/120-347/T/D1/F/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




RF Module




Antenna Location



Antenna Connector



Antenna



SIF50-I1250/120-347/T/D1/F/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3



Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector



Antenna



SIF30-I0750/120-347/T/D1/APP


Open View of EUT



Internal View of EUT-1




Internal View of EUT-2



Internal View of EUT-3




Internal View of EUT-4




RF Module




Antenna Location



Antenna Connector



Antenna




SIF50-I1250/120-347/T/D1/APP


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




RF Module



Antenna Location



Antenna Connector



Antenna

