

English instructions for smart glasses (Key payment)

measure : 40mm×175mm

PS : The key fonts have been marked in red, and they should also be printed in red.

<div>Multifunctional Smart Glasses</div> <div>(J1 Instruction Manual)</div> <div><div>1.Long press the power button for 3S to boot.</div><div>2.Press the power button twice to the next song.</div><div>3.Press the power button 3 times to the previous song.</div><div>4.Press 4 times to switch between Chinese and English mode (Used when the device is turned on and not connected).</div></div> <div><div>• Disclaimer</div><div>First of all,thank you for using out products! Please read this manual before using and use this product correctly.For the better service, changes due to the performance and functionality of the product will be revised without notice.Open-ear smart audio glasses.This product is a Bluetooth speaker withstereo function,easy to operate, stylish and practical,easy too carry.</div><div>• Product Introduction</div><div>Multifunctional smart glasses use Bluetooth chips, compatible with mainstream brand mobile phones and tablets and other Bluetooth devices, support aptX audio decoding technology, achieve CD-level high-quality sound quality, long-lasting battery life, left and right double speakers, open directional pronunciation, and barrier-free reception of external sounds. The surrounding environment information can be obtained at all times, which is safe, intelligent, healthy and convenient.</div><div>• Packing List</div><div>Audio glasses,Glasses charging cable, Instruction manual,Glasses cleaning cloth.</div></div>	<div><div>• Directions For Use</div><div>(1)Glasses switch machine and matching. Turn on the bluetooth device such as the mobile phone,press and hold the power button for 3 seconds,the glasses voice prompts [power on], and the LED indicator light keeps flashing at this time;after the connection with the bluetooth device is successful,the indicator light goes out. (For detailed operation, please refer to the bluetooth connection diagram on the last two pages)</div><div>(2)Charging and alarm. 1.Low power alarm,voice prompts [batt ery low],the LED indicator continues to blink 3 seconds interval 5 seconds. 2.Low power off,voice prompts [power off], the LED indicator for 1second long. 3.During charging,the red light of the LED indicator is long. 4.When the charging is completed,the LED indicator red light will automatically go out.</div><div>(3)Functional Operation The phone is connected, and in the standby mode, press the power button twice to wake up the voice assistant.</div></div> <div><div>• Product Parameters</div><div>Frame Material: ABS+PC Lens Material: AC Lens Color: Sunglasses color (Multiple options) Bluetooth Protocol: 5.3 Charging Time: 1.5H Use Time: 3-4H Standby Time: 120H(Bluetooth connection) Battery Capacity: 110mAh Sound Channel: Double speakers, stereo sound Charging Voltage And Current: DC5V/120mA</div><div>• Warm Prompt</div><div>Charging time: 1-2 hours. When not in use for a long time,charge the battery at least once every 2 months.</div></div>	<div><div>1. Making and receiving calls. • Make a phone call: Press the power button twice in succession,and when you hear the prompt tone,call ** (the name in the address book) or the phonenumber of the other party, then you can make a phone call; • Answer the call: Single press the power button to answer the call; • Hang up the call: Single press the power button to hang up the call; • Redial: Press the power button three times in succession to redial the last call record; 2. Listen to music. • Accurate song selection: Press the power button two times and say "Play music" after hearing the prompt sound (such as Shanghai Tang), then you can call and play the songs inside the phone; • Random play: Press the power button two times, and when you hear the prompt sound, say "Play music",you can call and randomly play the songs inside the phone; • Play the next song: Press the power button two times; • Play the last song: Press the power button three times in a row; • Pause playback: Single press the power button.</div><div><div>⚠ Caution</div><div>Please follow the relevant laws and regulations and do not use headphones in the following environments. • Such as gas stations, oil depots, chemical warehouses and other environments where flammable and explosive gas or chemicals are stored, it is strictly prohibited to use the equipment. • Do not use this device in hospital operating rooms, emergency rooms, intensive care units, etc.; in order to avoid interfering with the work of medical equipment, please keep away from pacemakers, hearing aids, cochlear implants and other medical equipment when using this device, please keep this More than 15 cm between the device and the pacemaker. • To use this device near personal medical equipment, consult your physician and device manufacturer. • Follow all safety warnings and regulations regarding the use of this device while driving. • During thunderstorms, do not use it outdoors in order to avoid lightning accidents. • When charging, do not make a call while charging.</div></div></div>	<div><div>3. Switch between playing music and making phone calls. • When you need to make a call while listening to music,first press the power button to pause the music,and then press the power button twice to make the call after hearing the prompt tone. 4. Navigation. • Turn on the navigation: press the power button twice, say "Help me navigate to the ** position" after hearing the prompt,and then perform voice operations according to the prompt sound of the glasses; • Turn off the navigation: Press the power button twice,and then say "Exit the navigation" after hearing the prompt tone. 5.Offline camera function,etc • When the camera is turned on,single press the power button to take a photo.</div><div><div>• Tips</div><div>1.Please read the instructions carefully before using this product and keep this manual. 2.For the first time,please fully charge this glasses. 3.If the glasses does not charge for a long period of time (more than two weeks),charge it before use.</div><div>• Do not use the charger in a place with high humidity such as a bathroom, otherwise it may cause electric shock, personal injury, fire and damage to the charger. • Please comply with the relevant legal provisions that are expressly prohibited in any environment.</div><div><div>• Product warranty certificate</div><div>During the product warranty period, non-human-damaged performance failures can enjoy the following three-guarantee services: • Within 7 days from the date of receipt, if the product has a performance failure that is not artificially damaged, the user can choose to return the payment or replace the product with the same model and specification. • Within 15 days from the date of receipt, the user can choose to replace the product with the same model and specification if the product has a performance failure that is not artificially damaged. • Within one year from the date of receipt of the product, if the product has a performance failure that is not artificially damaged, the user can send it to the merchant for repair.</div></div></div></div>	<div><div>• Warning</div><div>1.Do not dismantle or repair this product for any reason,as this may result in fire. Electronic breakdown or even complete damage to the product. 2.Do not place the device in an environment where the temperature is too low or too high(below 0°C or above 45°C). 3.Do not get the product wet with liquid or immerse in liquid. 4.Do not expose the glasses to the sun for a long time,otherwise it will be easily deformed,broken and broken. 5. Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetically attracting metal objects.</div><div><div>• Important Safety Information</div><div>1. Before using this product, please read all safety information to ensure correct and safe use. 2. Using a power supply, charger or battery not approved by the original manufacturer may cause fire, explosion or other hazards. 3. Please use the accessories approved by the manufacturer and matched with this model of equipment.</div></div><div><div>Schematic diagram of Bluetooth connection</div><div><div>① Go to settings</div><div><div>② Select the Bluetooth option</div></div><div><div>③ Make sure the Bluetooth switch is ON, search for the device name: J1, click the Bluetooth name to enter the connection.</div></div><div><div>④ The bluetooth connection is successful.</div></div></div></div></div>	<div><div>4.Use accessories approved by this manufacturer and compatible with this model.Please use the device within the temperature range of 0°C-35°C, and store the device and its accessories within the temperature range of -20°C - 55°C. When the ambient temperature is too high or too low,it may cause equipment failure. 5.If the device uses a non-removable internal battery do not replace the battery yourself to avoid damaging the battery or device.The battery can only be replaced by an authorized service center. 6.If charging is complete ,disconnect the charger from the device the unplug the charger from the power outlet.Do not charge more than 12 hours. 7. Please keep the device dry. 8. If the equipment or any other parts do not work properly, please do not repair the product by yourself. 9. When connecting to other devices, please refer to the connection method in the user manual, and do not connect any unsuitable devices at will.</div><div><div>FCC Statement</div><div>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: — Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver. — Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help.</div><div>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div><div>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div><div>The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.</div></div></div>
---	---	---	--	---	---