

无线蓝牙耳机EW305使用说明 中国制造



地址:天津自贸试验区(空港经济区)空港国际物流区第二大街1号 服务热线:400-0100-800

功能

开机

关机

播放

暂停

接听

拒绝

挂断

音量加

音量减

上一曲

下一曲

SIRI

连接成功

断开连接

低电量

多功能触控区

当前状态

关机

开机

已连接

音乐播放

第一个来电打讲

第一个来电打进

双方通话中

音乐中/诵话中

音乐中/通话中

音乐中

音乐中

音乐中/联机中

耳机参数 蓝牙版本: 5.1 佩戴方式: 入耳式 最大工作距离:10m(无障碍) 电池容量:30mAh

耳机播放时间:4-5h 配对名:EW305



充电盒参数

电池容量: 250mAh 充电电流:5V/1A 充电接口:TYPE-C

充电盒充电红灯闪烁,充满红灯常亮

注意事项

- 1.请勿将无线耳机摔落,撞击,刮擦,扭曲,敲打,碾压,投入水中等 2.使用无线耳机时,请将其远离磁体,电器和扬声器附件; 3.尽量避免将无线耳机放置于极端温度中(使用环境工作温度范围-10
- 4.避免将无线耳机暴露在潮湿的环境中;
- 5.若长时间不使用无线耳机,请充满电并隔一星期充一次电,延长无线 耳机使用寿命:
- 6. 请勿让无线耳机靠近火源
- 7.请勿将无线耳机与充电仓放在易燃易爆物品旁边;

提示音

Power on

最大音量-嘀嘀

Connected

Battery low

操作

拿出充电仓自动关开机/

手动开机长按3S

手动关机长按5S

单击

単击

单击

长按1.5S

双击右耳

双击左耳

三击主耳L

三击副耳R

长按2S

给充电仓充电请使用标准直流充电器(DC 5V/500MA-1A); 请勿拆卸充电仓与无线耳机。或者将其他物品插入产品内,以避免产品 **捐坏给您带来伤害**

请勿在充电时使用本产品,请使用厂家指定的适配器给产品充电。 内置锂电子电池切勿拆开放置火中,不可让金属物品接触或短路电极 不可碰击和挤压电池,避免放置于潮湿腐蚀或过热(>60°C)环境中。

来酷售后服务承诺:

本产品售后有效期:自购买之日起,在正常使用的情况下提供整机一年保 修服务,其他附件(如包装等)不属于售后范围之内。

售后服务

- 以下情况不属于售后范围
- 1、 不能提供有效的凭证及有效发票的 (能证明此产品在产品售后有效期 内除外)或擅自涂改有效凭证的;
- 2、 有效凭证上的产品型号及序列号与产品实物不相符合的;
- 3、未按产品使用说明的要求使用、维护和保管而造成损坏的;
- 4、因意外灾害、自行拆卸、人为损坏或经非本公司授权之外服务站维修 所引起的故障:
- 5、因不可抗力因素所造成的损坏。

包装内容

- 1、无线耳机2PCS
- 2、充电收纳盒1PCS
- 4、充电线一条

合格证 检验员: QC03




COO TWS Wireless Earbuds EW305 User Guide Made in China



Manufacturer: Lecoo Technology Co., Ltd Address: No. 1, 2nd Street, Airport International Logistics Zone, Tianjin Pilot Free Trade Zone (Airport Economic Zone) Hotline: 400-0100-800

product description

Earbuds parameter Wearing method: in-ea Maximum working distance: 10m Battery capacity: 30mAh Headphone play time: 4-5h Pairing name: EW305



Back of the charging case **Charging Case Spec**

Charging interface: TYPE-C The red light of the charging box is flashing, and the red light is always on when fully charged



	operating	
Power off	Take out the charging compartment and automatically turn off the machine/ Manually turn on and long press for 3S	Power on
Power on	Put it into the charging compartment and automatically shut down/Manual shutdown long press 5S	Power off
Connected	Click the touch area	
Play music	Click the touch area	
The first call comes in	Click the touch area	
The first call comes in	Long press the touch area for 1.5S	
Calling	Click the touch area	
In music/calling	Double tap the right ear touch area	Maximum volume "beep-beep"
In music/calling	Double tap the left ear touch area	
In music	Triple tap the left ear touch area	
In music	Triple tap the right ear touch area	
Music/Online	Long press 2S	"Beep"
		Connected
		Disconnected
		Battery low
	Power on Connected Play music The first call comes in The first call comes in Calling n music/calling n music/calling In music In music	Power off And automatically turn off the machine/ Annually turn on and long press for 3S Put it into the charging compartment and automatically shut down/Manuall shutdown long press 5S Connected Click the touch area Play music Click the touch area The first call comes in Calling Click the touch area for 1.5S Calling Click the touch area n music/calling Double tap the right ear touch area In music In music Triple tap the left ear touch area Triple tap the right ear touch area

02 EN

Precautions

- 1. Do not drop, impact, scratch, twist, beat, crush, drop into the water,
- 2. When using a Wireless Farbuds, please keep it away from magnets.
- When using a Wireless Earbuds, please keep it away from magnets electrical appliances and speaker accessories;
 Try to avoid placing the Wireless Earbuds in extreme temperatures (working environment operating temperature range -10 C -45 C);
 Avoid exposing the Wireless Earbuds to a humid environment;
 If you don't use the Wireless Earbuds for a long time, please fully charge it and charge it every other week to extend the service life of the
- wireless Earbuds
 6, Do not put the Wireless Earbuds near the fire source;
 7. Do not place the Wireless Earbuds and charging compartment next to flammable and explosive items;

the standard DC charger (DC 5V/500MA-1A) to charge the charging compartment; do not disassemble the charging compartmen and Wireless Earbuds. Or insert other items into the product to avoid damage to you caused by product damage.

- duct while charging, please use the adapter
- specified by the manufacturer to charge the product.

 Do not disassemble the built-in lithium electronic battery and place it in a fire. Do not allow metal objects to contact or short-circuit the electrode. Do not hit or squeeze the battery. Avoid placing it in a wet,

03 EN

After-sales service

- After-sale period of validity of the product: from the date of purchase, the product is provided with one-year warranty service under normal use. Other accessories (such as packaging, etc.) are not within the scope of after-sales service.
- The following situations are not covered by after-sales service:

 1, Unable to provide valid warranty card and valid invoice (not including
- those that can prove the product is within the valid warranty period) or alter the warranty without authorization;

 2. The product model and serial number on the warranty card are not
- consistent with the real product:
- Damage is caused by failure to use, maintain and keep the product according to the instructions;
- 4. Damage caused by accident, personal dismantle, man-made damage or repair of service stations not authorized by the Company; 5. Damages caused by force majeure.

Package Contents

- 1.Wireless Earbuds 2pcs 2. charging box lpcs instruction
- 3.manual lpcs 4.1 charging cable

QC PASS Inspectors: QC03



radio frequency energy and, it not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

of the following measures:

cause undesired operation.

- -Reorient or relocate the receiving antenna.
 -Increase the separation between the equipment and receiver.
 -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 -Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject (1) This device complex with part 15 of the PCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

for compliance could void the user's authority to operate the equipmen

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

The device has been evaluated to meet general RF exposure requ The device can be used in portable exposure condition without restriction.



说明书 折后尺寸:70*80mm 材质:100g书写纸 黑白印刷 风琴折

