



无线蓝牙耳机EW310使用说明
中国制造



关注联想智生活

制造商：来酷科技有限公司
地址：天津自贸试验区（空港经济区）空港国际物流区第二大街1号
服务热线：400-0100-800

产品介绍



触控位

耳机参数

蓝牙版本：5.1
佩戴方式：入耳式
最大工作距离：10m (无障碍)
电池容量：30mAh
耳机播放时间：2-3h
配对名：EW310

充电盒参数

电池容量：180mAh
充电电流：5V/500mA
充电接口：TYPE-C
充电盒充电红灯闪烁，充满红灯常亮

功能	当前状态	说明
开机	关机	拿出充电仓自动开机
关机	开机	放入充电仓自动关机
TWS配对	开机	首次开机自动TWS配对
播放/暂停	已连接	单击触控位
接听	第一个来电打进	单击触控位
拒绝	第一个来电打进	长按触控位1.5S
挂断	通话中	单击触控位
音量加	音乐中/通话中	双击右耳触控位
音量减	音乐中/通话中	双击左耳触控位
SIRI	音乐中/联机中	长按2S触控位
上一曲	音乐中	三击左耳触控位
下一曲	音乐中	三击右耳触控位

注意事项

1.请勿将无线耳机摔落，撞击，刮擦，扭曲，敲打，碾压，投入水中等
2.使用无线耳机时，请将其远离磁体，电器和扬声器附件；
3.尽量避免将无线耳机放置于极端温度中（使用环境工作温度范围-10°C-45°C）；
4.避免将无线耳机暴露在潮湿的环境中；
5.若长时间不使用无线耳机，请充满电并隔一星期充一次电，延长无线耳机使用寿命；
6.请勿让无线耳机靠近火源；
7.请勿将无线耳机与充电仓放在易燃易爆物品旁边；
8.禁止快充

安全指导：
给充电仓充电请使用标准直流充电器（DC 5V/200MA-1A）；
请勿拆卸充电仓与无线耳机。或者将其他物品插入产品内，以避免产品损坏给您带来伤害。

严重警告：
请勿在充电时使用本产品，请使用厂家指定的适配器给产品充电。
内置锂电池切勿拆开放置火中，不可让金属物品接触或短路电极，
不可碰击和挤压电池，避免放置于潮湿腐蚀或过热(> 60°C)环境中。

包装内容

1. 无线耳机2PCS
2. 充电收纳盒1PCS
3. 说明书
4. 充电线一条

售后服务

来酷售后服务承诺：
本产品售后有效期：自购买之日起，在正常使用的情况下提供整机一年保修服务，其他附件（如包装等）不适用于售后范围之内。
以下情况不适用于售后范围：
1. 不能提供有效的凭证及有效发票的（能证明此产品在产品售后有效期内外）或擅自涂改有效凭证的；
2. 有效凭证上的产品型号及序列号与产品实物不相符合的；
3. 未按产品使用说明的要求使用、维护和保管而造成损坏的；
4. 因意外灾害、自行拆卸、人为损坏或经非本公司授权之外服务站维修所引起的故障；
5. 因不可抗力因素所造成的损坏。

合格证

检验员：QC03




TWS Wireless Earbuds
EW310 User Guide
Made in China



Follow Lenovo Smart Life

Manufacturer: Lecoo Technology Co., Ltd
Address: No. 1, 2nd Street, Airport International Logistics
Zone, Tianjin Pilot Free Trade Zone (Airport Economic Zone)
Hotline: 400-0100-800

product description



Touch position

Earbuds parameter
Bluetooth version: 5.1
Wearing method: In-ear
Maximum working distance: 10m
Battery capacity: 30mAh
Headphone play time: 2-3h
Pairing name: EW310

Charging Case Spec
Battery capacity: 180mAh
Charging current: 5V/500mA
Charging interface: TYPE-C
The red light of the charging box is flashing, and the red light is always on when fully charged

status	operating
Power on	Take out the charging bin headphones automatically shut down the power
Power off	Put into the charging bin headphones automatically shut down
TWS Pairing	Automatic TWS pairing on first boot
Play/pause	Click on the touch position
Answer	Click on the touch position
Rejected calls	Long press the touch position 1.5S
Hang up	Click on the touch position
Volume +	Double click on the touch position
Volume -	Double click on the touch position
Siri	Long press 2S left or right touch position
Previous piece	Three-strike left touch position
Next track	Three-strike right touch position

Precautions

1. Do not drop, impact, scratch, twist, beat, crush, drop into the water, etc, the Wireless Earbuds
2. When using a Wireless Earbuds, please keep it away from magnets, electrical appliances and speaker accessories;
3. Try to avoid placing the Wireless Earbuds in extreme temperatures (working environment operating temperature range -10°C - 45°C);
4. Avoid exposing the Wireless Earbuds to a humid environment;
5. If you don't use the Wireless Earbuds for a long time, please fully charge it and charge it every other week to extend the service life of the Wireless Earbuds;
6. Do not put the Wireless Earbuds near the fire source;
7. Do not place the Wireless Earbuds and charging compartment next to flammable and explosive items;
8. No fast charging

Safety guidance:
Please use the standard DC charger (DC 5V/200MA-1A) to charge the charging compartment; do not disassemble the charging compartment and Wireless Earbuds. Or insert other items into the product to avoid damage to you caused by product damage.

Serious warning:
Do not touch this product while charging, please use the adapter specified by the manufacturer to charge the product.
Do not disassemble the built-in lithium electronic battery, and place it in a fire. Do not allow metal objects to contact or short-circuit the electrode. Do not hit or squeeze the battery. Avoid placing it in a wet, corrosive or overheated (>60°C) environment.

After-sales service

Lecoo After-sales Service Commitment:
After-sale period of validity of the product: from the date of purchase, the product is provided with one-year warranty service under normal use. Other accessories (such as packaging, etc.) are not within the scope of after-sales service.
The following situations are not covered by after-sales service:
1. Unable to provide valid warranty card and valid invoice (not including those that can prove the product is within the valid warranty period) or after the warranty without authorization;
2. The product model and serial number on the warranty card are not consistent with the real product;
3. Damage is caused by failure to use, maintain and keep the product according to the instructions;
4. Damage caused by accident, personal dismantle, man-made damage or repair of service stations not authorized by the Company;
5. Damages caused by force majeure.

Package Contents

1.Wireless Earbuds 2pcs
2. charging box 1pcs instruction
3.manual 1pcs
4. charging cable

QC PASS

Inspectors: QC03

说明书

折后尺寸：70*80mm

材质：100g书写纸 黑白印刷

风琴折

