

InvisiClean Aquanova

Air Purifier & Humidifier



USE & CARE INSTRUCTIONS

If you have any questions, please email us at support@invisiclean.com or call us at 818-787-1188 Monday-Friday 9AM-5PM Pacific time for immediate assistance.

READ AND SAVE THESE INSTRUCTIONS

WARNING

Failure to comply with the warnings listed below may result in electric shock or serious injury.

 This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Read all instructions before using appliance.
- To avoid fire or shock hazard, plug the appliance directly into an AC outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the machine before moving it, changing filters, cleaning, or whenever the machine is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

- DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Contact customer service for assistance.
- Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- DO NOT use outdoors.
- DO NOT place anything on top of unit.
- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.


DO NOT add hot water into water tank. Use only cold water (tap water, distilled water, mineral water, or other drinking water)

DO NOT drink the water used in the water basin and do not use it for animals or plants. Empty the water basin into a drain.

DO NOT add water through the air outlet of the humidifier.

- **WARNING:** To reduce the risk of fire or electric shock, do not use this device with any solid-state speed control device.

PRODUCT STRUCTURE



AIR CLEANING SYSTEM

PRE-FILTER: Captures initial large particles and dust.

HEPA FILTER: Captures dust, smoke, pollen and other allergens.

HUMIDIFICATION SYSTEM

HUMIDIFICATION FILTER: Absorbs water and allows air to pass through the wet surface of the filter and humidifying the air.

OPERATING INSTRUCTIONS


BEFORE OPERATING THE MACHINE:

1. Carefully lift your machine from the box and remove the plastic bags from unit and humidification filter.
2. Select a firm, level and flat location for the machine.
3. Plug the power cord into a right voltage AC outlet.
4. When moving the product, lift it from the bottom of water tank carefully.

*For proper air flow, locate the unit at least 1 foot from any wall or furniture.

*Make sure none of the grills are blocked.

OPERATING THE AIR PURIFIER&HUMIDIFIER



POWER & WI-FI BUTTON:

The power button is used to turn the unit on and off. While the unit is on, pressing the power button for 3 seconds will reset the wi-fi connection for setup.



TIMER BUTTON:

Programmable timer to turn off the unit after a pre-set amount of time. Press the “Timer Button” to set the timer between 1 to 12 hours. Pressing one more time after 12 will turn the timer off. Pressing the timer button while the timer is activated will show the hours left on the display screen on the current timer. Pressing again will start cycling through the settings again.



SPEED BUTTON:

Press this button to cycle through the speed settings: I (Low), II (Medium), III (High), IV(Turbo) and Auto mode.

Auto mode automatically changes fan speeds depending on air quality levels. The circular light surrounding the control panel will show blue(good), yellow(moderate), orange(bad) and red(dangerous) depending on air quality. During normal use the fan will stay on low until a change in air quality is detected. The AUTO indicator light will display on the screen when auto mode is enabled.



AIR QUALITY INDICATOR LIGHT BUTTON:

Press this button to turn the air quality indicator light on and off.



SLEEP BUTTON:

Sleep mode will turn off all lights on the unit, allowing the unit to run in complete darkness. Set the air purifier to the desired settings and press sleep mode and the screen will turn off. Press any button on the unit to turn sleep mode off.



WATER LEVEL & CHILD LOCK BUTTON:

Pressing this button will show how much water is left in the unit. For example, 100% will mean the unit is full, 50% will indicate it is half full, and 0% will indicate the unit needs to be refilled.

Child lock will lock the controls so it cannot be changed accidentally by children or pets. To turn on and off, press and hold this button for 5 seconds until the child lock indicator turns on or off on the display screen. Pressing any button while child lock is enabled, the child lock indicator will blink on the screen.



FILTER RESET BUTTON

Pressing this button will display how much life is left on the filter indicated by a percentage. When the filter needs to be checked or replaced the red replace filter indicator on the screen will illuminate. The replace filter indicator is based on 4320 hours or 180 days of usage time. Your actual replacement time may be longer or shorter depending on the environment it is used in. To reset the indicator after the filter has been checked or replaced, press and hold the filter reset button for 5 seconds.

Important note: When the unit is not in use, please switch it off and unplug it.

SETTING UP WI-FI CONNECTION

Wi-Fi setup is not required and will turn off after 10 minutes if not used.

1. Make sure your phone is connected to your Wi-Fi network (Not your cellular data) while you add the device to your app.
2. Make sure the Wi-Fi icon on the air purifier display is blinking. If not, press and hold the power button while the unit is on for 5 seconds to activate the Wi-Fi connection.

Step 1

Search for and download the “InvisiClean” app in App Store or Play Store. Both IOS and Android versions are available. Create a new account or login if you already have an account.

Step 2

Make sure you are connected to your Wi-Fi and your Bluetooth is enabled. Tap the + sign and select “Add Device”. The app will scan and look for your air purifier. Tap the air purifier and you will be prompted for your Wi-Fi password. Enter the Wi-Fi password and the air purifier will be added.

Step 3

The device will now appear in the InvisiClean app and you will be able to control the air purifier from anywhere you have internet service. Please note the air purifier must also have access to a Wi-Fi connection. If your air purifier is moved to a new network or Wi-Fi settings are changed you will need to reconnect the air purifier by pressing and holding the power button while the unit is on for 5 seconds. The Wi-Fi icon will blink to show it is ready for a new connection.

WATER LEVEL INDICATOR



1. When the water tank is not installed correctly or the water level detection contact is poor, the water level indicator will flash orange.
2. When the water level is low, the water level indicator light will turn orange.
3. When the water level is normal, the water level indicator light will turn white.

ADDING WATER



1. Using the handle on the top of the unit, lift the main upper body off the water tank and set aside.
2. Add water to the water tank, the humidification filter can be left in the tank. Do not to fill past the maximum water level indicator.
3. Place the main upper body back on the water tank ensuring the arrows on the front of the unit are aligned.


REPLACING FILTERS

REPLACE FILTER INDICATOR

CAUTION: Before replacing filters, turn OFF and unplug the unit.

Note: It is recommended that the filters are cleaned monthly and replaced every 6-12 months, depending on the air quality and environment it is used in

The REPLACE FILTER INDICATOR lighting up indicates that it is time to replace the filter. Follow the instructions below to change filter and reset the light.



1. Unplug the unit from power and lift up the main upper body of the machine and place on a soft surface upside down.
2. To remove the HEPA filter, turn the filter to the left using the tabs on the filter. The arrows on the filter body will indicate which way to turn to remove the filter. Replace with a new filter and turn right to lock it in place.
3. The humidification filter can just be lifted out and replaced.
4. Replace the main upper body to the water tank ;
5. Reset the filter timer by pressing and holding the filter reset button.

CLEANING & MAINTAINANCE

The machine should be cleaned at least once every month by a clean, dry, soft cloth. More frequent cleaning may be required depending on environmental conditions.

CAUTION: Before cleaning, turn OFF and unplug the unit.

NOTE:

Do NOT stick any foreign objects or your fingers inside of the unit. Do NOT use gasoline, benzine, thinner, harsh cleaners, etc. on or in the unit while cleaning as they will damage the product. NEVER use alcohol or other solvents.

External cleaning of unit:

- Turn off and unplug the unit.
- Use a soft cloth slightly damp cloth to wipe the outer surfaces.
- Do not allow water to slip into the internal parts as this could damage the unit and result in electrical shock or injury.
- Allow the unit to dry thoroughly before use.

Cleaning the filter:

- Turn off and unplug the unit.
- Lift up the main upper body of the machine and place on a soft surface upside down.
- Remove the HEPA filter by turning the filter to the left using the tabs on the filter. The arrows on the filter body will indicate which way to turn to remove the filter.
- Run a vacuum cleaner with brush attachment on low power setting along the mesh pre-filter to pick up the dust and other particles.
- Reinsert the filter and turn the filter to the right to secure in place.
- Replace main upper body back onto the water tank. Ensure the unit is set properly on the water tank with the alignment arrows on the front of the unit aligned or the unit will not turn on.

TECHNICAL SPECIFICATIONS

Working environment	40-104°F
Rated voltage/frequency	100~240VAC / 50~60Hz
Rated power	32W±10%
Noise level	32-50dB
CADR	150CFM
Water tank capacity	1 gallon
Dimension	11.14x11.14x18.7in
Weight	8.38lbs

FREQUENTLY ASKED QUESTIONS

Why is the replace filter light on?	The replace filter light is set to automatically go off after 4,320 hours. It is only a reminder to check the filter to keep the air purifier/humidifier running smoothly. To reset the light, please hold down the replace filter button while the unit is on for 5 seconds.
How often should I change filters?	The filter replacement frequency varies greatly on environment. We recommend checking the filter to see when it turns grayish in color and there is a noticeable reduction in airflow. Vacuum or clean off any visible dust and hair on the filter monthly and replace filter when necessary.
My unit no longer powers on, what should I do?	First, please check another outlet to see if it is a problem with the outlet. Second, please make sure the main upper body of the unit is seated properly on the water tank and there is no debris or water on the contact sensor. The sensor is located on the back right side of the water tank. If it still does not work, please contact us for further assistance.
Cannot connect to the InvisiClean app	Make sure your phone is powered on and is not connected with other Bluetooth devices. Try connecting with another phone. Make sure your app is updated to the latest version. Make sure you connect to your Wi-Fi router's 2.4GHz network and that the network is working correctly. Make sure the Wi-Fi password you entered is correct. Shorten the distance between the air purifier/humidifier, Wi-Fi router, and the phone. Make sure your air purifier and the Wi-Fi router are located away from appliances that produce electromagnetic radiation (e.g. microwave ovens, refrigerators, etc.).
The air	Make sure the air purifier/humidifier is plugged in and

purifier/humidifier is offline in my app.	<p>powered on, then refresh "My Devices" in InvisiClean app by swiping down on the screen.</p> <p>Make sure your router is connected to the internet and your phone's network connection is working.</p> <p>If the Wi-Fi password has been changed, the air purifier will automatically go offline. Try connecting it to the network again.</p> <p>Delete the offline air purifier from InvisiClean app, then add and reconfigure the air purifier/humidifier again in the app.</p>
---	---

FCC NOTICE

The user manual shall include the following or similar statement, placed in a prominent location in the text of the manual:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty: 1 year from the date of purchase

Thank you for purchasing from InvisiClean.

InvisiClean warrants this product to be free of defects in materials or workmanship commencing upon the date of the original purchase. Save your original sales receipt to validate start of warranty period. Warranty is not valid without receipt. If this product should become defective within the warranty period, we will repair or replace any defective parts free of charge. All warranty repairs must be completed by InvisiClean. This warranty does not cover unauthorized repairs. The warranty does not include unusual wear, damage resulting from accident, or unreasonable use of the product. This warranty only covers the product when used with genuine InvisiClean accessories. This warranty covers product that was purchased from authorized distributors. This warranty gives you specific legal rights and you may also have other rights (other rights may vary from state to state in the U.S.A.). To submit product under warranty the complete machine must be delivered pre-paid to InvisiClean. Please include complete information including: the problem, the model number of the product, the day of purchase, and a copy of the original sales receipt along with your name, address, and telephone (email optional). Please contact the original authorized retailer for return authorization and instructions.

To satisfy FCC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.



**Need a reminder to change filters?
Subscribe and Save 20% on
Filters and get FREE SHIPPING**



**Go to: invisiclean.com/save
No commitments or hassles
and cancel online anytime.**