


USE & CARE INSTRUCTIONS



InvisiClean Nova Air Purifier

If you have any questions, please email us at support@invisiclean.com or call us at 818-787-1188 Monday – Friday 9AM-5PM Pacific time for immediate assistance.

READ AND SAVE THESE INSTRUCTIONS WARNINGS

**Failure to comply with the warnings listed below may
result in electric shock or serious injury.**




This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Read all instructions before using appliance.
- To avoid fire or shock hazard, plug the appliance directly into a right AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Please contact the manufacturer for assistance.

- Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- DO NOT use outdoors.
- DO NOT place anything on top of unit.
- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- WARNING: To reduce the risk of fire or electric shock, do not use this device with any solid-state speed control device.



QUICK START & FILTER INSTALLATION

BEFORE OPERATING THE AIR PURIFIER:

1. Carefully lift your air purifier from box and remove the plastic bags from unit.
2. To remove the filter, please switch the filter lock to the unlock position and lift the unit off the filter. Remove the plastic on the filter and replace the unit onto the filter and switch the filter lock to the locked position.
3. Select a firm level surface for the air purifier and plug the power cord into an AC outlet and turn on using the center power button,

*For proper air flow, locate the unit at least 1 foot from any wall or furniture.

*Make sure none of the grills are blocked.

TECHNICAL SPECIFICATIONS


Rated Voltage: 120V~,60Hz

Rated Power: 50W

Noise Level: From: 28dB(LOW) to 56dB(TURBO)

Dimensions: 10.8(L) x 10.9(W) x 21(H) inches

OPERATING THE AIR PURIFIER



“POWER” & “WIFI” BUTTON:

Short press this button to turn on the unit or off;

Press and hold for 3-5 seconds to activate or reset Wi-Fi connection. If the Wi-Fi connection is not made in 10 minutes, it will turn off automatically and not turn on again until you press and hold to activate the Wi-Fi again.



“TIMER” BUTTON:

Press this button to set the timer for 1-12 hours. Pressing this button while the timer is active will display the remaining hours. Pressing again will increase the timer. To reset, press until the timer is at 12 and press one more time.



“SPEED” BUTTON:

Press this button to cycle through the speed settings from I (Low), II (Medium) , III (High) , IV(Turbo), Auto.

Under AUTO mode, the unit will automatically change the speed according to the air quality detected by air sensor. The auto mode indicator will show up on the LCD screen when in this mode.

Air quality indication ring will show different colors according to the detect air quality:

Blue	Excellent
Yellow	Moderate
Orange	Unhealthy
Red	Dangerous



“CHILD LOCK” BUTTON:

Long press this button for 3 seconds to enter or exit the child lock mode. If any button is pressed when child lock is activated, the icon will flash 3 times to remind you if the locked status.



“SLEEP” BUTTON:

Press this button to turn on & off sleep mode. The sleep icon will flash for 5 seconds before the unit enters into sleep mode. Under sleep mode, all lights will turn off . Pressing any other buttons while sleep mode is active will turn off sleep mode.



“UV” BUTTON:

Press this button to turn on/off UV light. Press and hold for 3-5 seconds to reset the UV indicator light. We recommend replacing the UV bulb half yearly.



“IONIZER” BUTTON:

Press this button to turn on/off IONIZER function. The ionizer function helps filtration by combining particles together so they filtered out of the air more easily. The heavier particles will fall before reaching the filter which will create more dust on surrounding furniture and surfaces. If this is not desired, please turn the ionizer off.



“FILTER RESET” BUTTON

Short press this button to check the remaining life (%) of the filter.

After operating 4320 hours, the indicator will turn red. Please check the filter, clean and replace if necessary. After replacing the filter, press and hold this button 5 seconds to reset the indicator light and the filter timer will restart.

Important note: When the unit is not in use, please switch it off and unplug it.

SETTING UP WI-FI CONNECTION

Wi-Fi setup is not required and will turn off after 10 minutes if not used.

1. Make sure your phone is connected to your Wi-Fi network (Not your cellular data) while you add the device to your app.
2. Make sure the Wi-Fi icon on the air purifier display is blinking. If not, press and hold the power button while the unit is on for 5 seconds to activate the Wi-Fi connection.

Step 1

Search for and download the “InvisiClean” app in App Store or Play Store. Both IOS and Android versions are available. Create a new account or login if you already have an account.

Step 2

Make sure you are connected to your Wi-Fi and your Bluetooth is enabled. Tap the + sign and select “Add Device”. The app will scan and look for your air purifier. Tap the air purifier and you will be prompted for your Wi-Fi password. Enter the Wi-Fi password and the air purifier will be added.

Step 3

The device will now appear in the InvisiClean app and you will be able to control the air purifier from anywhere you have internet service. Please note the air purifier must also have access to a Wi-Fi connection. If your air purifier is moved to a new network or Wi-Fi settings are changed you will need to reconnect the air purifier by pressing and holding the power button while the unit is on for 5 seconds. The Wi-Fi icon will blink to show it is ready for a new connection.


INSTALLING & REMOVING FILTERS

FILTER REPLACE INDICATOR

The FILTER icon lighting up to indicates that it is time to replace the filter. Follow the instruction below to change filter and reset the program.

Remark:


- * Remember to tear off the plastic bag of the new filter before replacing it.
- * The filter will last approximately 6-12 months depending on air quality.




1. Find the lock on the base of unit and moving it to left to unlock it.
2. Lift up the air purifier from its base.
3. Change the old filter to new one, and set the unit back, move the lock to right
4. Press and hold filter button on control panel for 5 seconds to reset the filter life.

INSTALLING & REMOVING UV LAMP

We recommend changing the UV bulb half yearly for best performance. Follow the instructions below to change UV lamp and reset the indicator.





1. Find the lock at the base of unit and move it to left to unlock it.
2. Lift up the unit off the filter and turn upside down on a soft surface.
3. Loosen the screw holding the UV lamp housing. To prevent the screw from falling out, the screw is captured and will not come out of the housing. Rotate the UV lamp cover counter-clockwise to unlock the housing. Grab the base of the lamp and pull out straight. It is a 4 prong connector.
4. Attach the foam gasket to the end of the new bulb and insert it into the lamp holder. It will only fit in the correct orientation so if it does not align, turn 45 degrees and try again.
5. Align the tabs of the housing slightly to the left of the tabs on the unit and gently rotate the UV lamp housing clockwise to assemble. If it does not align, remove and try again, it requires very little force to turn. Align the housing with the screw hole, and tighten the screw.
6. Place the unit onto the filter and base and move the lock button on the base to the right. Plug in and turn on the unit.
7. Reset the UV light indicator by pressing and holding the UV button for 3-5 seconds while the unit is on.

CLEANING & MAINTAINING

The machine should be cleaned at least once every month by a clean, dry, soft cloth. More frequent cleaning may be required depending on environmental conditions.

NOTE:

Do NOT stick any foreign objects or your fingers inside of the unit.
Do NOT use gasoline, benzine, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the product.
NEVER use alcohol or other solvents.

TROUBLESHOOTING GUIDE

Before carrying out any of the following service checks, unplug the unit from power.

Insufficient air flow	Check that the filters are clean Check for any obstructions in the air inlet and outlet
Unit will not start	Check the power outlet and make sure it has power. Check breaker box to make sure it has not tripped. Check that the Bottom Cover is latched firmly in place. Check that the Filter is firmly in place.
Excessive noise	Check for any foreign objects in contact with the fan. The filter may be clogged and ready for replacement. Check if foam sealing gaskets on the filter have been installed correctly. Uneven positioning. Place on level surface.

FREQUENTLY ASKED QUESTIONS

Why is the replace filter light blinking?	The replace filter light is set to automatically go off after 4,320 hours. It is only a reminder to check the filter to keep the air purifier running smoothly. To reset the light, please hold down the power button while the unit is on for 5 seconds.
How often should I change filters?	The filter replacement frequency varies greatly on environment. We recommend checking the filter to see when it turns grayish in color. Vacuum or clean off any visible dust and hair on the filter monthly and replace filter when necessary.
What is the difference between our 2 filters	We offer two filters for this air purifier, the IC- NOVA-FILTER and the IC-NOVA-HEPA-C.

you offer?	The IC-NOVA-FILTER is our standard HEPA filter with a light amount activated carbon on the inside. The IC-NOVA-HEPA-C features a HEPA filter with an array of pelletized carbon. It has much more activated carbon content and is optimized for VOC gas and odor removal.
My unit no longer powers on, what should I do?	First, please check another outlet to see if it is a problem with the outlet. Second, please make sure the air purifier is seated properly, the filter is in place, and the filter lock is engaged. If it still does not work, please contact us for further assistance.
Cannot connect to InvisiClean app.	Make sure your phone is powered on and is not connected with other Bluetooth devices. Try connecting with another phone. Make sure your app is updated to the latest version. Make sure you connect to your Wi-Fi router's 2.4GHz network and that the network is working correctly. Make sure the Wi-Fi password you entered is correct. Shorten the distance between the air purifier, Wi-Fi router, and the phone. Make sure your air purifier and the Wi-Fi router are located away from appliances that produce electromagnetic radiation (e.g. microwave ovens, refrigerators, etc.).
The air purifier is offline.	Make sure the air purifier is plugged in and powered on, then refresh "My Devices" in InvisiClean app by swiping down on the screen. Make sure your router is connected to the internet and your phone's network connection is working. If the Wi-Fi password has been changed, the air purifier will automatically go offline. Try connecting it to the network again. Delete the offline air purifier from InvisiClean app, then add and reconfigure the air purifier again in the app.
When should I change the bulb?	The bulb should be changed yearly for optimum performance.
How do I tell if my UV lamp is working?	When the UV is on you should be able to see a blue glow from the UV bulb from the air outlet. It is easier to see in the dark. The unit is shielded from UV exposure and you are only seeing a reflection of the UV light. Please do not disable any safety features to look at the UV light and do not look at it directly for any length of time.

Warranty: 1 year from the date of purchase

InvisiClean warrants this product to be free of defects in materials or workmanship commencing upon the date of the original purchase. Save your original sales receipt to validate start of warranty period. Warranty is not valid without receipt. If this product should become defective within the warranty period, we will repair or replace any defective parts free of charge. All warranty repairs must be completed by InvisiClean. This warranty does not cover unauthorized repairs. The warranty does not include unusual wear, damage resulting from accident, or unreasonable use of the product. This warranty only covers the product when used with genuine InvisiClean accessories. This warranty covers product that was purchased from authorized distributors. This warranty gives you specific legal rights and you may also have other rights (other rights may vary from state to state in the U.S.A.). To submit product under warranty the complete machine must be delivered pre-paid to InvisiClean. Please include complete information including: the problem, the model number of the product, the day of purchase, and a copy of the original sales receipt along with your name, address, and telephone (email optional). Please contact the original authorized retailer for return authorization and instructions.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Air Purifier, the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter, End-Users must be provided with transmitter operation conditions for satisfying RF exposure compliance.