1 Product Introduction

1.1 overview

ZKBM01 is a highly integrated BLE Bluetooth transparent module with features such as small size, low power consumption, and ease of use, helping users develop Bluetooth applications at the lowest cost and fastest speed. After the module is started, it will automatically broadcast, and mobile devices can scan and connect it. After successful connection, users can communicate in both directions between the module and the mobile device.

1.2 Application scope

- Smart Home Related Products
- General LED lighting control for smart home related products, intelligent lighting such as Tmall Genie
- Logistics tracking, warehouse inspection, electronic labels, etc.
- Wireless data acquisition and control of industrial instruments and meters
- Wireless remote control and voice remote control for electronic consumer products
- Wireless alarm and security system

1.3 pinouts

Serial Number	name	types of	describe
1	BLAS		Retention function
2	MIC		Retention function

3	A_P	voice	speaker+
4	A_N	voice	speaker-
5	RST		Reset foot
6	GND	GND	Power-
7	VCC	VCC	Power+
8	VDDIO		
9	ALL		
10	ALO		
11	PD7	I/O	Retention function
12	PD6	1/0	Retention function
13	PD5	1/0	Retention function
14	PD4	I/O	Retention function
15	DIO	I/O	Burn-SDA
16	TCK	I/O	Burn-SCL
17	PC5	I/O	Retention function
18	PC3	I/O	Retention function
19	PC2	I/O	Retention function
20	PC1	I/O	Retention function
21	PC0	1/0	Retention function
22	PD3	I/O	Retention function
23	PD2	1/0	Retention function
24	PD1	1/0	Retention function
25	PD0	1/0	Retention function
26	PB4	1/0	Retention function
27	PB6	1/0	Retention function
28	PB7	1/0	Retention function
29	PB5	1/0	Retention function
30	PB1	1/0	Retention function
31	PB2	1/0	Retention function
32	PB3	1/0	Retention function
33	PA3/TX	1/0	Serial

34	PA2/RX	1/0	Serial
35	PA1	1/0	Retention function
36	PA0	1/0	Retention function
37	PA7	1/0	Retention function
38	PA6	1/0	Retention function
39	PA4	1/0	Retention function
40	PA5	1/0	Retention function

2 hardware design

2.1 power

The power supply voltage range of the module is between 1.8 and 4.3V, and cannot be outside this range. Exceeding this range may permanently damage the module. According to the application needs, the module can be powered separately or shared with the host device, but please choose a better power supply for the ripple system. If using a switching power supply, please pay attention to the interference of switching pulses on the module.

Note: Normal working voltage of the module is DC 3.3V

2.2 IO power

The module IO port has a TTL level of 3.3V. When connecting to the main control MCU, attention should be paid to level matching. The maximum input voltage that the module IO port can accept is 3.6V, which may damage the module. If the external MCU level is 5V, a transistor voltage conversion circuit or specialized voltage conversion chip can be used to convert it to a matching level and then connect it to the module IO port.

For IO ports that are not used by the module, please hover or use a 10K resistor to pull them down to GND.

3 use

3.1 UART

- 1. The module can be used to upgrade firmware using a PC burning tool and a serial port. The specific operations are as follows:
- 2. Open the PC serial port burning tool, select the correct serial port number, import the DAT file (select the updated bin file), and then open the serial port to enter the waiting connection state.
- 3. Connect the TX of the serial tool to the chip PA2 (RXD1 on the module side) and RX to the chip PA3 (TXD1 on the module side).

Attention: Because the TX of the serial port tool will be connected to the module end in series, the wiring connection sequence should follow the process described in steps 2 and 3 above, otherwise the module will not be successfully connected.

4 Contact Us

Zhongshan Zhikong Intelligent Technology Co., Ltd

地址:Part II, 3rd Building, No.8 Building, No.3 Jiuzhou Avenue, Huoju Development Zone, Zhongshan City

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2.2

This module has been assessed against the following FCC rule parts: CFR 47 FCC Part 15 C (15.247, DTS). It is applicable to the modular transmitter

2.3

This radio transmitter 2BBCH-ZKBM01 has been approved by Federal Communications Commission to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

The concrete contents to check are the following three points.

- 1) Must use a PCB antenna with gain not exceeding those shown in the table below.
- 2) Should be installed so that the end user cannot modify the antenna
- 3) Feed line should be designed in 50ohm

Fine-tuning of return loss etc. can be performed using a matching network.

The antenna shall not be accessible for modification or change by the end user

2.4

The module complies with FCC Part 15.247 and apply for Single module approval.

2.5

Trace antenna designs: Not applicable.

The device must be professionally installed

The intended use is generally not for the general public. It is generally for industry/commercial use.

The connector is within the transmitter enclosure and can only be accessed by disassembly of the transmitter which is not normally required. the user has no access to the connector.

Installation must be controlled. Installation requires special training

2.6

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

2.7 Antenna type and antenna gain:

Antenna	Frequency (MHz)	Antenna Type	MAX Antenna Gain (dBi)
1	2402-2480	PCB Antenna	0.09

2.8

Please notice that if the FCC identification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as "Contains FCC ID: 2BBCH-ZKBM01"; any similar wording that expresses the same meaning may be used.

2.9

Testing of the host product with all the transmitters installed – referred to as the composite investigation test- is recommended, to verify that the host product meets all the applicable FCC rules. The radio spectrum is to be investigated with all the transmitters in the final host product functioning to determine that no emissions exceed the highest limit permitted for any one individual transmitter as required by Section 2.947(f). The host manufacturer is responsible to ensure that when their product operates as intended it does not have any emissions present that are out of compliance that were not present when the transmitters were tested individually.

If the modular transmitter has been fully tested by the module grantee on the required number of channels, modulation types, and modes, it should not be necessary for the host installer to re-test all the available transmitter modes or settings. It is recommended that the host product manufacturer, installing the modular transmitter, perform some investigative measurements to confirm that the resulting composite system does not exceed the spurious emissions limits or band edge limits (e.g., where a different antenna may be causing additional emissions).

The testing should check for emissions that may occur due to the intermixing of emissions with the other transmitters, digital circuitry, or due to physical properties of the host product (enclosure). This investigation is especially important when integrating multiple modular transmitters where the certification is based on testing each of them in a stand-alone configuration.

2.10

Any company of the host device which installs this modular should perform the test of radiated & conducted emission and spurious emission etc. according to FCC Part 15C: 15.247 and 15.209 & 15.207, 15B class B requirement, only if the test result complies with FCC part 15C: 15.247 and 15.209 & 15.207, 15B class B requirement. Then the host can be sold legally.

The host product manufacturer is responsible for compliance with any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuity), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed. 2.11

The host manufacture is recommended to use D04 Module Integration Guide recommending as "best practice" RF design engineering testing and evaluation in case non-linear interactions generate additional non-compliant limits due to module placement to host components or properties.

2.12

This module is stand-alone modular. If the end product will involve the Multiple simultaneously transmitting condition or different operational conditions for a stand-alone modular transmitter in a host, host manufacturer have to consult with module manufacturer for the installation method in end system.

Canada Statement

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Please notice that if the ISED certification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains IC: 30341-ZKBM01" any similar wording that expresses the same meaning may be used.

l'appareil hôte doit porter une étiquette donnant le numéro de certification du module d'Industrie Canada, précédé des mots « Contient un module d'émission », du mot « IC: 30341-ZKBM01» ou d'une formulation similaire exprimant le même sens, comme suit

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 RF, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ouémetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

This radio transmitter 30341-ZKBM01 has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain

Le présent émetteur radio 30341-ZKBM01 a été approuvé par Innovation, Sciences et Développement économique Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué pour tout type figurant sur la liste, sont strictement interdits pour l'exploitation de l'émetteur.

The concrete contents to check are the following three points.

- 1) Must use a PCB antenna with gain not exceeding those shown in the table below.
- 2) Should be installed so that the end user cannot modify the antenna
- 3) Feed line should be designed in 50ohm

Fine tuning of return loss etc. can be performed using a matching network.

Le contenu concret à vérifier sont les trois points suivants.

- 1) doit utiliser une antenne PCB avec un gain ne dépassant pas ceux indiqués dans le tableau ci-dessous.
- 2) devrait être installé de sorte que l'utilisateur ne puisse pas modifier l'antenne
- 3) la ligne d'alimentation devrait être conçue dans 50ohm

Le réglage fin de la perte de retour, etc. peut être effectué en utilisant un réseau correspondant.

Antenna type and antenna gain:

Antenna	Frequency (MHz)	Antenna Type	MAX Antenna Gain (dBi)
1	2402-2480	PCB Antenna	0.09

Notice to OEM integrator

Must use the device only in host devices that meet the FCC/ISED RF exposure category of mobile, which means the device is installed and used at distances of at least 20cm from persons.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The end user manual shall include FCC Part 15 /ISED RSS GEN compliance statements related to the transmitter as show in this manual (FCC/Canada statement).

Host manufacturer is responsible for compliance of the host system with module installed with all other applicable requirements for the system such as Part 15 B, ICES 003.

Host manufacturer is strongly recommended to confirm compliance with FCC/ISED requirements for the transmitter when the module is installed in the host.

The use condition limitations extend to professional users, then instructions must state that this information also extends to the host manufacturer's instruction manual.

This module is stand-alone modular. If the end product will involve Multiple simultaneously transmitting condition or different operational conditions for a stand-alone modular transmitter in a host, host manufacturer has to consult with module manufacturer for the installation method in the end system.

Any company of the host device which install this modular should perform the test of radiated & condicted emission and spurious emission etc. according to FCC Part 15C: 15.247 and 15.209 & 15.207, 15B class B requirement, only if the test result comply with FCC part 15C: 15.247 and 15.209 & 15.207,15B class B requirement. Then the host can be sold legally. This modular transmitter is only FCC authorized for the specific rule parts (47CFR Part 15.247) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification.

Host manufacturer is strongly recommended to confirm compliance with FCC/ISED requirements for the transmitter when the module is installed in the host.

Must have on the host device a label showing Contains FCC ID: 2BBCH-ZKBM01 or IC: 30341-ZKBM01

Both FCC ID and IC ID are not to be placed on the host at the same time and only hosts going into the US can use the FCC ID and only hosts going into Canada can use the IC ID.

l'hôte doit utiliser l'instrument uniquement dans des dispositifs qui répondent à la fcc / (catégorie d'exposition rf mobile, ce qui signifie le dispositif est installé et utilisé à une distance d'au moins 20 cm de personnes.

le manuel de l'utilisateur final doit inclure la partie 15 / (fac rss gen déclarations de conformité relatives à l'émetteur que de montrer dans ce manuel.

le fabricant est responsable de la conformité de l'hôte, le système d'accueil avec le module installé avec toutes les autres exigences applicables du système comme la partie 15 b, ices - 003.

accueillir le fabricant est fortement recommandé de confirmer la conformité avec les exigences de la fcc / (émetteur lorsque le module est installé dans l'hôte.

le dispositif d'accueil doivent avoir une étiquette indiquant contient FCC ID: 2BBCH-ZKBM01, IC: 30341-ZKBM01

Doit avoir sur l'appareil hôte une étiquette indiquant Contient l'ID FCC : 2BBCH-ZKBM01 ou IC : 30341-ZKBM01 L'ID FCC et l'ID IC ne doivent pas être placés sur l'hôte en même temps et seuls les hôtes se rendant aux États-Unis peuvent utiliser l'ID FCC et seuls les hôtes se rendant au Canada peuvent utiliser l'ID IC.