

73mm

95mm

Portable Wireless Speaker Operation Manual

Model : IML324AAWT

Thank you for purchasing this Mini Wireless Speaker.
Please read all instructions carefully before using and
retain this manual for future use and reference.

Key Description

- ◀ Short press to previous song /long press to decrease volume
- ▶ Short press to next song /long press to increase volume
- ↔ left-on ,right-off
- 📞 Answer/ hang up/ pause / play
- M mode/
- TF card slot
- USB charging port

18.disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion

Safety and maintenance

1. Keep the device away from heat, direct sunlight and sharp edges
2. Do not insert any metal object into the device. As this is a risk of short circuit
3. To avoid static charge, do not use in a extremely dry climate
4. Do not repair the unit yourself. Contact an authorized specialist
5. Do not charge in the shower or other wet environments
6. Only charge when unit is dry
7. Do not submerge under water
8. Please charge the speaker in time when it reminds "battery low"
9. Please charge the speaker once every 20 days if it is not used for a long time.
10. Please place the speaker in a safe and dry environment if it is not use for a long time.
11. Please use the Micro USB charging cable that are delivered with this unit to connect with external devices.
12. If there is any abnormality of the speaker, please stop using it, such as: fever, smoke, odor, etc.
13. Please using 5v device to charge. Do not use the charging device more than 5v to charge to avoid damage of internal components.
14. To help prolong the speakers use life and your health, please don't listen to music in the long time, high volume environment, in order to avoid damage to your hearing.
15. This product is not a toy, Keep out of reach of children.
16. replacement of a battery with an incorrect type that can defeat a safeguard
17. Keep the device away from low extreme temperatures and low air pressure at high altitude
18. disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion

Specifications

Product name:	Wireless Speaker
Input:	5 V
Battery capacity:	400 mA
Charging time:	1.5-2 hours
Horn Power:	3 W
Output power:	3 W
version:	5.0
Running time:	2 hours
distance:	10 meters
Product weight:	115g
Product size:	70Lx70Wx55Hmm

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2.The colored light flashes slowly when play music under the mode of TF card.

wireless mode

1.Turn on key left dial to power on. Colored light on means wireless is on .

2.The colored light flashing means the speaker is already

into pairing mode. Click speaker name "PUSHEEN

SPEAKER" on bluetooth list of your phone to connect.

If successfully connected , the colored light will flashes

slowly . You will hear a beep sound when pairing is

successful. The paired device will automatically connect

with the speaker when you use it again.

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

5.When music playing, long press the ▲/▼ to increase or decrease the volume. Click the ▲/▼ button once to go to the previous song/next song. Click the answer📞button to answer/hang up/pause/play.

6.The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Instruction Sheet:



THIS IS A BATTERY-OPERATED PRODUCT. THIS IS NOT A TOY. INTENDED USE OF THE PRODUCT SHOULD NOT RESULT IN EXPOSURE TO THE BATTERY. In case of abuse, there is risk of rupture, fire, heat, leakage of internal components, which could cause causally. Abuse includes, but not limited to: charging for long time, short circuit, put into fire, washed with water, punctured with a sharp object, crushed, and broken.

Harmful if swallowed. Causes skin irritation. Causes eye irritation. May cause respiratory irritation.



Corrosive.

Avoid contact with eyes and skin. Severe burns or skin damage may result.

In case of rupture - Attention! Corrosive material.

Avoid contact with eyes, and skin. Ensure adequate ventilation. Use personal protective equipment as required. Keep equipment away from water. Refer to device's protective measures. Handle in accordance with good industrial hygiene and safety practices.

Stop the leak if safe to do so. Contain the spilled liquid with dry sand or earth. Clean up oils immediately if safe to do so. Absorb spilled materials with an absorbent material (dry sand or earth). Stop contamination absorption into acceptable waste container. Collect all contaminated absorbents and dispose of according to recycling standards in accordance with government, state and local regulations, to ensure proper disposal. Scrub the area with detergent and water, collect all contaminated water for proper disposal.



Items may burst and release hazardous decomposition products when exposed to a fire situation.

Lithium batteries contain flammable electrolyte that may ignite and produce sparks when subjected to high temperature, when damaged or abused (e.g. mechanical damage, electrical overcharging), may burn rapidly with flame/burn-off effect, may ignite other batteries in close proximity.

5. When fire extinguishing media:

Small fire: use water, spray, dry chemical, carbon dioxide, or chemical foam.

Large fire: water spray, fog, or foam.

6. After skin contact:

Remove contaminated clothes. Rinse skin with plenty of water or shower for 15 minutes. Get medical aid.

7. After eye contact:

Remove contact lenses. Rinse eye with plenty of water for 15 minutes. Get medical aid.

8. After swallowing:

Rinse mouth with water. Administer least 2 glasses of milk or water. Induce vomiting if patient is unconscious. Get medical aid.



反

正