


M I K O

IBUKI+ AIR PURIFIER S

User Manual

MA-04WBN



READ AND SAVE THESE INSTRUCTIONS AND WARNINGS

FAILURE TO COMPLY WITH THE WARNINGS LISTED BELOW MAY RESULT IN ELECTRIC SHOCK OR SERIOUS INJURY.



1. Read all instructions before using appliance.
2. Only use original supplied power adaptor.

This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.



ATTENTION!

- To avoid fire or shock hazard, plug the appliance directly into the right AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- The power plug must be connected in such a way as to avoid risks if the humidifier is tipped over or liquid is spilled.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.

- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Send to Customer Service for assistance.
- Use appliances only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to person.
- DO NOT use outdoors.
- DO NOT place anything on top of unit.
- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.

- **WARNING:** To reduce the risk of fire or electric shock, do not use this device with any solid-state speed control device.
- Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer.
- Before servicing or cleaning unit, switch power off at service panel and lock the service disconnecting means to prevent power from being switched on accidentally.

GET TO KNOW IBUKI+



PRIOR TO FIRST USE

1. Carefully lift your air purifier from box and remove the two packed plastic bags from unit and filter.
2. Select a firm, level and flat location for the air purifier.
3. Plug the power cord into a right voltage AC outlet.
4. For proper air flow, locate the unit at least 1 foot from any wall or furniture.
5. Make sure none of the grills are blocked.

HOW TO OPERATE IBUKI+

	POWER	Press to turn on/off device Long press (3s) to turn on WiFi pairing mode
	FAN SPEEDS	Low / Med / High
	AUTO	Ibuki+ monitors environment and maintains it to a perfect air quality
	TIMER	2hrs / 4hrs / 8hrs / Turn off.
	SLEEP	Long press (2s) to enter sleep mode. Press any button to wake up.
	CHILD LOCK	Press to lock/unlock the buttons
	WIFI	WIFI icon is on when device is connected with the app WIFI icon is blinking when it's in pairing mode
	FILTER RESET	Lights on when filter lifetime is up. After change filter, long press 3 secs to reset.

PAIR IBUKI+ WITH YOUR PHONE

Before Pairing

- Make sure your phone is connected to WIFI and bluetooth is on during pairing.
- Long press the power button for 3 seconds to turn on Ibuki+ 's WIFI. The WIFI icon blinks while WIFI is on and ready for connection.

1. Download "My Miko app" and register/log in your account.
2. Select "add device" and add Ibuki+ to your Miko app.
3. Follow the instructions on the app to pair with your phone.
4. Select Ibuki+ on app's device list. Now you can operate and schedule Ibuki+, and monitor qir quality on your phone anytime anywhere.

INSTALLING & REMOVING FILTERS

- The FILTER icon lighting up on red indicates that it is time to replace the filter. Follow the instruction below to change filter and reset the program.

Remark:

- Remember to tear off the packing bag of the new filter before replacing it.
- Combination Filter will last approximately 6 months.

1. Upside down the machine.
2. Flip the unit, then rotate and lift the base cover.
3. Change the used filter to new filter.
4. Reattach the base to the unit.
5. Reset the filter timer by filter reset button.

HOW TO CLEAN IBUKI+

- The machine should be cleaned at least once every month by a clean, dry, soft cloth.
- More frequent cleaning may be required depending on environmental conditions.

NOTE:

- Do NOT stick any foreign objects or your fingers inside of the unit.
- Do NOT use gasoline, benzine, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the product.
- NEVER use alcohol or other solvents.

TECHNICAL DATA

Model number: MA-04WBN

Product model: Miko IBUKI+ Air Purifier S

Power supply: DC24V/0.65A

Power consumption: 15.6W

Dimensions: 210*206*312 mm / 8.3*8.1*12.3 in

Weight: 2.0 kgs / 4.4 lbs

CORRECT DISPOSAL OF THIS PRODUCT



Please dispose of this product after its service life pursuant to the Waste Electrical and Electronic Equipment Directive 2012/19/EU- WEEE. The symbol on the product or its packaging indicates that this product cannot be treated as normal household waste but must be returned to a collection point for recycling electrical and electronic products.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter, End-Users must be provided with transmitter operation conditions for satisfying RF exposure compliance.



M I K O

For all comments, questions or complaints reach out to us:

hello@shopmiko.com

www.shopmiko.com

+1-866-201-9816

