

95mm

75mm

iGaur | 艾高尔




请使用淘宝扫码

星空无线音乐台灯


型号:YN-S3

产品使用说明书



非常感谢您选择我司产品,在使用产品前请认真阅读说明书!

01/产品外观




- 1.皮革提手带
- 2.音箱腔体
- 3.充电底座
- 4.氛围灯
- 5.氛围灯触摸板
- 6.USB输出口
7. Type-C输入口

02/包装清单

便携式充电×1 使用说明书×1 Type-C充电线×1 适配器×1(选配)


03/指示灯功能

插入Type-C充电线,充电时中间红灯常亮,充满电时红灯熄灭。



04/充电使用方法


当充电时,务必将Type-C线插入本产品才能使用。



05/按键功能

⑨ 开关机/播放/暂停/免提通话

长按5秒开机或关机,在播放状态下,短按一下暂停歌曲,再次短按播放歌曲。来电话时,短按接听电话,长按2秒拒接电话。



⑧ 蓝牙开关键

短按开启或关闭蓝牙。长按3秒任意一台音箱蓝牙键进入或关闭TWS对箱模式,可实现2个音箱互连,达到左、右立体声道环绕效果。

⊕ 音量加/下一首


在播放状态时,依次短按可增加音量,音量加到最大时发出“咚咚”的提示音,长按会播放下一首歌曲。

⊖ 音量减/上一首

在播放状态时,依次短按可降低音量,长按会播放上一首歌曲。

06/开启您的音箱并使用

1. 长按开关键 ⑨ 5秒开机,并且有提示声,蓝灯常亮。
2. 短按蓝牙键 ⑧ 打开蓝牙,中间蓝灯快闪,蓝牙搜索中。
3. 此时打开您手机的蓝牙功能,在蓝牙设备中,搜索蓝牙音箱出现[iGaur S3]字样。
4. 点击选中[iGaur S3]自动进入配对,配对连接成功后,会有提示音,蓝灯慢闪。




02/Packing List

charger×1 Instruction manual×1 Type-C×1 Adapter×1


03/Indicator Light Function

Insert the Type-C charging cable. When charging, the red light in the middle is steady on. When fully charged, the red light is off.



04/How To Use Charging

When charging wirelessly, be sure to plug the Type-C cable into this product to use it.



05/Key Function

⑨ Switch on/off/play/pause/hands-free call

Long press for 5 seconds to power on or off, in the playing state, short press to pause the song, short press again to play the song. When a call comes, short press to answer the call, long press for 2 seconds to reject the call.

⑧ Bluetooth Switch

Press to turn Bluetooth on or off. Long press the Bluetooth key of any speaker for seconds to enter or close the TWS box mode, which can realize the interconnection of two speakers and achieve the left and right stereo channel surround effect.

⊕ Volume up/next song


When the volume increases to the maximum, the "Dong Dong" tone will sound. Press and hold to play the next song.

⊖ Volume down/last song

When in play status, short press in sequence to lower the volume, long press will play the previous song.


06/How To Pair Your Speakers

1. Long press the on key for 5 seconds to start up, and there will be a prompt sound, and the blue light will be steady on.
2. Short press the Bluetooth to turn on. The blue light in the middle flashes quickly, the Bluetooth is searching in.
3. At this time, open your phone's Bluetooth function, in the Bluetooth device, search for Bluetooth speakers appear [Gaur S3] words.
4. Click on [Gaur S3] to automatically enter the pairing. After the pairing connection is successful, there will be a prompt tone and the blue light will flash slowly.




07/TWS对箱功能使用方法

1. 长按3秒任意一台音箱的蓝牙键⑧进入TWS对箱模式,等待5秒左右,2个音箱互连,连接成功后,主机蓝灯快闪,副机蓝灯慢闪,主机保持与手机蓝牙配对,连上蓝牙后,主副机蓝灯同时慢闪,实现左、右立体声道环绕效果。
2. 再次长按3秒任意一台音箱的蓝牙键⑧,以关闭TWS对箱模式,可单独播放音乐。



08/氛围灯使用方法

1. 触摸第一次,亮度为最高亮度的30%。
2. 触摸第二次,亮度为最高亮度的70%。
3. 触摸第三次,为最高亮度。
4. 触摸第四次,关闭灯光。
5. 长按3秒进入无极调光模式。



产品保修卡 Warranty Card

用户名称: _____ 购买时间: _____
User Name Ordering Time

联系电话: _____ 邮政编码: _____
Tel Number Postcode

产品型号: _____ 发票型号: _____
Product Model Invoice Type


联系地址: _____
Contact Address

经销单位(盖章生效)
Dealer (Stamp Company Seal Effect)

Sky Wireless Music Lamp


Model:YN-S3

Product Manuals



Thank you very much for choosing our products, please read the instructions carefully before using them!

01/Product Appearance




1. Leather handle strap
2. Sound box cavity
3. Charging base
4. Atmosphere lamp
5. atmosphere light touch board
6. USB input outlet
7. Type-C input port

02/Packing List

charger×1 Instruction manual×1 Type-C×1 Adapter×1


03/Indicator Light Function

Insert the Type-C charging cable. When charging, the red light in the middle is steady on. When fully charged, the red light is off.



04/How To Use Charging

When charging wirelessly, be sure to plug the Type-C cable into this product to use it.



05/Key Function

⑨ Switch on/off/play/pause/hands-free call

Long press for 5 seconds to power on or off, in the playing state, short press to pause the song, short press again to play the song. When a call comes, short press to answer the call, long press for 2 seconds to reject the call.

⑧ Bluetooth Switch

Press to turn Bluetooth on or off. Long press the Bluetooth key of any speaker for seconds to enter or close the TWS box mode, which can realize the interconnection of two speakers and achieve the left and right stereo channel surround effect.

⊕ Volume up/next song


When the volume increases to the maximum, the "Dong Dong" tone will sound. Press and hold to play the next song.

⊖ Volume down/last song

When in play status, short press in sequence to lower the volume, long press will play the previous song.


06/How To Pair Your Speakers

1. Long press the on key for 5 seconds to start up, and there will be a prompt sound, and the blue light will be steady on.
2. Short press the Bluetooth to turn on. The blue light in the middle flashes quickly, the Bluetooth is searching in.
3. At this time, open your phone's Bluetooth function, in the Bluetooth device, search for Bluetooth speakers appear [Gaur S3] words.
4. Click on [Gaur S3] to automatically enter the pairing. After the pairing connection is successful, there will be a prompt tone and the blue light will flash slowly.



07/How To Pair The TWS

1. Long press the Bluetooth key of any speaker for 3 seconds to enter the TWS box matching mode, wait for about 5 seconds, the two speakers interconnect, the host blue light flash quickly, the secondary blue light flash slowly, the host is paired with the mobile phone. Bluetooth, Bluetooth is connected, the main and secondary blue lights flash slowly at the same time, to achieve the left and right stereo channel surround effect.
2. Long press the Bluetooth key of any speaker again for 3 seconds to turn off the TWS box mode and play music separately.



08/Use Method Of Atmosphere Lamp

1. touch the first time, the brightness is 30% of the highest brightness,
2. touch the second time, the brightness is 70% of the highest brightness,
3. touch the third time, for the highest brightness,
4. touch the fourth time, turn off the light,
5. long press for 3 seconds to enter the stepless dimming mode,



09/产品参数

产品型号:YN-S3 USB有线输出:5V~2A
电源输入:9V=3A 12V=3A 光源功率:1W
音箱功率:20W
电池容量:7.4V, 2000mAh
(注:型号YN-S3A无内置锂电池)
执行标准:GB/T 13837-2012;GB 17625.1-2012;GB 8898-2011

10/注意事项

- 本产品需使用9V=3A或12V=3A以上的适配器。不能使用9V=2A及以下的适配器为产品充电,低功率输入会导致设备无法正常工作。
- 请务必使用产品配置的快充线或符合快速充电标准的Type-C线材。
- 请配套使用已获CCC认证并符合相关标准的电源适配器。
- 如果您想清洁本产品,请断开电源。
- 产品工作环境温度范围20~45°。
- 产品内置锂电池,不可更换,请勿丢弃或置于火中,以免引起危险。

09/Product Parameters

Product Model:YN-S3 Lamp power:1W
Power input:9V=3A 12V=3A USB wired output: 5V~2A
Speaker Power:20W
Battery capacity:7.4V, 2000mAh
(Note: Model YN-S3A has no built-in Li-battery)
Implementation standard: GB/T 13837-2012;GB 17625.1-2012;GB 8898-2011trrrt

10/Cautions

- This product requires an adapter with 9V=3A or 12V=3A or above. Do not use 9V 2A and below adapters to charge the product, low power input will cause the device to not work properly.
- Be sure to use the fast charging cable configured with the product or a Type-C cable that meets the fast charging standard.
- Please use a power adapter that has been certified by CCC and complies with the relevant standards.
- If you want to clean this product, please disconnect the power.
- The working temperature range of the product is 20~45°.
- Product built-in lithium battery, cannot be replaced, do not discard or put in the fire, so as not to cause danger.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.