TR-66

(TOPR-000046)

If you have questions about the TR–66 visit us online at

US

RGA Top Race US LLC
801 Barton Springs Road,
Austin, TX 78704
Email: support@dollardeal.zendesk.com

CA

RGA Ben LLC
801 Barton Springs Road,
Austin, TX 78704

DE FERNGESTEUERTER DROHNEN-CLIP-Warnung! Nicht für Kinder unter 36 Monaten geeignet. Verschluckungsgefahr. Sie sollten diese Packung zum späteren Nachschlagen aufbewahren.

FR CLIP POUR DRONE A DISTANCE- Attention! Ne convient pas aux enfants de moins de 36 mois. Risque d'étouffement. Nous vous recommandons de garder cet emballage afin de vous y référer à l'avenir.

ES CLIP DE DRONE REMOTO- ¡Advertencia! No adecuado para niños de menos de 36 meses. Peligro de asfixia. Le recomendamos guardar este embalaje para consultas futuras.

IT CLIP DRONE REMOTO- Avvertenza! Non adatto ai bambini di età inferiore a 36 mesi. Pericolo di soffocamento. Si consiglia di conservare questo imballaggio per una consultazione successiva.

NL Waarschuwing! Niet geschikt voor kinderen jonger dan 36 maanden.Verstikkingsgevaar. Wij raden u aan deze verpakking te bewaren voor toekomstig gebruik.

SV Varning! Ej lämplig för barn under 36 månader. Kvävningsrisk. Vi rekommenderar att du behåller denna förpackning för framtida referens.

PL Ostrzeżenie! Nie nadaje się dla dzieci poniżej 36 miesięcy. Ryzyko zadławienia. Zalecamy zachowanie tego opakowanie do wykorzystania w przyszłości.

DA Ikke egnet for born under 36 måneder - indeholder smådele.Gem vejledningen.

Tested according to international standards

⚠ WARNING:
CHOKING HAZARD - small parts. Not for children under 3 years.

EU
Razor Group Acquisition XIII GmbH,
Ritterstraße 16-18, 10969 Berlin.

MADE IN CHINA

1. INTRODUCTION:

Thank you for choosing the Top Race® TR-66 Drone Clip™ . The Drone Clip™can be attached to any larger sized drone capable of lifting at least 3 ounces or more. Please read this instruction manual carefully before using your device. Save these instructions for future reference.

IMPORTANT NOTES

The TR-66 Drone Clip™ should not be used as a toy. While it is small in size, it can still pose dangers to users and anyone in the vicinity. Always follow safety precautions while using your Drone Clip™ .
The TR-66 Manufacturer or dealers assume no liability for damages caused by parts, wear, improper use, or use in an unsafe manner. Always operate the Drone Clip™in a safe manner and safe environment, free of obstacles, and at a safe distance from others. Damage or dissatisfaction, due to accidents or modifications of the product, are not covered by the manufacturers warranty and will void all attempts to return or replace this product.

If you have any questions about this product please email us.
USA: support@dollardeal.zendesk.com

WARNING!!!

Users should operate the Drone Clip™ in safe areas away from other people. Never drop anything from the clip near or above people or pets.
Never drop anything metal, sharp, or too heavy at any time.
Users of this Drone Clip™ are responsible for any errors, poor performance, and any damage or injury that may occur while using this device.

2. DRONE CLIP AND ACCESORIES



3. BATTERY INSTALLATION



Remove the battery cover in back of the remote and install 3 button batteries in the transmitter (included), make sure to install them in the proper polarity as shown inside the battery compartment. Never mix old and new batteries.

4. CHARGING

The TR-66 came with a dedicated USB charging cable
1. Connect the USB Charging cable to a computer or USB outlet. Once connected the the light on the USB will turn red.
2. Connect the other end of the USB to the Clip battery. When connected the light will turn off.
3. Once the light turns on again the charging process is complete. Charge time is about 20 min.



Once the battery is fully charged simply connect and install the battery into the clip by removing the Drone Clip cover and putting it into place.
Note: Use caution when plugging the battery into the Drone Clip™. Do not force the connection and be sure to connect it the proper way.

Note: Only use the original Top Race charging cable that came in the box.

5. DRONE CLIP INSTALLATION



1. Use the included fastener strip and slide it into the Drone Clip™ . (see image)
2. Pull both ends of the fastener strip all the way around the drone until they meet on top and fasten it together as tight as possible. (see image)

Note: the fastener included is long enough to go around any large size drone. You can always cut off a piece if its too long to better fit the drone.

6. PAIRING THE CONTROLLER TO THE DEVICE

1. Turn on the switch of the transmitter. The light on the transmitter will flicker.
2. Turn on the switch of the Drone Clip. The lights will stop flickering and the controller will automatically pair up with the Drone Clip™and is now ready to use.

7. OPERATING THE DRONE CLIP

Press the button of the transmitter and the Drone Clip™ will open. You can now load your desired product into the clip. Press the button again and the clip will close, holding the product, loaded tightly in place and ready to take off.
We have included several accessories to start you off: Water Balloons, Parachute. You can use the clip for any other product as long it fits and is not too heavy. (Please read warning)
Note: A special lightweight plastic clip is included in the box to help you clip on products that wont fit directly to the Drone Clip™ .

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

8. HOW TO OPERATE THE PARACHUTE