

<div data-bbox="241 173 416 223" data-label="Section-Header"><h1>Manual</h1></div> <div data-bbox="218 262 439 732" data-label="Image"></div> <div data-bbox="214 791 442 833" data-label="Section-Header"><h2>App Cat Toy</h2></div>	<div data-bbox="631 156 802 176" data-label="Section-Header"><h3>Appearance Description</h3></div> <div data-bbox="631 228 1073 791" data-label="Image"></div> <div data-bbox="842 833 868 863" data-label="Text"><p>2</p></div>	<div data-bbox="1159 156 1331 176" data-label="Section-Header"><h3>Appearance Description</h3></div> <div data-bbox="1149 228 1612 732" data-label="Image"></div> <div data-bbox="1371 833 1397 863" data-label="Text"><p>3</p></div>	<div data-bbox="1685 156 1803 176" data-label="Section-Header"><h3>Appearance Size</h3></div> <div data-bbox="1721 220 2041 786" data-label="Image"></div> <div data-bbox="1899 833 1926 863" data-label="Text"><p>4</p></div>	<div data-bbox="2213 156 2395 176" data-label="Section-Header"><h3>Download and Install APP</h3></div> <div data-bbox="2213 206 2679 357" data-label="Image"></div> <div data-bbox="2213 399 2679 556" data-label="Image"></div> <div data-bbox="2223 606 2659 752" data-label="Text"><p>Register users and log in</p><ul style="list-style-type: none">• Open the App, if you do not have an account, click "Create a New account", the privacy policy page of the smart platform will be displayed, click "agree", and use your mobile phone number or email to register an account.• After registration, log in to the system. You can choose password log in or verification code log in.</div> <div data-bbox="2428 833 2454 863" data-label="Text"><p>5</p></div>	<div data-bbox="2742 156 2821 176" data-label="Section-Header"><h3>Add Device</h3></div> <div data-bbox="2742 193 3194 396" data-label="List-Group"><ul style="list-style-type: none">• Click "Add Device" or "+" on the top right of the App home page.• In the process of searching for a pair, please make sure that the Bluetooth of your phone is turned on. When connecting for the first time, click "Turn on Bluetooth", and then there will be a suggestion to Turn on Bluetooth. Click "Go to Set" and a prompt selection will appear. Click OK to enter the state of discovering devices..• After the device is discovered, click "Add" to enter the device to be installed mode. Click "+" until the device is added successfully. Then click "Done" to enter the operation page.</div> <div data-bbox="2742 416 2828 435" data-label="Section-Header"><h4>Friendly Tips:</h4></div> <div data-bbox="2742 453 3201 544" data-label="List-Group"><ol style="list-style-type: none">1. If the connection times out, please go back to the previous step and reconnect.2. In the case of not connecting APP, directly turn on the toy which can be used as a common cat toy for the cat to play with.</div> <div data-bbox="2957 833 2983 863" data-label="Text"><p>6</p></div>
<div data-bbox="102 907 237 925" data-label="Section-Header"><h3>Instruction For Use</h3></div> <div data-bbox="102 944 555 1055" data-label="Text"><p>1) Automatic mode: If you select automatic mode, the product can run by itself. The default automatic teasing duration is 1min, and the automatic teasing duration can be changed in the setting (only in automatic mode).</p><p>Note: When running automatic mode, if operate the direction control interface, it will automatically switch to manual mode.</p></div> <div data-bbox="165 1055 495 1609" data-label="Image"></div> <div data-bbox="313 1584 340 1614" data-label="Text"><p>7</p></div>	<div data-bbox="631 907 766 925" data-label="Section-Header"><h3>Instruction For Use</h3></div> <div data-bbox="631 944 1083 999" data-label="Text"><p>2) Manual mode: Select Manual Mode, which can be operated on the direction control interface .</p></div> <div data-bbox="637 1034 1077 1421" data-label="Image"></div> <div data-bbox="631 1429 1060 1520" data-label="Text"><p>Switch on and off:</p><p>Press the switch button for 3 seconds to turn on the device. Press the switch button again for 3 seconds to turn off the device (when the device be on state, the device can be turned off but cannot be turned on through the switch of the APP page) .</p></div> <div data-bbox="842 1584 868 1614" data-label="Text"><p>8</p></div>	<div data-bbox="1159 907 1295 925" data-label="Section-Header"><h3>Instruction For Use</h3></div> <div data-bbox="1176 944 1609 1018" data-label="Text"><p>3) In-situ rotation mode: Press the rotation button to rotate the toy in one direction, which can be manually closed or cancelled by operating the direction control interface.</p></div> <div data-bbox="1268 1034 1500 1538" data-label="Image"></div> <div data-bbox="1371 1584 1397 1614" data-label="Text"><p>9</p></div>	<div data-bbox="1685 907 1820 925" data-label="Section-Header"><h3>Instruction For Use</h3></div> <div data-bbox="1685 944 2124 1018" data-label="Text"><p>4) Light control: The default setting is on, and the light can be turned off manually. can choose the light mode in the setting, including steady flashing, normal flashing and random flashing.</p></div> <div data-bbox="1698 1088 2127 1513" data-label="Image"></div> <div data-bbox="1899 1584 1926 1614" data-label="Text"><p>10</p></div>	<div data-bbox="2213 907 2349 925" data-label="Section-Header"><h3>Instruction For Use</h3></div> <div data-bbox="2207 944 2679 1018" data-label="Text"><p>5) Looking for device: When the device can't be found, press this button to find the position of the device and it will beep for 3-4 seconds. (This function is only used when the device is powered on and connected to APP).</p></div> <div data-bbox="2329 1043 2560 1538" data-label="Image"></div> <div data-bbox="2428 1584 2454 1614" data-label="Text"><p>11</p></div>	<div data-bbox="2742 907 2867 925" data-label="Section-Header"><h3>Important Notes:</h3></div> <div data-bbox="2742 944 3201 1491" data-label="List-Group"><ul style="list-style-type: none">• Do not install the device in damp, dusty places where children can easily reach it.• Not children's toys, only for pets, preferably under the supervision of adults.• Do not disassemble the device at will. It is recommended to use smooth ground or common carpet. but it is not suitable for all carpets, such as use on a plush carpets may affect function.• Multiple products can be added to one APP account.• A device can only be controlled by one mobile phone. If want to use another mobile phone to operate, please remove the device from the connected mobile phone or hold down the reset button on the device before reconnecting the device and a sound will be emitted at the same time.• This device needs to be connected through Bluetooth, not WIFI version, this App needs to be connected to the Internet to work.• Please refer to the device in kind. the manual is for reference only.• The manual may contain technical inaccuracies, inconsistencies with device functions or typographical errors. Please refer to our final interpretation.</div> <div data-bbox="2957 1584 2983 1614" data-label="Text"><p>12</p></div>

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction