



S31

说明书

产品描述:

产品名称: S31
蓝牙版本: Bluetooth V5.4
耳机电池 (30mAh) 充电盒 (300mAh) 特殊可定制。
支持协议: A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP
持续通话/播放时长4小时左右

功能介绍:

1、开机: 充电盒中取出自动开机或在关机状态下长按触摸位 (触摸圆形) 处开机。
2、关机: 长按触摸位5秒蓝牙关机。
3、接听/挂断电话: 单击触摸位1下。
4、音量加: 双击右耳 MFB 键 加音量 音量减: 双击左耳 MFB 键 减音量
5、上一曲: 三击 MFB 键左边, 切换为上一曲
下一曲: 三击 MFB 键右边, 切换为下一曲
6、播放/暂停: 左/右 单击 MFB 键
7、激活语音助手: 在常规待机状态下, 长按右耳 2S 进入语音助手
8、游戏模式/音乐模式: 在常规待机状态下, 长按 右耳2S 听到嘟声识别音后松手
进入游戏模式。游戏模式长按右耳2S 听到嘟声识别音后松手进入音乐模式
9、低电量报警: 开机状态下, 电量低时每隔60秒发出一次提示音。
10、低电量关机: 开机状态下电量低时耳机将自动关机。
11、充电: 将耳机放入充电盒中即可充电。充电时耳机白灯常亮, 充满灯灭。充电仓
充电时充电仓白灯闪烁; 充满不闪, 常亮。
12、蓝牙配对: 手机连接: 首次配对蓝牙对耳时, 同时从充电盒中取出左、右耳机(关机
状态下双耳机长按3秒左右开机)左右耳指示灯闪烁, 自动左右配对, 配对成功后
一个耳机出现白灯闪烁。开启手机蓝牙, 搜索蓝牙设备, 选择“S31”耳机, 如
连接成功, 灯灭。

备注: 产品在不定时的升级更新, 部分功能操作会因手机的不同而有所改变, 请用户
以实际操作为准。

注意事项:

▲请在常温环境中存放以及使用本产品;
▲请勿将本产品暴露雨中或是潮湿环境中,
▲请勿丢弃, 避免因跌落造成产品损坏;
▲请勿自行拆解、修理和改造本产品;
▲请勿使用化学溶剂擦拭本产品;
▲请勿随意丢弃, 或至于高温(温度高于60度)与火中, 以免引起危险!
▲蓝牙产品均受环境和距离影响, 请勿靠近大电磁场干扰
和强磁的环境中使
▲若长时间不使用蓝牙耳机, 请充满电并隔一个星期充一次电, 延长蓝牙
耳机使用寿命。

合格证

型 号: S31

检验员: GC

08

已检验

S31

Manual

Product description:

Product name: S31
Bluetooth version: Bluetooth V5.4
Headphone battery (30mAh) and charging box (300mAh) can be customized.
Support protocol: A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP
About 4 hours of continuous talk/play

Features:

1. Turn on: Take it out of the charging box and turn it on automatically or press and hold the touch position (touch graphics) when it is turned off
2. Shut down: Long press the touch bit for 5 seconds to shut down the Bluetooth.
3. Answer/hang up the call: Click the touch position 1.
4. Volume increase: Double click the right ear MFB key to increase volume; Volume decrease: Double click the left ear MFB key to decrease volume
5. Previous song: Three clicks on the left side of the MFB key to switch to the previous song
Next song: Three clicks on the right side of the MFB key to switch to the next song
6. Play/Pause: Left/Right Click MFB Key
7. Activate voice assistant: In normal standby mode, long press the right ear for 2 seconds to enter the voice assistant
8. Game mode/Music mode: In normal standby mode, press and hold the right ear for 2 seconds to hear a beep recognition sound and release to enter game mode. Press and hold the right ear for 2 seconds to hear a beep recognition sound and release to enter music mode
9. Low battery alarm: When the battery is turned on, a beep will sound every 60 seconds when the battery is low.
10. Low battery shutdown: The headset will automatically shut down when the battery is low when it is turned on.
11. Charging: Put the headset into the charging box to charge. The white light of the headset is always on when charging, and the light is off when it is full. When the charging compartment is charging, the white light of the charging compartment will flicker; when it is full, it will not flicker and will be on.

12. Bluetooth pairing. Mobile phone connection: When pairing the Bluetooth pair ears for the first time, remove the left and right earphones from the charging box at the same time (when the two earphones are turned off press and hold for about 3 seconds to turn on) the left and right ear indicators flash, automatically pair left and right, and the pairing is successful The White light flashing.
Turn on the phone's Bluetooth, search for Bluetooth devices, and select the "S31" headset. If the connection is successful, the light is off

Remarks: The product is upgraded from time to time, and some functions and operations will be changed due to different mobile phones. Please refer to the actual operation.

Precautions:

▲Please store and use this product in a normal temperature environment;
▲Do not expose this product to rain or humid environment;
▲Do not throw to avoid product damage due to falling;
▲Do not disassemble, repair or modify this product by yourself;
▲Do not use chemical solvents to wipe this product;
▲Do not throw away randomly or as for high temperature (temperature higher than 60 degrees) and fire, so as not to cause danger!
▲Bluetooth products are affected by the environment and distance, please do not use it in an environment with large electromagnetic field interference and radiation.
▲If you do not use the Bluetooth headset for a long time, please charge it fully and charge it once a week to extend the life of the Bluetooth headset.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.