

# 1. ¿Qué hay en la caja?

1 1 1 1	1

# 2. Pantalla de reloj inteligente para niños

Lado delantero: Parte trasera:

Recuerde: No toque el micrófono ni la salida de aire con objetos afilados, como alfileres para quitar tarjetas.

# 3. Elegir la tarjeta SIM correcta

Paquete de datos: antes de usar el reloi, asegúrese

que la tarjeta SIM esté activa y pueda usar datos 2G/3G/4G.

Normal SIM Micro SIM Nano SIM

Operador: elección del operador que admita la red 2G/3G/4G. Lea atentamente antes de encender el reloj para evitar cualquier Tipo de tarjeta SIM: solo tarjeta Nano SIM. anomalía causada por una instalación incorrecta de la tarjeta.



2. Coloque la tarjeta SIM en la ranura para tarjetas, con el chip hacia arriba e insértela al reloj. Nota: Para una tarieta SIM nueva, no instale la tarieta SIM hasta que se

12. Función básica

y Google Play Store

5. Descargue la APLICACIÓN "Trackino"

Descarque la aplicación Trackino a través de los métodos siguientes

1. Escanee el código QR para descargar la APLICACIÓN

2. Descárguelo desde la tienda de aplicaciones de Apple

# 6. Registrese e inicie sesión con "Trackino"











Obtener código:

1. En la página "Vincular", toque "Código de vinculación" para ingresar y obtener el código de vinculación. 2. Escanee el código QR o ingrese el código de vinculación manualmente.

7. Escanee el código QR y vincule el reloj

2. Vava a la interfaz del código de registro, escanee el código QF

o conectarlo a WIFI. la interfaz del código QR generará

un código vinculante y luego se podrá vincular el reloj).

para vincular el reloj (después de insertar el reloj en la tarjeta SIM

\_\_\_ Introduzca su nombre

2 Vincular con éxito

Bed succeeduly

### 8. Cómo cambiar la correa

1 Inserte un objeto similar a un alfiler en el lado de la correa nara liherarla Esto quitará la correa existente del reloj (el pasador no se proporciona con el reloj, se puede usar cualquier pasador) 2. Tire del gancho e inserte la nueva correa en lugar de la correa antiqua existente. Utilice el mismo proceso en ambos lados .QR 3. En caso de que no haya un gancho en la correa, se proporciona una herramienta de tornillo que se puede usar para

presionar desde un lado para insertar la correa en el reloi.

## 9. Operación del botón de función

Botón de función Mantenga presionado para encender
(Si el reloj no puede encenderse, confirme si el reloj no iene energía) Presione brevemente para apagar/encender la pantalla SOS con un toque

Mantenga presionado durante 3 segundos para enviar una llamada de emergencia.
(Es necesario configurar la persona de contacto de emergencia en la APLICACIÓN). Recuerde: si el nuevo reloj no se puede encender, es probable que no tenga energía. Conecte el cable de carga hasta que el reloj muestre la interfaz de carga.

## 10. Operación básica

interfaz principal para acceder a la función Teléfono/Chat/Agregar

## 11. Cargando

Alinee los contactos de carga del reloi con los contactos metálicos del cable de carga hasta que aparezca el indicador de energía de carga en la pantalla del reloj.

4. Instalación de la tarjeta SIM





Chat

Haga clic en "Chat". En la página "Chat", mantenga
presionado "HOLD" para grabar voz y luego suéltelo presionado "HOLD" para grabar voz y luego suéltelo Haga clic en el mensaje no leído en la pantalla para reproducir el mensaje de voz.



Teléfono Haga clic en "Teléfono", seleccione el contacto para realizar una llamada telefónica: Si no puede realizar una llamada, verifique si el contacto está agregado en la APLICACIÓN.

# Video Ilamada

Settings

Haga clic en "Chat", en la página "Chat", seleccione el contacto y Seleccione el chat de vídeo. Ya que la videollamada de dos vías utilizará Datos, puedes nectar Wi-Fi para video llamadas; Recuerde: las video llamadas largas harán que el reloj se



Pasos Haga clic Haga clic en "Configuración", puede configurar la configuración del dispositivo,Luz de flash, alarma, cuenta atrás, brillo, sonido,Formato de tiempo, pasos diarios. retroiluminación, borrar caché y acerca de.



Haga clic en "Añadir amigos" e inserte la tarjeta Configuración de Wi-Fi SIM. En la página "Añadir amigos", busque amigos Después de vincular el reloj, abra "Más"

Haga clic en "pasos", podrá ver el número de

-Configuración-WLAN-Configurar WiFi. Posicionamiento

Encienda la aplicación, haga clic en "ubicación" para verificar el seguimiento y el posicionamiento del GPS.

# 13. Especificaciones

1. Encienda la aplicación e inicie sesión.

Especificaciones Tamaño 54,7x42,6x15,8mm Color Negro Pantalla IPS de 1,4 pulgadas, resolución de 240x240 Memoria ROM:128MB RAM:128MB Sensor Acelerómetro

7. Scan QR code and bind watch

2. Turn to registration code interface scan QR code to bind watch

1. On "Bind" page,tap "Bind code" to enter and obtain bind code.

2. Scan QR code or enter the bind code manually.

GPS/WiFi/LBS/A-GPS Posicionamiento Posicionamiento del acelerómetro Batería 680mAh Cámara 2MP RTOS Sistema Reloj inteligente para niños x1 Contenido Cable de carga x1 del paquete Manual de usuario x1 Selector de tarjeta SIM x1

# esenses® ( User Manual

Diseñado y ensamblado en China

www.esenses.co



### 1. What's in the box

Kids Charging Watch Cable 1 1 1 1 1







# 2. Kids smartwatch display

Remind: Do not poke the mic and air vent with sharp objects such as card

9. Function button operation

## 3. Choosing correct SIM card

para ingresar a Cámara

Operator: choosing operator who supports 2G/3G/4G network SIM card type: Nano SIM card only Data packet: Before you use watch, please make sure SIM card is active and able to use 2G/3G/4G data

0



10. Basic operation

interface to enter Camera



amigo/Pasos/Vincular/Más





### 4. SIM card installation Please read carefully before turn on watch to avoid any abnormal

1. Scan QR code to download APP caused by wrong card installation. 2. Download from Apple App store and Google Play Store





5. Download "Trackino" APP

Download Trackingo APP through followed methods:

12. Basic function

# 6. Register & Login with "Trackino'

Video call



Click "Chat" On "Chat" page. Select contact and

Remind: Long video calls will cause the watch to heat up. Please do not make video calls for a long time. Please do not wear the watch when the high temperature

alarm pops up. Wear the watch after the temperature drops to avoid high

data, you may connect Wi-Fi for video call:

select video chat.Since-two-way video call will use



Add friends Click "Add Frien















1. Turn on App and login.







Positioning GPS/WiFi/LBS/A-GPS



Enter your name Enter watch's name





## 13. Specifications Specifications

### Size 54.7x42.6x15.8mm Color Black/yellow/purple Display 1.4-inch IPS display,resolut Memory ROM:128MB Sensor Accelerometer

		20
	Contents	User Manual x1 SIM Card Picker x1
RAM:128MB	Package	Kids Smartwatch x1 Charging Cable x1
ution of 240x240	System	RTOS
	Camera	2MP
	Battery	680mAh
		Accelerometer positioning

# 说明书

Designed and assembled in China www.esenses.co

### 8. How to change strap 1.Insert a pin like object on ang side of the strap to release it.

This will remove the existing strap from the watch (pin not provided with watch, any pin can be used) 2.Pull the hook and insert the new strap in place of the existing old strap. Use the same process on both side .QR 3.In case there is no hook in the strap,a screw tool is provided that can be used to press the from one side to insert the strap into the watch.

- Function Button Long press to turn on (If watch can't turn on, please confirm whether watch is out of power) Short press to turn off/on screen

**®** 

 One-tap SOS
 Long press for 3s to send emergency call (Need to set emergency contact person in APP) that the watch is out of power.

Please plug in the charging cable until the watch shows he charging interface. Remind: If the new watch cannot be turned on, it is likely



### Please align charging contacts of the watch with metallic contacts on the charging cable until charging power indicator appears on

11. Charging

watch screen.

Note: For new SIM card, do not install the SIM card until activation is done.



Click "Phone", Select contact to make a phone call; if can't make a call, please check whether contact is added on APP.

### Click "Chat", On "Chat" page, press and hold "HOLD" to record voice, and then release to send voice. to record voice, and then release to send voice. Click the unread message on the screen to play voice

Click "Settings", You can set the Device Settings, FlashLight, Alarm, CountDown, Brightness, Sound, Time Format, Backlight, Clear cache, and About.

manually add friends.

Click "Add Friends" and insert the SIM card. On

the "Add Friends" page, search for friends and

Click "steps", you can view the number of daily

Turn on App, click "location" to check GPS track and positioning.

After binding watch, open"More"-Setting-WLAN-Set up WiFi.

### FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference,
- (2) this device must accept any interference received, including interference that may cause undesired operati

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of this Device KSW-90 (FCC ID: 2BBNN-KSW-90) has been tested against this SAR limit. SAR information on this can be viewed on-line at http://www.fcc.gov/oet/ea/fccid/. Please use the device FCC ID number for search. This device was tested for typical operations 0mm from the body. To maintain compliance with FCC RF exposure requirements, 0mm separation distance should. maintained to the user's bodies

### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.