


















USER MANUAL Wireless Carplay & Android Auto	Content English..... 1-11 Deutsch..... 12-22	English	Bluetooth Connection Tap on Settings-->Bluetooth to see the Bluetooth name of the device. On your smartphone enable Bluetooth, search the device Bluetooth name and connect it, smartphone will pop up "Bluetooth Pair", tap "Pair" to complete the pairing process.  	How to Use Wireless Carplay and Wired Carplay Tap Settings-->Smart Phone-->Apple Device-->set to CarPlay  	  
---	---	--------------------	---	--	---

◆Wireless CarPlay Connection Connect your iPhone Bluetooth to the device Bluetooth first, after that iPhone will pop up "Use CarPlay" when pairing for the first time. Please select pair to achieve wireless CarPlay connection. Wired CarPlay Connection Please connect the iPhone to the USB port of the device with a original iPhone USB cable. How to Use Wireless Android Auto/ Wired Android Auto Tap Settings-->Smart Phone-->Android Device-->Set to Android Auto 	  	◆Wireless Android Auto Connection Connect your smartphone Bluetooth to the device Bluetooth first, after that device will pop up android auto icon with your phone name, tap phone name to achieve wireless android auto connection. ◆Wired Android Auto Connection Please connect the smartphone to the USB port of the device by a original smartphone USB cable. Note: If your smartphone without "Android Auto" app, please download it from the google play and install it. How to Use Airplay Tap Settings-->Smart Phone-->Apple Device-->set to iOS Mirror. 	  	◆Wireless Connection Connect your iPhone to the WiFi of the device and turn on "Screen Mirroring" on your iPhone, tap the device name to start screen mirroring. ◆Wired Connection Connect your iPhone to the device with a usb cable, and allow the authorization request of the iPhone. How to Use Phonelink Tap Settings-->Smart Phone-->Android Device-->set to Auto Link Connect your android smartphone to the device by USB data cable, it will start android smartphone Mirroring. 	  
--	--	--	--	---	--

Note: Before using this function, please make sure that you have installed the "Auto Link" app on your android smartphone. (if not, please download "Auto Link" from google play store). How to Transfer the Sound to Car Speakers The device has built-in speaker, if you want louder sound, you can transfer it to your car's speakers. 1.By FM radio transmitter-set the device and your car radio to the same FM channel. (please avoid using the channel which have been occupied by the FM station). 2.By AUX cable-connect the audio port of the device and the original aux port of your car(if your car have) by a aux cable. 	Deutsch	Bluetooth-Verbindung Tippen Sie auf Einstellungen--> Bluetooth-einstellungen, um den Bluetooth-Namen des Geräts anzuzeigen. Aktivieren Sie Bluetooth auf Ihrem Smartphone, suchen Sie den Bluetooth-Namen des Geräts und verbinden Sie es. Das Smartphone zeigt "Bluetooth-Kopplung" an, tippen Sie auf "Koppeln", um den Kopplungsvorgang abzuschließen.  	Wie verwenden Sie Wireless Carplay und Wired Carplay? Klicken Einstellungen--> Mobilfunkverbindung--> Apple-Gerät--> auf CarPlay einstellen 	  	◆Wireless CarPlay Verbindung Verbinden Sie zuerst Ihr iPhone über Bluetooth mit dem Bluetooth-Gerät, danach erscheint beim ersten Pairing auf dem iPhone "Use CarPlay". Bitte wählen Sie Pairing aus, um eine drahtlose CarPlay-Verbindung herzustellen. ◆Wired CarPlay Verbindung Bitte verbinden Sie das iPhone mit einem original iPhone USB-Kabel mit dem USB-Anschluss des Geräts. Wie verwenden Sie Wireless Android Auto und Wired Android Auto? Klicken Einstellungen --> Mobilfunkverbindung --> Android-Gerät --> Auf Android-Gerät einstellen 
--	--------------------	---	---	--	--

  	◆Wireless Android Auto Verbindung Verbinden Sie zuerst Ihr Smartphone über Bluetooth mit dem Bluetooth-Gerät, nachdem das Gerät das Android-Auto-Symbol mit Ihrem Telefonnamen angezeigt hat, tippen Sie auf den Telefonnamen, um eine drahtlose Android-Auto-Verbindung herzustellen. ◆Wired Android Auto Verbindung Bitte verbinden Sie das Smartphone über ein Original-Smartphone-USB-Kabel mit dem USB-Anschluss des Geräts. Hinweis Wenn Ihr Smartphone keine "Android Auto"-App hat, laden Sie sie bitte von Google Play herunter und installieren Sie sie. Wie verwenden Sie Airplay? Klicken Einstellungen-->Mobilfunkverbindung-->Apple-Gerät-->auf iOS Mirror einstellen. 	  	◆Wireless Verbindung Verbinden Sie Ihr iPhone mit dem WLAN des Geräts und schalten Sie "Airplay" auf Ihrem iPhone, klicken Gerätenamen, um das Airplay zu starten. ◆Wired Verbindung Verbinden Sie Ihr iPhone mit einem USB-Kabel mit dem Gerät und lassen Sie die Autorisierungsanfrage des iPhones zu. Wie verwenden Sie Phonelink? Klicken Einstellungen-->Mobilfunkverbindung-->Android-Gerät-->auf Auto Link setzen Verbinden Sie Ihr Android-Smartphone über ein USB -Datenkabel mit dem Gerät, es startet die Android -Smartphone-Spiegelung. 	  	Hinweis Bevor Sie diese Funktion nutzen, vergewissern Sie sich bitte, dass Sie die "Auto Link"-App auf Ihrem Android -Smartphone installiert haben. (Wenn nicht, laden Sie bitte "Auto Link" aus dem Google Play Store herunter). Wie wird der Ton auf Autolautsprecher übertragen? Das Gerät verfügt über einen eingebauten Lautsprecher. Wenn Sie einen lauterer Ton wünschen, können Sie ihn auf die Lautsprecher Ihres Autos übertragen. 1.Per UKW-Radiosender: Stellen Sie das Gerät und Ihr Autoradio auf denselben UKW-Kanal ein. (Bitte vermeiden Sie es, den Kanal zu verwenden, der vom UKW-Sender belegt ist). 2.Per AUX-Kabel: Verbinden Sie den Audioanschluss des Geräts und den ursprünglichen Aux-Anschluss Ihres Autos (falls Ihr Auto vorhanden ist) über ein Aux-Kabel. 
---	--	--	---	--	---

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.