

成品尺寸：100X135mm，展开尺寸：400X135mm
材料要求：128g双铜，不过膜
印刷要求：双面四色印刷

USER MANUAL

APP Installation

1. For IOS system: search "JTTPRINTER" in app store and download it;For Andriod system search "JTPTINTER" in google play or Myapp and download it. Or scan the following QR code to download the APP.

2. Open the APP, click the "Library", and open all folders, then the files inside will be downloaded automatically. Then, the app is ready for the printing.

JTTPRINTER

Printer:

Status: Not Connect

Mode:

Battery:

Library

Animal

Plant

Person

Article

Scenery

IOS

Android

Operation Instruction

1. Remove the base cover

2. Slide off the front cover

3. Take off the clip from catridge

4. Slot the catridge into the printer

5. Put on the front cover

6. Power on the printer by sliding the power button to "ON"

7. Connect the Wifi named"jer-printer-XXXXXX" in the mobile phone wifi list,Initial password: 12345678. Voice prompt "WiFi connected" means successful connection.

8. Open the APP, In the "Edit" mode, click "NEW" for typing letters or doodling, or click "Open" for loading the photos from mobile phone album. After file is ready, click "yes", then "send to the printer" to transmit the content to printer. Voice prompt "Data reception completed,please press the key to print" means transmission is successful.

In the "Library", there are various files ready for printing. Remarks: In the "settings", AP and STA network modes are optional in network settings, and it is allowed to set printing resolution, ink type, print mode, voice volume, voice language and power save mode in printer settings. In "About", it is available to choose the APP language.

9. Click the button, and the indicator will change to flash in blue, then keep the roller of the printer touching the printing surface, and move the printer from left to right to print. Voice of "Print completed, press the key to repeat print" prompts that the printing is finished and press the button to print it again if necessary . The content will be replaced when receiving a new file from APP, or pressing the button for over 5 seconds to remove it .

10. After printing, power off the printer, remove the cartridge from the printer, and hold it with the cartridge clip.

Note

1. It is recommended to clean the printing nozzle with non-dust cloth or paper before re-working, so as to realize better printing performance.

2. When printing, keeping the roller of printer touching the printing surface, otherwise printing will fail.

3. If printing on a curve surface, it is recommended to touch the surface by the printer roller only, keep the nozzle of printer 2-5mm away from the surface.

4. After printing, please put the catridge back to the catridge holder.

5. If no any operation over 5 minutes, the printer will enter standby mode automatically. Press the printing button to wake it up.

Parameters

Product name: portable pinter

Model No: JT01

Dimension(L×W×H): 79×55×69 mm

Printing resolution: 300dpi

Printing range (W×L): 1x16 inches

Wifi: 802.11b/g/n

Net Weight: 185g

Input power: 5V 2A

Parts in the box

printer × 1pc

user manual × 1pc

USB cable × 1pc

catridge × 1pc

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

使用说明

一、APP下载

1. 苹果手机在APP里下载“JTTPRINTER”应用，安卓手机在 google play、应用宝内下载；或扫描对应二维码下载打印机 APP。

2. 安装后打开APP，点开图库，并点开图库每个文件夹，APP会自动下载图库内文件，下载完后即可以连接打印机使用。

JTTPRINTER

打印机:

状态: 未连接

模式:

电量:

Library

动物

植物

人物

动物

风景

IOS系统下载

安卓系统下载

二、打印机操作指南

1. 打开底盖。

2. 滑开前盖。

3. 打开墨盒保护夹。

4. 墨盒触点朝内压入打印机墨盒槽，直到“咔”声表示墨盒已装配到位。

5. 前盖沿着导槽推入，听到“咔”声表示前盖装配到位。

6. 滑动底部电源键至“ON”，此时能听到语音“开机，请打开手机Wi-Fi连接本机”。

7. 打开手机 Wi-Fi，找到“jer-printer-XXXXXX”网络名，并连接，默认密码为12345678，听到语音提示“Wi-Fi已连接”表示连接成功。

8. 打开APP，在编辑内选择“新建”可以输入文字或者涂鸦（可以选择单行或者多行输入模式），选择“打开”可以导入手机照片，“历史”选择已打印过的历史文件；输入或者选择好文件后，点击“确认”，文件进入画布，此时可以放大缩小以及移动旋转等动作，请注意文件不要超过手机屏幕显示范围。编辑完后再点击“确认”，选择“保存”或者“传输到打印机”去打印，听到“数据接收完成，请按键打印”语音提示，表示文件传输成功。

在“图库”可以选择预存的文件进行打印。

备注：“设置”选项下的“网络设置”，可以选择AP模式或则STA模式。“打印机设置”下可以设定打印机分辨率、墨水类型、打印模式、打印机语音提示音量、语音提示语言、进入省电模式的时间。

在“关于”选项里面可以选择APP语言。

9. 单击打印机按键，按键灯变为蓝色闪烁，此时让打印机底部滚轴接触打印介质，从左往右移动打印机即可进行打印，听到“打印完成，请按键重复打印”的语音后表示文件打印结束。如需重复打印，请再按一次按键。长按 5秒可以取消当前打印任务，或者发送新打印文件也可自动取消上一个打印任务并开始的打印任务。

10. 打印结束后，先把电源键滑至OFF关机，从上往下推开前盖，从右往左拨开卡键，墨盒会自动弹出，此时可以取出墨盒，并按图示方法放入墨盒夹。

三、提示：

1. 如果隔了一段时间使用，建议打印前先用无尘纸巾清洁一下喷头或者先试打印一次，然后再进行正式打印，这样可以获得更好的打印效果；

2. 打印时打印机滚轴必须要接触到打印介质并且打印机必须从左往右移动，否则无法打印；

3. 在曲面介质包括人体皮肤上打印时，建议只是滚轴接触介质，打印机其他底部不要接触介质，以便获得更好的打印效果，请注意喷头距离打印介质2-5mm为最佳打印效果；

4. 打印结束后，建议取下墨盒并放入保护夹，以防长期使用导致喷头堵塞或漏墨；

5. 打印机默认 5分钟无操作会自动进入省电模式，如需退出省电模式，请按打印机按键。

四、主要参数：

品名: 手持打印机

型号: JT01

尺寸 (Lx W xH) : 79×55×69 mm

打印精度 : 300dpi

打印范围 (W x L) : 1×16 英寸

Wifi : 802.11b/g/n

电源 : 5V 2A

净重 : 185g

五、包装清单：

打印机一台

说明书一本

USB线一根

墨盒一个