


**XG22**

Wireless smart headphones



**operating instructions**

Please read the instruction manual in advance to facilitate subsequent use


**Product Parameter**

Product Name	XG22
Bluetooth Version	5.4
Transmission Distance	≥10M
Speaker Diameter	Φ13mm
Charging Port	Type-C
Sensitivity	128±3dB
Charging Case Battery	3.7V
Headphone Battery	3.7V
Charge Time (Charging Case)	1.5-2H
Charge Time (Headphones)	0.8H
Playback time (headphones)	6H
Standby time (headphones)	30H (No connection)

**包装清单**

Wireless Headphones	*2
Carrying Case	*1
Instruction manual	*1
charging cable	*1

**Products**



① Touch Zone ② Indicator Light ③ Airflow Orifice  
 ④ Charging Contacts ⑤ Sound Hole ⑥ Digital display  
 ⑦ Type-charging Port

**Basic Operation**

**1. Switch on/off**

1. Switch on the computer  
 1. Remove the headset from the charging compartment and turn it on automatically. 2. Long press the headset touch button for 3S (Headset tone: TONE tone; Indicator light: White and green lights flash alternately )

2. Switch off  
 1. It will be put into the charging compartment to automatically switch off charging. 2. Long press the headset touch button for 5S. (Headset tone: TONE tone; Indicator light: white light on 3 off)


**2. Headphone Wearing**



1. Remove the headset  
 2. Wear your headphones in the right direction  
 3. Finish wearing


● The above wearing styles are only recommendations and can be worn comfortably according to your own habits.  
 ● Once worn, it can be used in accordance with subsequent operations

**Bluetooth Pairing**



Open the headphones compartment and remove the headphones inside  
 With the headset switched on  
 Turn on your mobile phone's Bluetooth setup and search for the device name: xg22  
 Click on the Bluetooth name, when it shows Connected, the connection is successful.

**3. Mode Selection**



Telephone Mode  
 Reject call: Long press 2s  
 Incoming call: Click to answer, then click to hang up

Music Mode  
 Double-touch in the left ear:  
 Play the previous song.  
 Right ear double touch:  
 Play next song.  
 Single touch: Play/Pause

In-ear mode  
 Three touches on the left ear: Volume down  
 Three touches on the right ear: Volume up

**In-ear mode**  
 Switch on: Long press 3S  
 Switch off: Long press 5S  
 Wake up Siri: Long press right ear 2s

**Caveat**

**Draw Attention To Sth.**

1. Please read this instruction manual carefully before using the product and keep it in a safe place.  
 2. Please fully charge the product for the first time use.  
 3. If the product is not used for a long time (more than 1 month), please charge it.;  
 4. If your mobile phone can not search for the Bluetooth headset, please make sure the Bluetooth headset is in the 'pairing state'. If there is no pairing or connection for a long time, the Bluetooth headset pairing function will be turned off, please turn on the Bluetooth headset again to the 'pairing state'. If the mobile phone program error, please restart the mobile phone. If the Bluetooth headset is not connected, please restart the mobile phone. If there is an error in the mobile phone programme, please restart the mobile phone; if there is an error in the Bluetooth headset programme, please restart the Bluetooth headset.

**Warnings**

1. Do not dismantle or modify the headset for any reason, as this may result in fire, breakdown of electronic components or even complete damage to the product.  
 2. Do not expose the device to temperatures that are too low or too high (below 0°C or above 45°C).  
 3. Avoid using the light near the eyes of children or animals.  
 4. do not use the device in thunderstorms, which may cause the device to operate improperly and increase the risk of electric shock.  
 5. Do not wipe the product with oil or other volatile liquids.  
 6. Do not wet the device with liquids.

**Warranty Description**

Dear customer, hello!  
 I am grateful for your patronage of our products, in order to ensure that your interests, please read the instructions and the following content carefully after you buy this product: (The following circumstances do not belong to the scope of the warranty, the company can provide paid services, please note)  
 1, not in accordance with the instructions for operation, use, storage, resulting in this product failure and damage.  
 2, unauthorised graffiti, tearing the product packaging and barcode.  
 3, unauthorised changes to the factory settings and dismantle the machine for repair.  
 4, accidental factors or human-induced damage to the product, such as the input of unqualified voltage, high temperature, water, damage, serious oxidation or rust of the product.  
 5, due to irresistible, such as earthquakes, fires, floods, lightning strikes and other causes of failure and damage.

**FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 -Reorient or relocate the receiving antenna.  
 -Increase the separation between the equipment and receiver.  
 -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 -Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC Radiation Exposure Statement**

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device can be used in portable exposure condition without restriction.