








802.11a / 6535 MHz / Chain A




802.11a / 6535 MHz / Chain B




802.11a / 6695 MHz / Chain A




802.11a / 6695 MHz / Chain B





802.11a / 6855 MHz / Chain A




802.11a / 6855 MHz / Chain B







802.11a / 6895 MHz / Chain A




802.11a / 6895 MHz / Chain B



802.11a / 7015 MHz / Chain A




802.11a / 7015 MHz / Chain B




802.11a / 7115 MHz / Chain A


802.11a / 7115 MHz / Chain B




802.11ax-20 MHz / 5955 MHz / Chain A




802.11ax-20 MHz / 5955 MHz / Chain B




802.11ax-20 MHz / 6175 MHz / Chain A




802.11ax-20 MHz / 6175 MHz / Chain B




802.11ax-20 MHz / 6415 MHz / Chain A




802.11ax-20 MHz / 6415 MHz / Chain B




802.11ax-20 MHz / 6435 MHz / Chain A




802.11ax-20 MHz / 6435 MHz / Chain B




802.11ax-20 MHz / 6475 MHz / Chain A





802.11ax-20 MHz / 6475 MHz / Chain B



802.11ax-20 MHz / 6515 MHz / Chain A





802.11ax-20 MHz / 6515 MHz / Chain B





802.11ax-20 MHz / 6535 MHz / Chain A

802.11ax-20 MHz / 6535 MHz / Chain B





802.11ax-20 MHz / 6695 MHz / Chain A

802.11ax-20 MHz / 6695 MHz / Chain B





802.11ax-20 MHz / 6855 MHz / Chain A

802.11ax-20 MHz / 6855 MHz / Chain B





802.11ax-20 MHz / 6895 MHz / Chain A

802.11ax-20 MHz / 6895 MHz / Chain B



802.11ax-20 MHz / 7015 MHz / Chain A

802.11ax-20 MHz / 7015 MHz / Chain B



802.11ax-20 MHz / 7115 MHz / Chain A

802.11ax-20 MHz / 7115 MHz / Chain B