






WPS指示灯	WPS连接指示灯
重置/WPS按键	<p>长按复位键7秒，指示灯全灭            机器恢复出厂状态</p> <p>短按复位键2秒，WPS指示灯快闪            与上级路由器匹配成功指示灯长亮</p>

\_\_\_\_\_



WPS LED	WPS connection indicator
Reset/ WPS Button	Press and hold for 7 seconds, and all the indicator lights are off. The machine returns to the factory state. Short press for 2 seconds, WPS indicator flashes; After the connection with the superior router is successful, the indicator is on

\_\_\_\_\_



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.