







NTNV-11AX40MIMO-Ant1-7085-PASS




NTNV-11AX40MIMO-Ant2-7085-PASS




NTNV-11AX40MIMO-Ant3-7085-PASS




NTNV-11AX40MIMO-Ant4-7085-PASS




NTNV-11AX80SISO-Ant1-5985-PASS




NTNV-11AX80SISO-Ant2-5985-PASS




NTNV-11AX80SISO-Ant3-5985-PASS




NTNV-11AX80SISO-Ant4-5985-PASS




NTNV-11AX80SISO-Ant1-6145-PASS




NTNV-11AX80SISO-Ant2-6145-PASS




NTNV-11AX80SISO-Ant3-6145-PASS




NTNV-11AX80SISO-Ant4-6145-PASS




NTNV-11AX80SISO-Ant1-6385-PASS




NTNV-11AX80SISO-Ant2-6385-PASS




NTNV-11AX80SISO-Ant3-6385-PASS




NTNV-11AX80SISO-Ant4-6385-PASS




NTNV-11AX80SISO-Ant1-6465-PASS




NTNV-11AX80SISO-Ant2-6465-PASS




NTNV-11AX80SISO-Ant3-6465-PASS




NTNV-11AX80SISO-Ant4-6465-PASS




NTNV-11AX80SISO-Ant1-6545-PASS




NTNV-11AX80SISO-Ant2-6545-PASS




NTNV-11AX80SISO-Ant3-6545-PASS




NTNV-11AX80SISO-Ant4-6545-PASS




NTNV-11AX80SISO-Ant1-6625-PASS




NTNV-11AX80SISO-Ant2-6625-PASS




NTNV-11AX80SISO-Ant3-6625-PASS



NTNV-11AX80SISO-Ant4-6625-PASS




NTNV-11AX80SISO-Ant1-6705-PASS




NTNV-11AX80SISO-Ant2-6705-PASS







NTNV-11AX80SISO-Ant3-6705-PASS




NTNV-11AX80SISO-Ant4-6705-PASS




NTNV-11AX80SISO-Ant1-6785-PASS




NTNV-11AX80SISO-Ant2-6785-PASS




NTNV-11AX80SISO-Ant3-6785-PASS




NTNV-11AX80SISO-Ant4-6785-PASS




NTNV-11AX80SISO-Ant1-6865-PASS




NTNV-11AX80SISO-Ant2-6865-PASS




NTNV-11AX80SISO-Ant3-6865-PASS




NTNV-11AX80SISO-Ant4-6865-PASS




NTNV-11AX80SISO-Ant1-6945-PASS




NTNV-11AX80SISO-Ant2-6945-PASS




NTNV-11AX80SISO-Ant3-6945-PASS




NTNV-11AX80SISO-Ant4-6945-PASS




NTNV-11AX80SISO-Ant1-7025-PASS



NTNV-11AX80SISO-Ant2-7025-PASS




NTNV-11AX80SISO-Ant3-7025-PASS




NTNV-11AX80SISO-Ant4-7025-PASS







NTNV-11AX80MIMO-Ant1-5985-PASS




NTNV-11AX80MIMO-Ant2-5985-PASS




NTNV-11AX80MIMO-Ant3-5985-PASS



NTNV-11AX80MIMO-Ant4-5985-PASS



NTNV-11AX80MIMO-Ant1-6145-PASS



NTNV-11AX80MIMO-Ant2-6145-PASS