














11AX40SISO-Ant1-6965-30~3000-PASS




11AX40SISO-Ant1-6965-3000~10000-PASS




11AX40SISO-Ant1-6965-10000~40000-PASS




11AX40SISO-Ant2-6965-30~3000-PASS




11AX40SISO-Ant2-6965-3000~10000-PASS




11AX40SISO-Ant2-6965-10000~40000-PASS




11AX40SISO-Ant3-6965-30~3000-PASS




11AX40SISO-Ant3-6965-3000~10000-PASS




11AX40SISO-Ant3-6965-10000~40000-PASS




11AX40SISO-Ant4-6965-30~3000-PASS




11AX40SISO-Ant4-6965-3000~10000-PASS




11AX40SISO-Ant4-6965-10000~40000-PASS




11AX40SISO-Ant1-7085-30~3000-PASS




11AX40SISO-Ant1-7085-3000~10000-PASS




11AX40SISO-Ant1-7085-10000~40000-PASS




11AX40SISO-Ant2-7085-30~3000-PASS




11AX40SISO-Ant2-7085-3000~10000-PASS




11AX40SISO-Ant2-7085-10000~40000-PASS




11AX40SISO-Ant3-7085-30~3000-PASS




11AX40SISO-Ant3-7085-3000~10000-PASS




11AX40SISO-Ant3-7085-10000~40000-PASS




11AX40SISO-Ant4-7085-30~3000-PASS




11AX40SISO-Ant4-7085-3000~10000-PASS




11AX40SISO-Ant4-7085-10000~40000-PASS




11AX40MIMO-Ant1-5965-30~3000-PASS




11AX40MIMO-Ant1-5965-3000~10000-PASS




11AX40MIMO-Ant1-5965-10000~40000-PASS



11AX40MIMO-Ant2-5965-30~3000-PASS




11AX40MIMO-Ant2-5965-3000~10000-PASS




11AX40MIMO-Ant2-5965-10000~40000-PASS




11AX40MIMO-Ant3-5965-30~3000-PASS




11AX40MIMO-Ant3-5965-3000~10000-PASS




11AX40MIMO-Ant3-5965-10000~40000-PASS




11AX40MIMO-Ant4-5965-30~3000-PASS




11AX40MIMO-Ant4-5965-3000~10000-PASS




11AX40MIMO-Ant4-5965-10000~40000-PASS




11AX40MIMO-Ant1-6165-30-3000-PASS



11AX40MIMO-Ant1-6165-3000-10000-PASS




11AX40MIMO-Ant1-6165-10000-40000-PASS



11AX40MIMO-Ant2-6165-30-3000-PASS



11AX40MIMO-Ant2-6165-3000-10000-PASS



11AX40MIMO-Ant2-6165-10000-40000-PASS