












11AX40MIMO-Ant1-6925-30~3000-PASS




11AX40MIMO-Ant1-6925-3000~10000-PASS




11AX40MIMO-Ant1-6925-10000~40000-PASS




11AX40MIMO-Ant2-6925-30~3000-PASS




11AX40MIMO-Ant2-6925-3000~10000-PASS




11AX40MIMO-Ant2-6925-10000~40000-PASS




11AX40MIMO-Ant3-6925-30~3000-PASS



11AX40MIMO-Ant3-6925-3000~10000-PASS




11AX40MIMO-Ant3-6925-10000~40000-PASS



11AX40MIMO-Ant4-6925-30~3000-PASS




11AX40MIMO-Ant4-6925-3000~10000-PASS




11AX40MIMO-Ant4-6925-10000~40000-PASS




11AX40MIMO-Ant1-6965-30~3000-PASS




11AX40MIMO-Ant1-6965-3000~10000-PASS




11AX40MIMO-Ant1-6965-10000~40000-PASS



11AX40MIMO-Ant2-6965-30~3000-PASS




11AX40MIMO-Ant2-6965-3000~10000-PASS



11AX40MIMO-Ant2-6965-10000~40000-PASS




11AX40MIMO-Ant3-6965-30~3000-PASS




11AX40MIMO-Ant3-6965-3000~10000-PASS




11AX40MIMO-Ant3-6965-10000~40000-PASS



11AX40MIMO-Ant4-6965-30~3000-PASS




11AX40MIMO-Ant4-6965-3000~10000-PASS




11AX40MIMO-Ant4-6965-10000~40000-PASS




11AX40MIMO-Ant1-7085-30~3000-PASS




11AX40MIMO-Ant1-7085-3000~10000-PASS




11AX40MIMO-Ant1-7085-10000~40000-PASS




11AX40MIMO-Ant2-7085-30~3000-PASS




11AX40MIMO-Ant2-7085-3000~10000-PASS




11AX40MIMO-Ant2-7085-10000~40000-PASS




11AX40MIMO-Ant3-7085-30~3000-PASS




11AX40MIMO-Ant3-7085-3000~10000-PASS




11AX40MIMO-Ant3-7085-10000~40000-PASS



11AX40MIMO-Ant4-7085-30~3000-PASS




11AX40MIMO-Ant4-7085-3000~10000-PASS




11AX40MIMO-Ant4-7085-10000~40000-PASS




11AX80SISO-Ant1-5985-30~3000-PASS




11AX80SISO-Ant1-5985-3000~10000-PASS




11AX80SISO-Ant1-5985-10000~40000-PASS



11AX80SISO-Ant2-5985-30~3000-PASS



11AX80SISO-Ant2-5985-3000~10000-PASS



11AX80SISO-Ant2-5985-10000~40000-PASS