






11AX80SISO-Ant3-6865-30~3000-PASS




11AX80SISO-Ant3-6865-3000~10000-PASS




11AX80SISO-Ant3-6865-10000~40000-PASS



11AX80SISO-Ant4-6865-30~3000-PASS




11AX80SISO-Ant4-6865-3000~10000-PASS




11AX80SISO-Ant4-6865-10000~40000-PASS




11AX80SISO-Ant1-6945-30~3000-PASS




11AX80SISO-Ant1-6945-3000~10000-PASS




11AX80SISO-Ant1-6945-10000~40000-PASS









11AX80SISO-Ant2-6945-30~3000-PASS









11AX80SISO-Ant2-6945-3000~10000-PASS




11AX80SISO-Ant2-6945-10000~40000-PASS









11AX80SISO-Ant3-7025-30~3000-PASS




11AX80SISO-Ant3-7025-3000~10000-PASS




11AX80SISO-Ant3-7025-10000~40000-PASS



11AX80SISO-Ant4-7025-30~3000-PASS



11AX80SISO-Ant4-7025-3000~10000-PASS




11AX80SISO-Ant4-7025-10000~40000-PASS







11AX80MIMO-Ant1-5985-30~3000-PASS




11AX80MIMO-Ant1-5985-3000~10000-PASS




11AX80MIMO-Ant1-5985-10000~40000-PASS



11AX80MIMO-Ant2-5985-30~3000-PASS




11AX80MIMO-Ant2-5985-3000~10000-PASS




11AX80MIMO-Ant2-5985-10000~40000-PASS




11AX80MIMO-Ant3-5985-30~3000-PASS




11AX80MIMO-Ant3-5985-3000~10000-PASS




11AX80MIMO-Ant3-5985-10000~40000-PASS




11AX80MIMO-Ant4-5985-30~3000-PASS




11AX80MIMO-Ant4-5985-3000~10000-PASS




11AX80MIMO-Ant4-5985-10000~40000-PASS




11AX80MIMO-Ant1-6145-30~3000-PASS



11AX80MIMO-Ant1-6145-3000~10000-PASS




11AX80MIMO-Ant1-6145-10000~40000-PASS



11AX80MIMO-Ant2-6145-30~3000-PASS



11AX80MIMO-Ant2-6145-3000~10000-PASS



11AX80MIMO-Ant2-6145-10000~40000-PASS