






11AX80MIMO-Ant3-6945-30~3000-PASS




11AX80MIMO-Ant3-6945-3000~10000-PASS




11AX80MIMO-Ant3-6945-10000~40000-PASS




11AX80MIMO-Ant4-6945-30~3000-PASS




11AX80MIMO-Ant4-6945-3000~10000-PASS




11AX80MIMO-Ant4-6945-10000~40000-PASS




11AX80MIMO-Ant1-7025-30~3000-PASS




11AX80MIMO-Ant1-7025-3000~10000-PASS




11AX80MIMO-Ant1-7025-10000~40000-PASS




11AX80MIMO-Ant2-7025-30~3000-PASS




11AX80MIMO-Ant2-7025-3000~10000-PASS




11AX80MIMO-Ant2-7025-10000~40000-PASS




11AX80MIMO-Ant3-7025-30~3000-PASS



11AX80MIMO-Ant3-7025-3000~10000-PASS




11AX80MIMO-Ant3-7025-10000~40000-PASS



11AX80MIMO-Ant4-7025-30~3000-PASS




11AX80MIMO-Ant4-7025-3000~10000-PASS




11AX80MIMO-Ant4-7025-10000~40000-PASS




11AX160SISO-Ant1-6025-30~3000-PASS




11AX160SISO-Ant1-6025-3000~10000-PASS




11AX160SISO-Ant1-6025-10000~40000-PASS



11AX160SISO-Ant2-6025-30~3000-PASS




11AX160SISO-Ant2-6025-3000~10000-PASS




11AX160SISO-Ant2-6025-10000~40000-PASS




11AX160SISO-Ant3-6025-30~3000-PASS




11AX160SISO-Ant3-6025-3000~10000-PASS




11AX160SISO-Ant3-6025-10000~40000-PASS



11AX160SISO-Ant4-6025-30~3000-PASS



11AX160SISO-Ant4-6025-3000~10000-PASS




11AX160SISO-Ant4-6025-10000~40000-PASS







11AX160SISO-Ant1-6185-30~3000-PASS




11AX160SISO-Ant1-6185-3000~10000-PASS




11AX160SISO-Ant1-6185-10000~40000-PASS




11AX160SISO-Ant2-6185-30~3000-PASS




11AX160SISO-Ant2-6185-3000~10000-PASS



11AX160SISO-Ant2-6185-10000~40000-PASS




11AX160SISO-Ant3-6185-30~3000-PASS




11AX160SISO-Ant3-6185-3000~10000-PASS




11AX160SISO-Ant3-6185-10000~40000-PASS




11AX160SISO-Ant4-6185-30~3000-PASS




11AX160SISO-Ant4-6185-3000~10000-PASS




11AX160SISO-Ant4-6185-10000~40000-PASS




11AX160SISO-Ant1-6345-30~3000-PASS



11AX160SISO-Ant1-6345-3000~10000-PASS




11AX160SISO-Ant1-6345-10000~40000-PASS



11AX160SISO-Ant2-6345-30~3000-PASS



11AX160SISO-Ant2-6345-3000~10000-PASS



11AX160SISO-Ant2-6345-10000~40000-PASS