







11AX160SISO-Ant3-6345-30~3000-PASS




11AX160SISO-Ant3-6345-3000~10000-PASS




11AX160SISO-Ant3-6345-10000~40000-PASS



11AX160SISO-Ant4-6345-30~3000-PASS




11AX160SISO-Ant4-6345-3000~10000-PASS




11AX160SISO-Ant4-6345-10000~40000-PASS




11AX160SISO-Ant1-6505-30~3000-PASS



11AX160SISO-Ant1-6505-3000~10000-PASS




11AX160SISO-Ant1-6505-10000~40000-PASS








11AX160SISO-Ant2-6505-30~3000-PASS



11AX160SISO-Ant2-6505-3000~10000-PASS




11AX160SISO-Ant2-6505-10000~40000-PASS







11AX160SISO-Ant1-6665-30~3000-PASS




11AX160SISO-Ant1-6665-3000~10000-PASS




11AX160SISO-Ant1-6665-10000~40000-PASS



11AX160SISO-Ant2-6665-30~3000-PASS




11AX160SISO-Ant2-6665-3000~10000-PASS




11AX160SISO-Ant2-6665-10000~40000-PASS




11AX160SISO-Ant3-6665-30~3000-PASS




11AX160SISO-Ant3-6665-3000~10000-PASS



11AX160SISO-Ant3-6665-10000~40000-PASS



11AX160SISO-Ant4-6665-30~3000-PASS




11AX160SISO-Ant4-6665-3000~10000-PASS




11AX160SISO-Ant4-6665-10000~40000-PASS




11AX160SISO-Ant1-6825-30~3000-PASS




11AX160SISO-Ant1-6825-3000~10000-PASS




11AX160SISO-Ant1-6825-10000~40000-PASS




11AX160SISO-Ant2-6825-30~3000-PASS




11AX160SISO-Ant2-6825-3000~10000-PASS




11AX160SISO-Ant2-6825-10000~40000-PASS




11AX160SISO-Ant3-6825-30~3000-PASS




11AX160SISO-Ant3-6825-3000~10000-PASS




11AX160SISO-Ant3-6825-10000~40000-PASS




11AX160SISO-Ant4-6825-30~3000-PASS




11AX160SISO-Ant4-6825-3000~10000-PASS




11AX160SISO-Ant4-6825-10000~40000-PASS




11AX160SISO-Ant1-6985-30~3000-PASS




11AX160SISO-Ant1-6985-3000~10000-PASS




11AX160SISO-Ant1-6985-10000~40000-PASS



11AX160SISO-Ant2-6985-30~3000-PASS



11AX160SISO-Ant2-6985-3000~10000-PASS



11AX160SISO-Ant2-6985-10000~40000-PASS