

THROWBACK AUTOTUNE • WIRELESS SPEAKER •



USER MANUAL

SPECIFICATIONS:

- Bluetooth 5.3
- 2x 5W Speakers
- Playtime 4-5 Hours
- Battery Powered
- USB-C Charging

THROWBACK © COPYRIGHT ALL RIGHTS RESERVED. THROWBACK is an innovative brand of Truststone Group LLC. No portion of this design may be reproduced without express written permission. Other trademarks and trade names are those of their respective owners. All rights reserved. Distributed by Truststone Group LLC, New York NY 10003.

FCC ID:2BBPLHGWLCRSPKL



MADE IN CHINA

Wireless Speaker Specification

- **charge** External 5V charge for this machine , plug in the USB-C cable for charging, the LED light stays on during charging and turns off when fully charged
- **ON/OFF** Hold M/∅ key to ON/OFF. Press:mode switching.
Turn on the Bluetooth function on your phone, search for WONDERLIT and connect to Bluetooth
- **The Key Operation**
 - 1, " M/∅ " Short press:Bluetooth/ autodyne / FM .Double click is TWS function
 - 2, " M/V- " Long press: Reduce volume
Short press: FM model for the previous station, Bluetooth mode is previous song.
The self timer mode short press " M/V- " button for the self timer function
 - 3, " M/V+ " Long press: Increase volume
Short press: FM Model for the next stage, the Bluetooth mode for the next song.
The self timer mode short press " M/V+ " button for the self timer function
 - 4, " M " FM / Bluetooth state short press play / pause . FM status
long press for the auto channel search.
Incoming short press the " M " key to answer the phone .Long press to reject calls
Short press " M " to hang up the call, double click the " M " key to dial back the last telephone
- **The Self Timer Funtion**
click "M", from the Bluetooth mode to the self timer mode
Turn on the Bluetooth function on your phone, search for "WONDERLIT" and connect to Bluetooth
open mobile phone camera interface, press " M/V- " or " M/V+ " button
to take pictures
Attached: Android system requires 4.2.2 IOS requires version 6.0nd above, the other version
does not support. Mobile phone with independent pictures button generally do not support.

TWS connection method:

- I. Open two bluetooth speakers at the same time
- II. Double-click the " M " key(Heard "tick" is ok)
- III. Wait for the two bluetooth speakers to interconnect(Two speakers also appear the sound at the same time,express connect success)
- IV. Open the phone bluetooth,search for the matching name for another bluetooth speaker and connect it
V. Two bluetooth speakers were connected successfully, and can start playing music

Remark:

1. Two bluetooth speakers that already connected successfully, can automatic connect another bluetooth speaker when open the speaker again. **Turn off TWS function:** Double click the M key on one of the machines
2. If no automatic connection, please turn off the bluetooth, restart two speakers(didn't need press any key)
3. When the two speakers automatic connect, open the phone bluetooth again and connect the two bluetooth speakers

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.