

BL-18002



Speaker Candle

STREAM HOLIDAY MUSIC
TO ANY ROOM



LITHIUM-ION BATTERY WARNINGS

This device contains a non-removable Lithium-Ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between accept any interference received, including interference that may cause undesired operation.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an

experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

TROUBLESHOOTING

BLUETOOTH NOT CONNECTING

- Ensure your device is within 33 feet of the speaker and reconnect your device to "Candle Speaker."

AUDIO IS NOT CLEAR

- Power the speaker off and then back on.
- Adjust your device's equalizer.
- Check the volume level on your device.

SPEAKER DOES NOT PLAY AUDIO

- Make sure the speaker is charged.
- Power the speaker off and then back on.
- Confirm device is paired.

NOTE: The speaker remembers the last device paired. If you would like to use another device, pair that device manually. you can pair any two device Togehter

CARE AND MAINTENANCE:

Clean the candle with a soft, dry cloth. Do not use harsh cleaners to clean the candle. Please note the wax candle is made from real wax and should be handled and stored with care.

SPECIFICATIONS

Power Supply: DC 5V/ 1A (Input)

Range: Class 2, up to 33 ft (10 m)

Compatibility: Bluetooth 5.0 device with A2DP/AVRCP

Speaker: 4 Ohm 2.5"

Horn speaker Power Output: 3W

Horn speaker Frequency Response: 200Hz - 10KHz

Battery Life: Approx. 4 hours

Charging Time: Approx. 3 hours

Product Weight: Approx. 1.0 lb


Product Dimensions:

Approx. 3.75" (dia) x 5.7" (h)

CHARGING THE SPEAKER

1. Connect the USB Cable (included) to the Micro USB Port on the speaker.
2. With the speaker powered off, plug the other end of the USB Cable into a USB Port on your computer or 5V 1A USB adapter (not included).
3. The LED Indicator light will illuminate red while charging and the light will turn blue when the speaker is fully charged. Charges in approximately 3 hours for up to 4 hours of listening enjoyment.

NOTE: When battery power is low, an alert tone will sound.



OPERATION

The control switch is located on the bottom of the Speaker Candle.

1. C (Candle function only)
2. OFF (Unit Off)
3. BT + C (Bluetooth Speaker and Candle function ON)

When switching to "C," the candle function is ON with automatic timer setting of 8 hours. The candle will stay ON for 8 hours and then OFF for 16 hours. The candle will turn on every day at the same time it was originally set.

Set the switch to "OFF" to turn off the candle and speaker function.

When switching to "BT+C," the Bluetooth Speaker function and Candle function is ON for 4 hours And then OFF for 20 hours. the candle will turn on every day at the same timer it was originally set.



PAIRING YOUR DEVICE FOR AUDIO

1. To pair your device, make sure your device is within 33 feet of the Speaker Candle. Refer to your device's owner's manual for details if necessary.
2. Turn the switch of the candle speaker to "BT+C."
3. The pairing mode tone will sound and the speaker is ready to pair.
4. Once the Speaker Candle is in pairing mode and your device is ready to pair, select "Candle Speaker" on your device. If prompted, use 0000 as a PIN for the pairing code. Once the Speaker Candle is selected, a tone will sound to confirm pairing is complete.
5. After the initial pairing of your device, the Speaker Candle should automatically pair with your device the next time the unit is powered on. Depending upon your device, you may have to select "Candle Speaker" in your device's Bluetooth® menu.
6. To enter manual pairing mode to pair with a new device, switch the Speaker Candle to "OFF" and to "BT+C" again to activate the Bluetooth pairing mode.
7. When "BT+C" mode is ON, if there is no Bluetooth connection established or the connection is lost for over 30min, the Speaker Candle will automatically turn off the Bluetooth function to conserve battery life. The flame light will remain lit. Re-set the Bluetooth function by moving the switch to "OFF" and then to "BT+C" again to activate Bluetooth functions.
8. Volume control and playback function can only be controlled through the paired device.

NOTE: The candle light will stay on For 4 hours and then OFF for 20 hours. When the Speaker Candle is in the "BT+C" Mode.

SAFETY INSTRUCTIONS

- This is an artificial candle. Do not light the candle.
- The candle is a decorative item and not a toy.
- Place the candle on easy to clean, durable surfaces. Product contains wax and oil and may stain delicate surfaces.
- The candle must not be exposed to extreme temperatures, direct sunlight or moisture.