

WATCH OPERATING GUIDE

WATCH CHARGING AND ACTIVATION

Attach the magnetic charging wire to the metal contact of the charging port until the charging indication appears on the watch display. When the watch is low, charge. The device is an all-in-one machine.

FUNCTION INTRODUCTION

Dial switch


Long press for 2s on the home screen to enter the dial switch interface. Slide right and left to switch the dial for selection and click to select the dial.

Control center

Function Overview: No Disturbance, Flipping Hands to Display, AI Voice, Illumination Degree, settings, search for phone, power-saving mode, system information.

MOBILE PHONE CLIENT DOWNLOAD

Scan the QR code below to download and install the mobile phone client.



FUNCTION INTRODUCTION

Call records

This function can save the last 10 call records.

Call bluetooth

Call Bluetooth: Divided into "call audio" and "media audio" switches.

Call audio

Use the Bluetooth connection switch for the bracelet to call. Media Audio: Switch for the band to play media audio. (off by default)

Find my phone

Keep the watch connected to the APP, and click "Find my phone". The beeping on your mobile

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Function menu

Slide the main interface to the right and enter the menu page. Double click the button to switch menu modes, sharing 6 menu modes. The default is the 3D rotating menu.

Call function

This function needs to be connected to audio Bluetooth. When entering the dial, you can enter the phone number as needed, and then dial; long press 7 and 9 on the keyboard for 2s to enter * and #.

FUNCTION INTRODUCTION

Sport record

The interface saves the recent 10 pieces of historical sport records. You can view the sport duration, heart rate and calories during the sport.

Stop watch

As for the timer function, the user may start quick timing through the system preset time or click the user-defined button to set the time. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports

interface will display the real-time temperature and weather type.

Information

Open information push on the App and the watch can receive the corresponding message. It can save up to the last 15 pieces of messages.

Secretary reminder

You can open this function through [device>editor>reminder] on the App. After it is opened, you can set the start time, end time and the period of

Movement data

Display the number of steps, distance, and calories recorded on the day, and the number of steps in the last seven days. You can set the target number of steps, distance, and calories in the APP.

FUNCTION INTRODUCTION

Alarm clock

Keep the watch connected to the APP, you can set a single alarm clock or a cyclic alarm clock. You can set up to 5 alarm clocks.

FUNCTION INTRODUCTION

RF warning statement

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Timer

Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to timing the pause. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports

interface will display the real-time temperature and weather type.

Information

Open information push on the App and the watch can receive the corresponding message. It can save up to the last 15 pieces of messages.

Secretary reminder

You can open this function through [device>editor>reminder] on the App. After it is opened, you can set the start time, end time and the period of

Movement data

Display the number of steps, distance, and calories recorded on the day, and the number of steps in the last seven days. You can set the target number of steps, distance, and calories in the APP.

FUNCTION INTRODUCTION

Stop watch

As for the timer function, the user may start quick timing through the system preset time or click the user-defined button to set the time. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports

interface will display the real-time temperature and weather type.

Information

Open information push on the App and the watch can receive the corresponding message. It can save up to the last 15 pieces of messages.

Secretary reminder

You can open this function through [device>editor>reminder] on the App. After it is opened, you can set the start time, end time and the period of

Movement data

Display the number of steps, distance, and calories recorded on the day, and the number of steps in the last seven days. You can set the target number of steps, distance, and calories in the APP.

FUNCTION INTRODUCTION

Stop watch

As for the timer function, the user may start quick timing through the system preset time or click the user-defined button to set the time. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports

interface will display the real-time temperature and weather type.

Information

Open information push on the App and the watch can receive the corresponding message. It can save up to the last 15 pieces of messages.

Secretary reminder

You can open this function through [device>editor>reminder] on the App. After it is opened, you can set the start time, end time and the period of

Movement data

Display the number of steps, distance, and calories recorded on the day, and the number of steps in the last seven days. You can set the target number of steps, distance, and calories in the APP.

FUNCTION INTRODUCTION

Stop watch

As for the timer function, the user may start quick timing through the system preset time or click the user-defined button to set the time. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports

interface will display the real-time temperature and weather type.

Information

Open information push on the App and the watch can receive the corresponding message. It can save up to the last 15 pieces of messages.

Secretary reminder

You can open this function through [device>editor>reminder] on the App. After it is opened, you can set the start time, end time and the period of

Movement data

Display the number of steps, distance, and calories recorded on the day, and the number of steps in the last seven days. You can set the target number of steps, distance, and calories in the APP.

FUNCTION INTRODUCTION

Stop watch

As for the timer function, the user may start quick timing through the system preset time or click the user-defined button to set the time. Click the start button for the timing of the start. Click the pause button to timing the pause. Click the reset button to time to zero.

Fa

to start the watch

Press the power switch for three times. Maybe the battery level is too low. Please charge the battery timely.

Music

Keep the watch connected to the APP, You can control the pause and start of the mobile phone

Find my phone

music player, volume adjustment, and song switching.

Calculator

The numerical input is in the upper limit of 7 digits (input one negative number is not processed), and the result of the calculation is within the upper limit

Weather

After you connect your watch with the APP and open the location permission, the weather

Sports