



# Installation List



**CRS1 X1**




**power cable1 X1**




**power cable2 X1**

# Product Introduction




# interface definition



# Installation instructions

1. Unpack the machine and fix it to the frame first
2. After installing the machine, install the power cord on the machine and install the loading cable on the vehicle
3. Installing the wire, modify the wire cover and fix it with screws



# spec

IO	botton	power、 up 、 down、 Play&pause
	spk	4Ω15W X2
	USB	USB2.0-Bx1
DCIN		support 24V--80V DCIN
Interface		Right SPK Harness : DCIN、 USB、 Audio cable Left SPK Harness: Audio cable
BT		Support Bluetooth5.0, compatible with Bluetooth4.2 /4.0/2.1 + EDR system

# FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.