



65.5*102.5MM 128克铜板纸 风琴折



User Manual

Works with




Hook


Indicator Light

Power Button

Charging Port

key chain





Setting Up Your iPhone

Compatibility

The key is only compatible with iPhone 8 series or later phones running iOS 14.5 or later with Two-Factor Authentication turned on.

1. Turn on Two-Factor Authentication for your Apple ID

On your iPhone, Go to **Settings** > your name > **Password & Security**. Tap **Turn On Two-Factor Authentication**. Then tap **Continue** and follow the onscreen instructions.

On your Mac, choose Apple menu > **System Settings** > **System Preferences**. Then click on your name (or Apple ID), click **Password & Security**, then tap **Two-Factor Authentication**, click **Turn On**, and follow the onscreen instructions.

On the web, Go to [appleid.apple.com](#) and sign in using your Apple ID. Answer your security questions, then tap **Continue**. Tap **Continue** when you see a prompt to update account security. Then tap **Update Account Security** and follow the onscreen instructions.

2. Turn on Find My

A. Go to **Settings**.

B. Tap your name, then tap **Find My**.


C. Tap **Find My iPhone** and turn on **Find My iPhone**.


3. Turn on Bluetooth

4. Connect to a stable Wi-Fi or cellular network

8. Turn on Location Services

Go to **Settings** > **Privacy & Security** > **Location Services** > turn on **Location Services**.





Getting Started

Power on


Short press the key's power button **once**, and a beep will sound to indicate that it's turned on.


Power off

To turn off the power, press the power button **3 times** in a row. **2 short presses** and **1 long press**, after hearing two "beeps", the "key" is turned off. If the key has not been paired with a mobile device, a beep will be heard and the power will automatically turn off. Turn on the power to continue pairing.

Factory reset

To reset, press the power button **5 times** in a row **at short presses** and **1x long press**, after hearing a beep, the "key" returns to factory setting.





Locating Your Key

Locate your key via the app

1. Open the Find My app.
2. Tap the **Items** tab.
3. Select your key in the **Items** list.
4. Tap **Directions** to open the location of your key and get directions in the Maps app.

Play sound alert

1. Open the Find My app.
2. Tap the **Items** tab.
3. Select your key in the **Items** list and tap **Play Sound**.

*The sound alert will only play if your iPhone is connected to a network, and your key is in Bluetooth range of your iPhone (approx. 300m).

Set up Notify When Left Behind


If your key is not in Bluetooth range of your iPhone for a period of time, you will receive a notification that your key has been lost (if you set up a name, the name will be displayed; otherwise it will show key).


1. Open the Find My app.
2. Tap the **Items** tab.
3. Select your key in the **Items** list and scroll down.
4. Under **Notifications**, tap **Notify When Left Behind** and turn on.

Mark your key as lost

1. Open the Find My app.
2. Tap the **Items** tab.
3. Select your key in the **Items** list and scroll down.
4. Under **Notify When Left Behind**, turn it on.
5. Under **Device**, tap **Enable**, then tap **Continue**.

Enter your phone number/email address so that the finder of your key can contact you. Then tap **Activate**.





Changing the Name of Your Key

1. Open the Find My app and tap the **Items** tab.
2. Select your key in the **Items** list.
3. Scroll down and tap **Rename Item**.
4. Select a name from the list or select **Custom Name**.
5. For Custom Name, input a name and select an emoji.
6. Tap **Done**.

Removing Your Key

Removing your key from your Apple ID will allow it to be activated and used by another person.

1. Ensure that your key is connected to your iPhone.
2. Open the Find My app.
3. In the **Items** tab, tap the key.
4. Tap **Remove Item** > **Remove** and confirm to remove.


*If not connected when removing your key from your Apple ID, it will no longer be discoverable and you will need to perform a factory reset before creating a new connection (see "Getting Started" > "Factory reset" above).


Unwanted Tracking Notification

If your key is separated from your iPhone and is detected moving with another person with an Apple device over time, that person will receive a tracking alert message.

Safety Warnings


1. Do not expose the device to temperatures below -10°C (14°F) or above 50°C (122°F).
2. Do not expose the device to an open flame, submerge it in water, or expose it to salt as this will damage the device.
3. Always check for damage to the device, cables, or other accessories before using the device. If damaged, do not use the device.





More Specific Info

1. How long will the battery last when fully charged?
After activating the device, it needs to be fully charged immediately and can be used normally for 5 months. It is recommended to charge it every 4 months.
2. How do you know the remaining power?
iPhone 8 series or later will display the remaining battery level of the device.
3. How long does it take to fully charge the battery?
3-5 hours.
4. Charging indicator light
 - Charging: Orange light
 - Full Charging: Green light



FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.