

尺寸: 75*105mm
材料:

A

B

Small Rig

Handle with Follow Focus for DJI RS Series

DJI RS 系列稳定器手柄 4329

Thank you for purchasing SmallRig's product. Please read the Operating Instruction carefully. Please follow the safety warnings.

Important Notice

Please read the following instructions carefully:

- This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.
- Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.
- Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.
- Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.
- Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.
- Do not use the product near combustible or volatile substances to avoid fire or smoke.
- Turn off the product after use.
- Please clean the product with a soft dry cloth.
- The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.
- After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.
- Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.
- When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

In the Box

1. Stabilizer follow focus handle × 1
 2. Receiver × 1
 3. USB-A to USB-C Cable × 1
 4. Guarantee Card × 1

产品特点

1. This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.

2. Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.

3. Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.

4. Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.

5. Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.

6. Do not use the product near combustible or volatile substances to avoid fire or smoke.

7. Turn off the product after use.

8. Please clean the product with a soft dry cloth.

9. The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.

10. After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.

11. Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.

12. When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

产品特点

1. This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.

2. Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.

3. Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.

4. Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.

5. Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.

6. Do not use the product near combustible or volatile substances to avoid fire or smoke.

7. Turn off the product after use.

8. Please clean the product with a soft dry cloth.

9. The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.

10. After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.

11. Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.

12. When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

产品特点

1. This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.

2. Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.

3. Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.

4. Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.

5. Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.

6. Do not use the product near combustible or volatile substances to avoid fire or smoke.

7. Turn off the product after use.

8. Please clean the product with a soft dry cloth.

9. The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.

10. After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.

11. Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.

12. When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

产品特点

1. This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.

2. Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.

3. Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.

4. Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.

5. Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.

6. Do not use the product near combustible or volatile substances to avoid fire or smoke.

7. Turn off the product after use.

8. Please clean the product with a soft dry cloth.

9. The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.

10. After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.

11. Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.

12. When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

产品特点

1. This product is not designed or waterproof. Please do not use it in water and do not immerse the product into the ground, liquid or strong areas.

2. Do not apply pressure to the OLED screen. Excessive pressure may cause permanent damage.

3. Do not use the product in a completely enclosed environment, as it may cause malfunctions, fire or accident due to increased internal temperature.

4. Do not place the product in a place of high temperature to avoid damage to the battery or battery explosion.

5. Do not place the product in a place of corrosion chemicals to avoid rust and pollution corrosion to the product.

6. Do not use the product near combustible or volatile substances to avoid fire or smoke.

7. Turn off the product after use.

8. Please clean the product with a soft dry cloth.

9. The product contains built-in non-removable lithium batteries, unauthorised disassembly is strictly prohibited.

10. After being stored for a long time without use, the product should be charged and then used. Please do not charge the product without removing the battery, or charge directly, to extend the life of the battery.

11. Do not use the product in a place with high humidity, high temperature, high salted substances. Please recycle the damaged or unused products in accordance with waste management regulations.

12. When the battery can't be folding, please stop the device immediately, otherwise the device will automatically shut off due to a failed battery or other reasons.

Do not disassemble the product. If you suspect any problem with the product, please contact the platform where you purchased it and apply for a return.

This product can only control the DJI RS stabilizer through the slider on the right side of the DJI stabilizer. Please make sure the level indicator is in the middle of the slider.

This product is prohibited to controlling the DJI RS2 / RS3 / RS4 / RS4 Pro / RS4 Mini.

C

[illegible]

D

--	--

技术要求 (包装物料) 1.材料:所有材料要求符合RoHS 2.0环保要求 2.珍珠棉类及含有胶水材料需满足质量验收要求: 低温存储: -20°C ±2°C 24h 高温高湿: 70 ±2°C 90% ±5% 24h 不温胶, 不自然分层, 测试后产品无残胶 3.工艺:模切整齐, 无划痕;覆膜无尘, 无气泡;烫印工整 4.印刷:印刷清晰, 无污点, 无脏污 5.公差:彩盒 ±1mm; 物流箱 ±10mm 6.外观:外观要求参考承认样, 提供《样品承认书》	单位	mm	页码	1/1		公差 ±1	MODEL (成品号)	4329				LEQI 乐其 SmallRig 斯莫格				文案审核			Vi 审核	
	纸张厚度标准: • 铜版纸类印刷品: 纸张克重依据印刷行业行业标准						PART_NO. (物料编号)	\		包装设计		袁康		认证/货鉴工程师		ID设计师		产品经理		
	• 坑纹纸类印刷品: 破裂强度及边压强度依据印刷行业行业标准						PART_NAME (零件名称)	操作指引		包装复核				质量工程师		结构设计师		产品线总监		