



USER MANUAL

AL-03 | WIRELESS NECKBAND EARPHONES

Before using this product, please read these instructions carefully and keep them.

STAR WELCOME

Thank you for choosing AzukiLife Product. Our wireless earphones come with light weight and fashionable design, along with on-the-go controls for your music and calling experience.


WIRELESS TECHNOLOGY

With the latest wireless technology, you can enjoy hassle free music without any interruption and you don't have to face wire tangling issues,

Wireless connection allows you to enjoy your music experience or calls without holding your mobile phone but the maximum distance between them shall be within 10 meters (about 30 feet). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices.

FUNCTION KEY DESCRIPTION

- 1 USB Type-C port
- 2 Volume+/Next Song
- 3 Power/Call/Multifunction Button
- 4 LED indication light
- 5 Volume-/Previous Song



USER MANUAL

AL-01 | WIRELESS NECKBAND EARPHONES

Before using this product, please read these instructions carefully and keep them.

STAR WELCOME

Thank you for choosing AzukiLife Product. Our wireless earphones come with light weight and fashionable design, along with on-the-go controls for your music and calling experience.

WIRELESS TECHNOLOGY

With the latest wireless technology, you can enjoy hassle free music without any interruption and you don't have to face wire tangling issues,

Wireless connection allows you to enjoy your music experience or calls without holding your mobile phone but the maximum distance between them shall be within 10 meters (about 30 feet). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices.

FUNCTION KEY DESCRIPTION

- 1 USB Type-C port
- 2 Volume+/Next Song
- 3 Power/Call/Multifunction Button
- 4 LED indication light
- 5 Volume-/Previous Song

TOP OPERATING GUIDE

In below instruction, MF button refers to the multifunction button (Please refer to FUNCTION KEY DESCRIPTION)
•Power on & Pairing: Long press on the MF button for 3 seconds
•Power off: Long press on the MF button for 5 seconds
•Pause/Play: Single tap on the MF button
•Volume up/down: Single tap on the +/- button
•Previous/Next song: Long press the +/- button for 2 seconds
•Answer phone call: Single tap once on the MF button
•End phone call: Single tap on the MF button
•Reject phone call: Long press on the MF button for 2 seconds
•Redial the last phone number: Double click on the MF button

TOP CONNECT YOUR DEVICE

1. Place your earphones within 1 meter from your phone.
2. Long press on the MF button until the red and blue lights flash alternatively, which indicates the device is in pairing mode now.
3. Turn on the Bluetooth function on your phone, and search for "AL-03" under pair new device list, and select "AL-03" on the next screen, tap on connect button.
If the blue light flashes up, congratulations! Your device is successfully connected now.

TOP CHARGE YOUR DEVICE

1. Use the USB Type-C charging port to charge your earphones. It will take around 1.5 hours to get fully charged.
2. Please use DC-5V 500mA charger to charge your device.
IMPORTANT: Please note that the maximum voltage supported cannot exceed DC-5V.

TOP LED LIGHT INDICATION

Low power: Red light flashes every 5 seconds with a voice alert "battery low".
Under charging: LED indication shows red light.
Full charged: LED indication turns blue.

FAQ

Why the device is not displayed on my phone?

It might be because the earphones are powered off or the wireless connection function of your mobile phone encounters some issues.

1. After you power off your earphones, long press on the MF button until the red and blue lights flash alternatively to activate the earphones pairing status.
2. Reboot your phone, and connect again.

NOTE

When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 2 minutes, otherwise your earphones will automatically power off.

Why the earphones cannot be linked with my mobile phone using the wireless connection function?

It might be because the wireless connection function on your device is not turned on or your earphones are connected to another device or the earphones are still in pairing mode.

1. Please check if the wireless connection function on your device is turned on.
2. Please check and confirm your earphones are not connected to another device.
3. Please check if your earphones are in pairing mode (which will be indicated by red & blue Led indication on your device).

Why can't I hear any sound from my earphones?

It might be because the earphones' volume is down to minimum; the earphones are not well connected with your phone; or your earphones are not within the wireless connection working range

1. Adjust volume on your phone; or press on the "+" button to turn the volume up.
2. Proceed to connection process again.
3. Keep your earphones within 10 meters from your mobile phone to respect the wireless connection working range.

When the music is playing, why the music cannot be controlled with the play/pause, previous/next song and volume up/down buttons?

It might be because the mobile phone doesn't support the AVRCP (Audio/Video Remote Control Profile) protocol.

This feature requires the mobile device to be paired with the earphones to support the AVRCP (Audio/Video Remote Control Profile) protocol.

TOP OPERATING GUIDE

In below instruction, MF button refers to the multifunction button (Please refer to FUNCTION KEY DESCRIPTION)
•Power on & Pairing: Long press on the MF button for 3 seconds
•Power off: Long press on the MF button for 5 seconds
•Pause/Play: Single tap on the MF button
•Volume up/down: Single tap on the +/- button
•Previous/Next song: Long press the +/- button for 2 seconds
•Answer phone call: Single tap once on the MF button
•End phone call: Single tap on the MF button
•Reject phone call: Long press on the MF button for 2 seconds
•Redial the last phone number: Double click on the MF button

TOP CONNECT YOUR DEVICE

1. Place your earphones within 1 meter from your phone.
2. Long press on the MF button until the red and blue lights flash alternatively, which indicates the device is in pairing mode now.
3. Turn on the Bluetooth function on your phone, and search for "AL-01" under pair new device list, and select "AL-01" on the next screen, tap on connect button.
If the blue light flashes up, congratulations! Your device is successfully connected now.

TOP CHARGE YOUR DEVICE

1. Use the USB Type-C charging port to charge your earphones. It will take around 1.5 hours to get fully charged.
2. Please use DC-5V 500mA charger to charge your device.
IMPORTANT: Please note that the maximum voltage supported cannot exceed DC-5V.

TOP LED LIGHT INDICATION

Low power: Red light flashes every 5 seconds with a voice alert "battery low".
Under charging: LED indication shows red light.
Full charged: LED indication turns blue.

FAQ

Why the device is not displayed on my phone?

It might be because the earphones are powered off or the wireless connection function of your mobile phone encounters some issues.

1. After you power off your earphones, long press on the MF button until the red and blue lights flash alternatively to activate the earphones pairing status.
2. Reboot your phone, and connect again.

NOTE

When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 2 minutes, otherwise your earphones will automatically power off.

When charging, why does the red light not lightning up?

It might be because the earphones are not connected to a working charging power source.

1. Please check the power charging port works properly.
2. Please check the charging port of the earphones is properly connected.
3. Please check the power supply is properly connected to the charging port of the earphones.

NOTE

When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 2 minutes, otherwise your earphones will automatically power off.

When charging, why does the red light not lightning up?

It might be because you did not use your earphones for a long time. Charge your earphones for 30 minutes until the red light is on.

1. Please check the power charging port works properly.
2. Please check the charging port of the earphones is properly connected.
3. Please check the power supply is properly connected to the charging port of the earphones.

NOTE

Overcharging or placing the earphones under high temperature atmosphere will cut down the battery capacity and lifetime.

TOP OPERATING GUIDE

It might be because the mobile network is not good enough or the earphones are not in the wireless connection working range.
1. Confirm whether the mobile network is strong enough.
2. Please confirm that the earphones are within the effective working distance of 10 meters from your mobile phone, also check if no major obstacle is causing interference to the connection.

Why the earphones call quality is not good?

It might be because the mobile network is not good enough or the earphones are not in the wireless connection working range.

1. Confirm whether the mobile network is strong enough.
2. Please confirm that the earphones are within the effective working distance of 10 meters from your mobile phone, also check if no major obstacle is causing interference to the connection.

STAR WELCOME

Thank you for choosing AzukiLife Product. Our wireless earphones come with light weight and fashionable design, along with on-the-go controls for your music and calling experience.

WIRELESS TECHNOLOGY

With the latest wireless technology, you can enjoy hassle free music without any interruption and you don't have to face wire tangling issues,

Wireless connection allows you to enjoy your music experience or calls without holding your mobile phone but the maximum distance between them shall be within 10 meters (about 30 feet). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices.

FUNCTION KEY DESCRIPTION

- 1 USB Type-C port
- 2 Volume+/Next Song
- 3 Power/Call/Multifunction Button
- 4 LED indication light
- 5 Volume-/Previous Song

FAQ

Why the device is not displayed on my phone?

It might be because the earphones are powered off or the wireless connection function of your mobile phone encounters some issues.

1. After you power off your earphones, long press on the MF button until the red and blue lights flash alternatively to activate the earphones pairing status.
2. Reboot your phone, and connect again.

NOTE

When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 2 minutes, otherwise your earphones will automatically power off.

When charging, why does the red light not lightning up?

It might be because the earphones are not connected to a working charging power source.

1. Please check the power charging port works properly.
2. Please check the charging port of the earphones is properly connected.
3. Please check the power supply is properly connected to the charging port of the earphones.

NOTE

Overcharging or placing the earphones under high temperature atmosphere will cut down the battery capacity and lifetime.

Why the earphones call quality is not good?

It might be because the mobile network is not good enough or the earphones are not in the wireless connection working range.

1. Confirm whether the mobile network is strong enough.
2. Please confirm that the earphones are within the effective working distance of 10 meters from your mobile phone, also check if no major obstacle is causing interference to the connection.

Why can't I hear any sound from my earphones?

It might be because the earphones' volume is down to minimum; the earphones are not well connected with your phone; or your earphones are not within the wireless connection working range

1. Adjust volume on your phone; or press on the "+" button to turn the volume up.
2. Proceed to connection process again.
3. Keep your earphones within 10 meters from your mobile phone to respect the wireless connection working range.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.