

Quick start guide

Attention

Thank you for buying this product! This product is installed with smart operating system. This user guide briefly introduces the various functions of this product, so that you can control freely and fully realize the value enjoyment brought by this product to you. Please read this user guide carefully before using it.

1. Note that the best performance of a new battery can only be achieved after two or three full charge and discharge cycles.
2. In order to prevent data loss, users are advised to regularly back up important data, especially before firmware upgrade or product repair. We are not responsible for any loss of data.
3. This product is a high-precision electronic product, please do not disassemble by yourself.
4. Avoid strong beating, water drop and water splash, and collision with the product.
5. Avoid using this product in the following environments: high temperature, low pressure, low temperature, humidity, dust, strong magnetic field and prolonged exposure to sunlight. Our company suggest you at an altitude of 3000 meters, 0°C to 35 °C, humidity 5% to 95% of the use of this product in the environment.
6. Please use batteries, chargers and accessories approved by the manufacturer. Use of any other type of accessories will violate the warranty and may be dangerous.

Charger adaption requirements

Please refer to the product input voltage/current value in the user guide for charger adaption. If the tablet is not used for a long time, please make sure to charge it once within three months, and then shut it down and place it after it is fully charged. For long-term use of the tablet, the charger must be pre-charged for more than 30 minutes before the charging state is displayed.

Charger specification: input AC100-240V, 50/60hz; output 5V/3A or 9V/2.22A.

Warm prompt

The nominal battery life of the product refers to the maximum battery life that can be achieved under the environment of minimum power consumption. The actual battery life may vary depending on the usage and environment (such as WIFI/WIFI hotspot, Bluetooth, screen brightness, volume), as well as the individual seat.

First boot wizard

This wizard will help you quickly select the language, set up mobile network, set up wi-fi network, set the date and time, set user and computer protection password, you can follow the wizard tips, user-friendly Settings, open your value experience.

Key definitions

Power:

In the shutdown state, long press the power button for 3 seconds to power on, short press the power button to put the screen out of sleep.

When the screen needs to be activated, press the power button again.

In the startup state, long press for 3 seconds to enter the shutdown prompt interface, long press for 10 seconds to force shutdown and restart.

Volume: Short or long press the volume button to increase or decrease the volume.

UNLOCK: Slide the screen upwards to unlock the screen.

HOME : Slide the screen upwards from the bottom return to the main screen.

Recent apps : Slide the screen upwards from the bottom and hold

SCREENSHOT: Press "Screenshot" to save the Selected application interface

Appearance and I/O instructions

WI-FI connection

1. Click the "setting" icon to enter the setting list interface, click "network & Internet", and select "Wi-Fi" to enter the setting menu;
2. Switch on the Wi-Fi, and the system will automatically scan the nearby wi-fi hotspot signals;
3. Select the Wi-Fi signal that can be connected, enter the corresponding password, and click "connect".

Mobile network connection

1. In the shutdown state, use the card needle to take out the SIM card tray, load the nano SIM card correctly and install the SIM card tray, then boot into the system;
2. Click the "setting" function icon to enter the setting list interface and select the "Data usage" menu;
3. Switch on the "mobile data network".

Bluetooth connection

1. Click the "setting" icon to enter the setting list interface and select the "connected devices" menu;
2. Click "connection preferences" menu to enter the list interface, and click "Bluetooth" menu;
3. Swipe the switch to enable the Bluetooth function, and the system will automatically scan the nearby Bluetooth signal;
4. Select the Bluetooth device that can be connected and click "pair" in the "Bluetooth pairing request" that pops up in the system;
5. When the other device is confirmed, it can be connected successfully.
- 2.

Display Settings

Click the "Setting" icon to enter the Setting list interface and select the "display" menu

1. Brightness level: the backlight display brightness of the screen can be adjusted by swiping the progress bar;
2. Night Light: you can choose to open the night light immediately or set the time;
3. Lock screen: set the display content in the lock screen;

4. Screen timeout: the system can be set to shut down the screen and sleep automatically when the system is not in operation;
5. Display size and text: the system display font size can be set;

Sound Settings

Click the "setting" function icon to enter the setting list interface and select the "sound & vibration" menu.

1. Volume: media, call volume, ring volume, notification volume and alarm tone can be adjusted by swiping the progress bar;
2. Ring tone: the ring tone can be set;
3. Notification sound: a notification ring can be set;
4. Alarm sound: alarm tone can be set;
5. Other prompts: open or close the screen lock prompt, touch prompt, dial-up keyboard prompt, charging prompt, touch vibration, etc.

Battery status

Click the "setting" function icon to enter the setting list interface, and click the "battery" menu to view the battery usage;

Battery percentage: switch can be switched on or off the battery power percentage display.

The built-in battery capacity is: 8000mAh, normal use time is 6-8 hours, standby time is about 20 days.

Connect to PC

The native product can be connected to a PC via a USB cable for data copying or deletion.

1. If the PC is a Windows7 or above operating system, the computer will automatically install the MTP driver if it is connected to the computer for the first time;
- 2, if the personal computer is Windows xp operating system, before the first connection, the system must be installed Windows Media Player11 can support the connection.

Application management

Click the "Settings" function icon to enter the Settings list interface, and click the "apps and notifications" menu to view all the installed applications. Click the application to uninstall, clear the default operation, clear the cache, clear the data, force stop and so on.

1. Third-party applications: uninstall;
2. System application: uninstall is not allowed.

Location

Click the "Settings" function icon to enter the Settings list interface and select the "Security & privacy " menu.

1. Use location: switch can be switched on or off to permit apps to use loaction.
2. Location sevices: to set up Earthquake alerts, Emergency location service and so on.

Languages & input

Click the "Settings" function icon to enter the Settings list interface, click the "system" menu.

1. Languages: you can add or chose the system language;
2. Keyboard: the default input method of the system can be set and the function of each input method can be set.

Date & time

Click the "setup" function icon to enter the setting list interface, click the "system" menu, and click the "date & time" menu.

1. Automatically date & time: by swiping the open function, the system can automatically synchronize the date and time when connected to the network. Select the off function to manually set the date and time;
2. Automatically time zone: the system can automatically synchronize the time zone when connected to the network by swiping the open function. Switch off function, you can manually set the time zone;
3. Automatically 24-hour format: swipe the open function to display the time in 24-hour mode.

reset

1. Click the "setting" function icon to enter the setting list interface, click the "system" menu, click the "reset options" menu, and select "Erase all data (factory reset)";
- 2, factory reset will clear all user data (applications, local data, etc.), please pay attention to backup.

Hardware specification

Memory	Flash Memory	128 GB
General	Main Chip	UniSOC T616 Octa-core 2.0GHz
	Display	10.95 inch,1920*1200 IPS
	GPU	Mali-G57 , 800MHz
	Operation	Powered by Android™
	DDR4	6 GB
	Built-in WiFi	6 Hours video play time
	TP	incell ,10 Point touch
	GNSS	GPS/BDS/Glonass/Galileo, A-GPS
	G-sensor	Yes
	Power	9V/2A, support PD fast charge
	Front camera	5.0 MP FF
	Rear camera	Main 13.0MP +Sub 2.0MP
	GSM (Optional)	GSM B2/B5/B8
	WCDMA (Optional)	UMTS B1/B2/B8
	4G LTE (Optional)	FDD B1/B3/BB5/B7/B8/B20, TDD B38/B39/B40/B41
	Dimensions	256.5*168*7.6mm
	WiFi/BT	802.11 a/b/g/n/ac+BT5.0
	Operational	-5~20 °C
Language	Multi -	English, Arabic,Chinese, Russia, French, etc.
Power	Battery	3.7V/8000mah
Compatibl e format	Video	Supports MPEG4-SP, H.264/AVC,H.263,3GP,3G2,MP4,MKV,AVI,WE
	Music	Supports MP3,MP2, AMR,AWB,APE,M4A,
	Photo	Supports JPG, BMP, GIF and PNG photos
	Ebook	Support PDF,TXT,EPUB etc.e-book format

Android is a trademark of Google LLC.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.