

产品说明书

一、包装物品

- > 无线耳机
- > 说明书
- > 充电线

二、 注意事项

- > 请在常温环境中存放以及使用本产品；
- > 请勿将本产品暴露在雨中或潮湿环境中；
- > 请勿丢弃，避免因跌落造成产品损坏；
- > 请勿自行拆解、修理和改造本产品；
- > 请勿使用化学溶剂擦拭本产品；
- > 勿随意丢弃或置于火中，以免引起危险！

三、 温馨提示

为了取得耳机最好的音质效果，请正常佩戴耳机，请勿自行拆卸硬件，清洁耳机请使用干燥、柔软的物品等。
我们建议您采取以下预防措施：

- 1、请以适当的音量欣赏音乐，以防止对听力造成不良影响。
- 2、请勿将产品使用在暴露液体、潮湿或湿气过重的环境中。
- 3、当温度超过指定的温度范围0℃到40℃时，请勿操作本产品。（如果在超过指定温度的范围，请关闭设备，让温度稳定在指定的操作范围内再继续操作。）

四、操作说明

序号	实现功能	耳机状态	操作	提示音	指示灯
1	开机	关机	长按MFB键1秒	开机"Power on"	蓝灯长亮后闪烁
2	关机	开机	长按MFB键3秒	关机"Power off"	红灯长亮约1秒
3	与手机连接成功	待机	/	蓝牙已连接"connected"	蓝灯约3秒内闪烁1次
4	与手机连接断开	连接待机	/	蓝牙已断开"disconnected"	/
5	开机回连	关机	开机后自动回连 先佩戴对充电的设备	蓝牙已连接 "Connected"	蓝灯约3秒内闪烁1次
6	音量调整	通话中、播放音乐	长按音量"V+","V-"	/	/
7	上一首	音乐播放中	单击"V-"键	/	/
8	下一首	音乐播放中	单击"V+"键	/	/
9	音乐播放/暂停	音乐播放中	单击MFB	/	蓝灯约3秒内闪烁1次
10	电话提醒	来电话	/	dudu...dudu./	/
11	接听电话	来电话	单击MFB键	/	/
12	拒接来电	来电话	长按MFB键	/	/
13	未接重拨	待机	双击MFB键	/	/
14	挂断电话	通话中	单击MFB键	/	/
15	SD卡模式	开机状态	插TF卡	SD MODE	蓝灯闪烁
16	FM模式	开机状态	双击V+键	FM MODE	蓝灯闪烁
17	FM自动搜索模式	FM模式	双击MFB自动搜索	/	蓝灯长亮

PRODUCT MANUAL

一、Packaging items

- >Wireless headphone
- > Manual
- > Charging cable

二、 Precautions

- > Store and use this product in a normal temperature environment;
- > Do not expose this product to rain or moisture;
- > Do not throw, to avoid damage caused by falling products;
- > Do not disassemble, repair and modify this product;
- > Do not use chemical solvents to wipe the product;
- > Do not arbitrarily discard or put in the fire, so as not to cause danger!

三、 Tips

In order to achieve the best sound quality headphones, please wear your headphones normally, do not disassemble the hardware yourself, use dry, soft cotton and so on.
We recommend that you take the following precautions:
1, please listen to the appropriate volume of music, to prevent the adverse effects of hearing.
2, do not use the product in the exposed liquid, wet or moisture in the environment.
3, when the temperature exceeds the specified temperature range 0 ℃ to 40 ℃ , do not operate the product. (If the range exceeds the specified temperature, turn off the device and allow the temperature to stabilize within the specified operating range.)

四、Instructions

NO	Function	Headset state	Operation	Prompt	Indicator light
1	Power on	Power off	Press MFB button for 1 second	"Power on"	The blue light flashes after a long time bright
2	Power off	Power on	Press MFB button for 3second	"Power off"	The red light stayed on for about a second
3	Successfully connected to mobile phone	Standby	/	"Connected"	Blue light flashes about once every 3 seconds
4	Disconnect from mobile phone	Connect the standby	/	"Disconnected"	/
5	Auto pairing	Power off	/	"Connected"	Blue light flashes about once every 3 seconds
6	Volume Adjustment	In a call/music	Long press the volume "V+","V-"	/	/
7	Last song	In the play	Press "V-"	/	/
8	Next song	In the play	Press "V+"	/	/
9	Music play/pause	In the play	Press MFB	/	Blue light flashes about once every 3 seconds
10	Income call	In call	/	dudu...dudu....	/
11	Answer call	In call	Press MFB	/	/
12	Reject call	In call	Long press the MFB for about 2 seconds	/	/
13	Redial last number	Standby	Double press MFB	/	/
14	Hang up the phone	In call	Press MFB	/	/
15	SD card pattern	On state	Insert TF card	SD MODE	Blue lights flash
16	FM pattern	On state	Double press "V+"	FM MODE	Blue lights flash
17	FM auto search pattern	FM pattern	Double Press MFB	/	Blue lights on

Notice

FCC compliance information statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

(1) Reorient or relocate the receiving antenna.

(2) Increase the separation between the equipment and receiver.

(3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction