








<p>自拍杆说明书</p>  <p>65</p>	 <p>Compatible</p> <p><input checked="" type="checkbox"/> iOS <input checked="" type="checkbox"/> Android</p>	<p>使用说明</p> <p>1. 开机: 长按拍照键3秒开机。 2. 蓝牙配对: 指示灯闪烁4秒进入配对状态, 配对状态蓝色指示灯闪烁, 用手机搜索 AB Shutter3 匹配, 蓝色指示灯熄灭配对成功。 3. 拍照: 蓝牙与手机连接后, 短按拍照键即可进行拍照。 4. 不配对: 开机后, 在未配对连接状态下, 5分钟无操作自动关机。 5. 配对: 手机开机后, 自拍与手机连接后, 10分钟无操作进入休眠状态, 再过10分钟自动关机。 6. 关机: 开机休眠状态下, 长按拍照键3秒关机, 指示灯闪烁。</p>	<p>自拍杆 G5 使用步骤说明</p>  <p>自拍杆使用说明</p> <p>当自拍杆切换到三脚架模式时, 注意拉出杆的最后1段, 调整到三脚架稳定。</p>	<p>三脚架模式</p>  <p>材质: 不锈钢+ABS 总长: 110mm 折叠长度: 200mm 产品重量: 145g 电池: CR1632 (可更换) 贮存不得暴露在如阳光、火或类似过热环境中。</p> <p>温馨提示</p> <p>自拍杆兼容安卓4.2.2和iPhone iOS5.0及以上。 (Android设备: 如果您的相机连接后不能控制音量键, 请在相机系统中将音量键设置更改为控制拍照, 请将控制器正常工作。)</p> <p>谢谢您的支持!</p> <p>CE ROHS</p>
<p>Instruction of selfie stick</p> <p>Specifications</p> <p>Main Material: Stainless steel Retracted Length: 20cm Extended Length: 110cm Gift carton size: 66*41*200mm Battery: CR1632(replaceable)</p> <p>65</p>	 <p>Compatible</p> <p><input checked="" type="checkbox"/> iOS <input checked="" type="checkbox"/> Android</p>	<p>How to use</p> <p>1. Turn on, long press the camera button for 3 seconds to turn on. 2. Bluetooth pairing: the indicator light flashes for 4 seconds to enter the pairing state, the blue indicator light of the pairing state flashes, use the mobile phone to search for AB Shutter3 to match, and the blue indicator light will go out after pairing is successful. 3. Take a photo: When the Selfie is connected to the mobile phone, short press the camera button and the blue light flashes. 4. No pairing: After booting, in the state of no pairing connection, it will automatically shut down after 5 minutes of no operation. 5. Power off: After turning on the phone, when the Selfie is connected to the phone, it will enter the dormant state if there is no operation for 0 minutes, and it will automatically shut down after another 10 minutes. 6. Power off: In power on and sleep mode, press and hold the camera button for 3 seconds to power off, the indicator light flashes and goes out.</p>	<p>Take out the SELFIE</p>  <p>Take out The self-timer can be removed by pushing up</p> <p>360° Rotation</p>  <p>The clip rotates 360°, Take pictures more freely!</p> <p>Change the battery</p>  <p>Just push the back cover up</p> <p>Open the tripod</p>  <p>Open the handle outwards, It becomes a tripod.</p>	<p>Tripod mode</p> <p>When the selfie stick changes to tripod mode, pay attention Pull out the last section of the pole and adjust it to The tripod is stable.</p>  <p>Specification</p> <p>Material: Stainless steel+ABS Total length: 110mm Folded length: 200mm Product weight: 145g Battery: CR1632 (replaceable) (The battery must not be exposed to such as sunlight, fire or similar overheating environment)</p> <p>Remind</p> <p>The selfie stick is compatible with Android 4.2.2 and phone iOS5.0 and above (Android device: if you are on the camera Change your "volume key function", be sure to change it to the default, Or "take a picture" and let the selfie stick normal work)</p> <p>thank you for your support!</p> <p>CE ROHS</p>

RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.