

TECHNOL MODEL



025002

R/C

扫描下方二维码进入下载界面

Scan the QR code below to enter the download interface

1

二维码
如(图一)所示
QR CODE.
As Shown in 1.



(图一)



2

请使用安卓的 浏览器/微信扫描二维码, 即可快速下载,如 (图二) 所示
Please use android browser/We Chat Scan QR CODE,To download quickly.As shown in



(图二)



3

点击安装, 下载安装完毕
如(图三)所示

Click Install to download and
install, as shown in 3.

根据不同的手机选择不同的下载方式
如不能安装下载请根据下一步操作
Choose different download methods
according to different mobile phones.If
you cannot install the download, please
follow the next step



(图三)



Android下载APP安装说明

扫描下方二维码进入下载界面

Scan the QR code below to enter the download interface

点击右上角(⋮)再点击在浏览器打开
进入系统浏览器, 如(图四)所示
Click on the upper right corner (...) Then click to open in the browser.
Enter the system browser.
As shown in 4.



点击系统
自带浏览器进入下载, 如(图五)所示
Click system bring your own browser
to Download.As shown in 5.



点击继续下载, 安装完毕
如(图六)所示
Click to continue
downloading, and the
installation is completed as



IOS系统下载APP安装说明


扫描下方二维码进入下载界面

Scan the QR code below to enter the download interface

1

二维码
如(图一) 所示
QR CODE.
As Shown in 1.

(图一)



2

请使用iphone 或 ipad的
Safari 浏览器/微信扫描二维码,
即可快速下载.如 (图二) 所示.
Please use iphone or ipad
Safari browser/We Chat Scan
QR code,To download quickly.
As shown in 2.

(图二)



3

点击允许进入
如(图三)所示
Click allow to enter
As shown in 3.

(图三)



4

点击获取下载
安装完毕
如(图四)所示
Click for Download
Installed
As shown in 4.

(图四)



APP蓝牙连接说明

APP Bluetooth connection instructions

1



允许开启蓝牙请求
如（图一）所示
Allow Bluetooth
requests to be
enabled as shown
in 1.



（图一）

2



允许权限请求，
如（图二）所示
Allow permission
request.
As shown in 2.



（图二）


3

打开后模块电源指示灯会闪，
成功连接时，指示灯会长亮，
如（图三）所示，打开遥控模式
页面可以进行操作。

After being turned on, the module
power indicator will flash, and
when successfully connected, the
indicator will remain on, as shown
in 3. Opening the remote control
mode page allows you to operate.

选择对应的模块电源
Select the corresponding
Module power supply

（图三）



快速遥控进入遥控界面

Quick remote control Enter the remote control screen

1

进入快速遥控
点击对应电机
再点击"GO"进入
如（图一）所示

Enter the quick remote control, click the corresponding motor and then click "GO" to enter. As shown 1.



2

跳入对应遥控界面
可进行操作
操作说明
如（图二）所示

Enter the corresponding remote control screen is can be operable. As shown in 2.



（图一）



（图二）

产品型号进入遥控界面

Item model into remote control screen

1

进入产品目录. 点击对应系列
再点击“OK”进入
如（图一）所示
Enter catalog.

Click corresponding series
click“OK”into.As shown in 1.



(图一)

2

点击对应的型号进入
如（图二）所示
Click on the corresponding
model to enter.
As shown in 2.



(图二)

3

跳入对应遥控界面可进行操作
如（图三）所示
Enter the corresponding
remote control screen is
can be operable.
As shown in 3.



(图三)

编程操作说明

1


点击编程进入
如（图一）所示
Click programming
to enter.
As shown in 1.



（图一）

2

双击自由添加编程
如（图二）所示
Double click to add
programming freely.
As shown in 2



（图二）

3

可下滑模块
使命令模块组合
如（图三）所示
Slippable module to
combine command
modules.
As shown in 3.



（图三）

编程操作说明

4

点击指定模块命令
可以输入参数 (秒)
根据设定的参数 (秒)
使运行中的指定时长
如 (图四) 所示

Click the specified
module order .can be
enter the parameters (s)
as per setting the
parameters (s).
make the specified
duration in operation.
As shown in 4.



(图四)

5

点击保存
如 (图五) 所示
Click save
As shown in 5.



(图五)

6

点击测试
操作进行
如 (图六) 所示
Click test.
Operation proceeded.
As shown in 6.



(图六)


自由添加编程说明

Free to add programming instructions

1

点击自由添加编程
如（图一）所示

Click to add
programming freely
As shown in 1.



（图一）

2

点击右上角保存
如（图二）所示

Click save in the
upper right corner.
As shown in 2.




（图二）

3

保存完毕会显示编程1
如（图三）所示

Program 1 will be
displayed after saving
As shown in 3




（图三）

自由添加编程说明

Free to add programming instructions

4

长按点击垃圾桶
进行删除
如（图四）所示
Long press on the
trash can to delete
As shown in 4



（图四）

5

点击√确定删除
点击x取消删除
如（图五）所示
Click √ to delete
Click x to cancel deletion
As shown in 5.



（图五）

6

可添加无数编程
如（图六）所示
Countless
programming
can be added
As shown in 6.



（图六）


CD002.CD002-1 遥控说明



CD002.CD002-1 Remote control instructions





CD003.CD003-1 遥控说明

CD003.CD003-1 Remote control instructions












1







2










4


3








5









6



7





8

