

# AI 使用说明书

## OWS 蓝牙耳机



将耳机取出悬挂在耳朵上，悬浮挂耳式佩带，悬浮空气感轻盈贴合不入耳，全天候轻盈舒适久戴不累耳。

打开“Wearfit Pro”APP，点击右上角选择进入耳机设备页面，点击主页“白噪音”卡片，进入功能页面，点击需要卡进入播放页面，点击播放按钮可播放/暂停音频，点击“单次播放”按钮可切换播放模式。

- 1. 产品名称: M127
- 2. 蓝牙耳机容量: 3.7V/40mAh (聚合物电池)
- 3. 支持模式: AAC/SBC
- 4. 充电仓电池容量: 3.7V/500mAh (聚合物电池)
- 5. 蓝牙传输距离: 10m
- 6. 载波频率: 2.402GHz~2.480GHz
- 7. 频响范围: 20Hz~20KHz
- 8. 喇叭尺寸: 40mm
- 9. 喇叭灵敏度: 129dB ±3dB
- 10. 喇叭阻抗: 16Ω±15%
- 11. 耳机额定功率: 5mW
- 12. 耳机电池容量: 3.7V/40mAh (聚合物电池)
- 13. 充电仓电池容量: 3.7V/500mAh (聚合物电池)
- 14. 充电接口: USB -Type C
- 15. 耳机使用时间: ≈6-8小时
- 16. 耳机单次充电时间: ≈1.5小时
- 17. 充电仓充电时间: ≈1.5小时
- 17. 充电仓给耳机充电次数: 约5-6次
- 18. 关机待机电耗: ≈3000小时

1. 初次使用本产品前，请先充满电再使用。

- 初次使用本产品前, 请先阅读充电说明。
- 本产品是玩具, 12岁以下的儿童须在成人监护下使用。
- 请使用通过国家强制性安全认证的5V/1A充电器, 避免充满后高压的快速充电器对产品造成损害。
- 请勿在潮湿的环境下使用, 在给电池充电时, 电量充满后请及时将充电线拔下, 避免长时间充电造成短路, 电池的充电时间为1-2小时。
- 本产品含有不可拆卸的锂离子电池, 需经手机售后店检测合格方能会随手机包装箱而转移, 电池损坏请及时更换, 这对所有可以重复使用锂离子电池设备均属于正常现象。
- 本产品带有锂电池, 如长时间未使用, 请至少一个月充电一次。
- 因个体差异原因, 如佩戴时感到皮肤不适, 请停止佩戴并咨询医生。
- 在蓝牙连接本产品使用时, 请将耳机音量调至合适音量大小, 以免长时间在大音量状态下使用造成听力损害。
- 如果在使用过程中需要集中注意力时, 请及时停止使用本产品, 注意您自身和他人的安全。例如在驾驶、骑行、过马路、施工场所、铁路或高速行驶时, 应放下耳机或暂停使用耳机以免对您的安全造成危害。
10. 请遵守所在国家/地区的所有相关法律法规, 并严格按照要求使用产品。
11. 本产品含有磁性材料, 使用或存放产品时, 请远离具有强磁场或强电场的电器, 如微波炉、电磁炉等。

1. 请遵循本说明书的内容正确使用, 避免产品因错误操作而损坏。

2. 本产品请远离阳光、热源、热源、冷冻源、水源及化学药品。

3. 请勿长时间使用大功率附件, 以免对灯罩造成不良损害。

4. 请勿将产品长时间放置于任何液体或用水冲洗产品, 否则会导致火灾或触电危险。

5. 请勿将产品放置在不正确照射或温度高的地方。高温会缩短电子部件的使用寿命、损坏灯泡、使某些部件老化。

6. 请勿将本产品放在过高、过多湿度和温度或过低的地方保存。

7. 请勿将电源线(例如延长线、插座及公头)长期接插在本产品, 否则可能导致电源线被损坏。

8. 请勿在本产品上添加过多的压力, 或拆卸、拆卸、弯曲、弯曲本产品, 以免对产品产生压力。

9. 请勿靠近热源使用本产品, 如加热器、电炉或暖气。炉灶或暖气片产生的热量会影响本产品的工作。


10. 请勿堵塞本产品的工作孔, 如灯罩孔、灯罩孔、通风孔等。

11. 请勿在暴雨天气下使用本产品, 雷电天气可能会导致设备损坏、增大火灾的风险。

12. 请勿避免本产品及其附件用油或受潮, 且剧烈运动或出现较多时使用本产品, 防止液体渗透到产品内部损坏产品。

13. 产品属于室内照明合理用途, 不可浸湿、请勿弄灰或浸入水中, 以免爆炸、起火等危险发生。

14. 如因遵守法律上上述警告而不当使用所造成的个人及财产损失需自行承担一切责任需本公司概不产生任何法律责任。



产地：中国·广东

# AI

## INSTRUCTION MANUAL

OWS Bluetooth earphones



Take out the headphones and hang them on your ears, wearing them in a suspended ear style. The suspended air feels light and fits snugly without getting into your ears, making them lightweight and comfortable to wear all day long without tiring your ears.

Open the "Wearfit Pro" app, click the top-right corner to enter the headphone device page, tap the "White Noise" card on the homepage to access the feature page, tap the audio card to enter the playback page, click the play button to play/pause the audio, and tap the "Single Play" button to switch the playback mode.

---

Product name: M127	10 Horn rated power :5mW
Bluetooth version : Bluetooth 5.49	11 Headphone battery capacity :3.7V/40mAh (polymer battery)
Support mode :AAC/SBC	12 Charging bin battery capacity :3.7V/500mAh (polymer battery)
Bluetooth transmission distance :10m	13 Charging interface : USB Type-C
Carrier frequency :2.402GHz-2.480GHz	14 Earpad use time :>6-8 hours
Frequency response range :20Hz-20KHz	15 Headset use time :>1.5 hours
horn size :Φ10mm	16 Charging time : <1.5 hours
Horn sensitivity :129dB±3dB	17 Charge the headset: About 5-6 times
Horn impedance : <16Ω±15%	18 Shutdown standby time :>3000 hours

Reject an incoming call	When the call is incoming, press and hold the function key of any light or press headset for 2 seconds	/	/
Hang up	While on the phone, double-click the touch button on any headset	/	/
Low battery alarm	When the voltage of the earbuds is lower than 3.3V, there will be a prompt up to the ear powered off	The white light flashes every 5 seconds	Ding Dong
Disconnect	Outside the effective connection range, or manually disconnect the Bluetooth connection of the smart device	The main headphone's white light is flashing, and the auxiliary headphone's light is off	Disconnected 断开连接
Automatic reconnection	After powering on or disconnecting, the earbuds will automatically connect to the last connected smart device within the effective distance	The lights go out	connected / 已连接
Charge the headphones	The earbuds will automatically shut down and start charging when placed lock in this charging case. The white light of the earbuds will remain on, and the light will turn off when fully charged		
The charging status of the headphones	The headphones is put into the charging box, the charging box immediately charges the headphone and activates the screen to show the current charge and the charging status of the headphone. The charging status of the headphones is as follows: the charging and the charging box screen shows the charging status signs, the final charging charge screen shows the remaining light to top up after 15 seconds		
Charging pin	When the battery is 50%, charge the battery with a power adapter with a standard output of 5V. The battery screen displays an eye flashes to show the current battery.		
The charging time fully charged	Charging pin screen light stays always bright number 100		

**Note:** When the Bluetooth headset is connected to a smart device and the game mode is switched, the usage time and connection distance of the headset will be shortened

[illegible]

- Please follow the relevant regulations of your region or country and use this product as required when driving.
1. Do not connect products with magnetic materials, please keep away from electrical appliances with strong magnetic fields, such as microwave ovens, refrigerators, etc., when using the product.
  2. It is recommended to use this product in an environment with a temperature of  $-0^{\circ}\text{C}$ – $45^{\circ}\text{C}$ . The storage temperature is below  $-5^{\circ}\text{C}$ , battery performance is limited.
  3. Do not use this product in places where it is expressly prohibited to use wireless equipment or where it will interfere with other electronic equipment or cause other dangers.
  4. Before approaching medical or industrial equipment or boarding a plane, please ask the local authorities for advice on what you can use.
  5. Before cleaning and maintaining this product, stop using this product, turn off all applications, and disconnect all connections or cables to other equipment.
  6. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.

2. Please follow the content of this manual to avoid damage to the product due to incorrect operation.

3. Do not use the product away from children, fire, heat, refrigeration, water and chemicals.

4. Do not listen at a loud volume for a long time to avoid adverse effects on hearing.

5. Do not use the product in the presence of any liquid or water. If the product is wet, please dry it thoroughly. Otherwise it will cause fire or electric shock hazard.

6. Do not place the product in the sun or in a place with high temperature. High temperatures will damage the product.

7. Do not store this product in a place with a lot of dust, too high or too low temperature and humidity.

8. Do not contact the magnetic stripe card (such as bank card, bus card, etc.) with this product for a long time, otherwise it may cause the magnetic stripe card to be damaged by the magnetic field.

9. Do not exert greater pressure to this product, or disassemble, bend, or shake this product to prevent damage to the product.

10. Do not use this product in the following places: sources, such as radiators, hot air registers, stoves, or other instruments that generate heat.

11. Do not block the openings of this product, such as charging ports, indicator lights.


12. Do not use the device in rainy weather, thunderstorms may cause the device to be damaged.

13. Do not use the device in the presence of fire or other fire hazards.

14. Please avoid using this product when this product and its accessories are exposed to rain or moisture, and when you exercise vigorously or sweat a lot, to prevent liquid from entering the product.

15. The product belongs to the built-in polymer battery, which cannot be recharged, please do not disassemble or replace the battery.

16. If the consumer violates the above warning and inappropriate use, the personal and property damage will be borne by the company, and the company will not incur any legal liability.



产地：中国·广东

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.