



Fürspark



Product Overview



Features

Features	Description
Feed	Click Feed: Short press this key to distribute pet food; long press to reset. Scheduled feeding: Set the time of feeding on the App and distribute pet food as scheduled. App feeding: Click to distribute food.
Real-Time Monitoring	Check the real-time video of the camera through mobile App.
Taking photos	Press the button "Photo" to take a photo.
Remaining Food Detection	Infrared detection function is available to check the remaining food inside the feeder and show the remaining food amount through App and the eyelid condition.
AI Pet care	Big eye feeder automatically record numbers of your pet's appearances, take pictures and related videos for you to check.
Sharing Device	Sharing with Family and Friends, 2-3 users online simultaneously available.

● For reference only, please refer to the actual product.

(01)

Product Manual

(02)

Parameters

Product Name	Smart Pet Feeder
Product Model	Fürspark Big Eye
Product Color	Grey and white
Product Dimensions	360*217*415mm
Wireless Connection	WiFi2.4GHz
Storage	TF card (Optional)
Input Parameter	5V/2A
Video Parameters	Support H.264 code, 1440P @30fps, 10Mbps

Indicator Light

Working Status of the Indicator Light	Status Description
Orange Light Flashing Slowly	WiFi waiting for connection.
Blue Light Is Always On	The WiFi connected, machine (including video) functions normally.
Orange Light Flashes Quickly	WiFi connection failure, machine errors detected.
The Blue Light Flashes Slowly	Backup battery mode's on, video related functions' off.

Product package List


● Machine *1	● Stainless steel bowl*1
● Power adapter*1	● Product manual*1
● Desiccant*1	

(03)

Equipment Operation


● Button

Short Press to Distribute Food (One Portion Each Time) / Long Press for 10 Seconds to Reset




How to Clean

Disassemble by holding the buttons on both sides of the component to lift and clean each component separately.



Child Safety Lock

Child safety lock is available on app, to prevent accidents. When child-safety-lock mode is on, food distributing button would be disfunctioned.



(04)

(05)


(06)

(07)

Position of the Desiccant

- Replace the Desiccant

After replacing the desiccant, in order to reset the time of desiccant reminder, please go to APP - [Device Settings] - [Desiccant] - [Desiccant Replaced, Reset Immediately]. After 30 days, the APP will remind you to replace it.




How to Power On

- Plug in the power cord and lead the cord out through the wiring duct.
- Dry Batteries (AA battery)

After replacing the desiccant, in order to reset the time of desiccant reminder, please go to APP - [Device Settings] - [Desiccant] - [Desiccant Replaced, Reset Immediately]. After 30 days, the APP will remind you to replace it.

Location of the Memory Card


- MicroSD Card Slot



The Food Barrel Cannot be Aligned with the Base

- Manually rotate the "blade" to align the barrel with the base.

We strongly suggest users not to rotate the "fan" from original position, but if it was taken off, after taking out the barrel, you



(08)


(09)

Connection

Open the Fürspark app on your mobile device and log in to your account, click on the "Add Smart Device" button to enter the device setup page.

After connecting the power supply with dry battery ensure this machine continues on its feeding mission for 1 week. Please make sure to check battery conditions before using, which highly affect the feeding persistence.

In dry battery mode, the smart pet feeder cannot connect to the internet.



Operation Guide

Download Fürspark App



(10)

(11)

Sync WiFi Information

WiFi in the 5GHz band not supported. Please use WiFi in the 2.4G band.

Select Net or enter WiFi

Ensure that the WiFi account and password are correct


Select WiFi to Pair Your Machine

1. Please keep the QR code on your phone 25-45 cm from the camera on your feeder.

2. Make sure to move your phone downward slightly so as to scan the QR code accurately.

3. Don't move your phone too fast, stop for 1-2s to try to scan QR code and then move the phone to the perfect position for scanning QR code.

4. After scanning, please wait for 20 seconds till the device's promote indicating that the WiFi connection is successful and the device is connected. After hearing the prompt, you can proceed to the next step.



(12)


Scan QR Code to Pair Your Machine

1. Please keep the QR code on your phone 25-45 cm from the camera on your feeder.

2. Make sure to move your phone downward slightly so as to scan the QR code accurately.

3. Don't move your phone too fast, stop for 1-2s to try to scan QR code and then move the phone to the perfect position for scanning QR code.

4. After scanning, please wait for 20 seconds till the device's promote indicating that the WiFi connection is successful and the device is connected. After hearing the prompt, you can proceed to the next step.



(13)

(14)

Wait for the Device's Voice Prompt

When the QR code is successfully recognized, you will hear a "beep" sound.

If an invalid QR code is recognized, the device will say "QR code recognition failed, please re-scan according to the app's instructions."

When the device is connecting to WiFi, you will hear "WiFi connecting."

If the device fails to connect to WiFi, you will hear "WiFi connection failed, please try again."

If the device fails to pair, you will hear "Device pairing failed, please refer to the app's instructions to reconnect."

If the device successfully pairs, you will hear "Device pairing successful."



Notice

- Before using the product for the first time, please fill the food compartment to the maximum limit and do not exceed it.
- When plugging or unplugging the adapter, do not pull the power cord directly.
- Do not put bizarre objects into or modify/repair the product without authorization.
- Please use the original power adapter and cable.
- This product is only suitable for indoor use. Please avoid direct sunlight to prevent interference with the food detection sensor.
- The food container can only hold dry dog/cat food and should not be filled with other objects.
- This device contains electronic components and does not have waterproof functions. It is not recommended to use it in damp places.
- This product is only suitable for feeding pets and not for any other purposes.
- Persons lacking relevant experience and knowledge (including children) do not have full civil capacity must use the product under the supervision and guidance of a guardian for cleaning and maintenance.
- In the event of malfunction, odor emission, smoking, overheating or abnormal behavior, please discontinue use of the product immediately and contact customer service at info@furspark.com.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio/television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC ID: 2ABAD-BIGEYE

(15)

	设计人员: 徐小云	包装类型: 说明书	材质: 105g双铜	工艺: 油墨印刷	公差: ±0.5mm
	归档人员: 徐小云	项目经理: 黄念念	比例尺寸: 1:1	尺寸: 110*130mm	颜色:

CPP海外版说明书变更履历表

修改对象	版本	修改时间	修改内容	修改原因
70401000146	V0.0	20230522	初版	
70401000158	V0.1	20230703	增加FCC警告语	认证需求
70401000158	V0.2	20230706	修正产品信息	