

# Product name: Smart Projector


Mode: Q7




Remote Control



Focus



Connection& Key



HDMI



Shortcut




File Manager



Same screen



WiFi




Bluetooth




Image settings




Projection Settings



Focus Settings



Keystone  
Correction Settings



Sound



System Settings




About



Input Source



App Upgrade



Bluetooth  
Speaker Mode

21

22


23

24

25

# Remote Control

## Instruction of Buttons



Note: 1. Please keep the remote control aiming at the projector screen.  
2. Please take out the battery if the remote control is not used for a long time.

# How to use the external mouse?




1. Left mouse button confirmation
2. Right click to return

# Focus

## Manual focus


- 1.Quick focus:Long press the button of “F+”/”F-”on the remote control, the FOCUS icon will appear and rotate quickly on the projection interface.
- 2.Precise focus: Click the “F+”/”F-”button on the remote control continuously, and the FOCUS icon on the projection interface will change according to the frequency of clicks.



# Focus

## Autofocus

1. Every time the machine is turned on or moved, it will automatically focus;
2. To disable the autofocus function, go to the "Settings" - "Projection settings" option and turn off the "Autofocus" switch;
3. If the autofocus is not clear, please use "F+/F -" on the remote control to make slight adjustments;



# Connection & Key

Touch buttons



# HDMI

## Connect External Multi-media Interface

Connect the HD cord to the projector and click HDMI on the home screen which will appear in sync within five seconds .



**Notes: It can be combined with Amazon Fire TV Stick to connect the projector.**

1. Plug the Fire TV device into projector HDMI port.
2. Check the Audio setting on your Amazon Fire TV or Fire Stick.
3. If you're still experiencing audio issues, try turning off Dolby Digital Plus: On your Amazon Fire TV or Fire Stick, go to Settings > Display & Sounds > Audio > Dolby Digital Output and then turn Dolby Digital Plus OFF.




# Shortcuts Button

- 1 Delete the apps you download by pressing and holding down the ok button for two seconds.



# Shortcuts Bottom

2 In the home screen interface, press the remote control "⌃" button to open the quick function pop-up window. Select the cleanup icon to clear the background memory.




3 Click the mouse button to switch between mouse mode and remote control mode



# File Explorer


The files accessed from the USB port can be opened through the resource manager



# Airplay (iPhone)

## iPhone AirPlay mirror operation guide


1. Connect your iPhone and projector to the same --WIFI-- network (Note that poor network connection can cause screen lag)



# Airplay (iPhone)

## iPhone AirPlay mirror operation guide

2. Click to open the projector's Airtray and select Airtray as the projection method at the bottom of the interface
3. Slide down your iPhone, open the control center of your phone, click on Airpalm Mirroring, and the device list will automatically search for projection devices within the same network
4. Select the name of the projector device that needs to be connected in the device list to successfully project the screen (the device name is located in the upper left corner of the projector projection interface)





# Android phone Wireless Screen mirroring

- 1 Make sure your Android phone and projector open the WIFI.
- 2 Please click Miracast on the projection screen.





# Android Miracast operation guide

- ③ Open “More Connections or Screen Projection for Android Phone” on the mobile phone (there are a variety of models of Android mobile phones which may have different names, and the mobile phone to be referred is HUAWEI mobile phone).
- ④ The phone and projector will search for same model in a few seconds and connect successfully.





# WIFI Connection

Connect to WIFI and set up a hotspot. Select the WIFI you want to connect to, enter the password, and click "Done." (Within the available range, the device will automatically connect to the previously selected WIFI network.)






# Bluetooth Connection

Connect to a Bluetooth device ( Settings > Bluetooth).





# picture settings

- 1.Picture mode: User/Standard/Bright/Sports/Movie/Game/Energy saving. When choosing customization, you can freely adjust brightness, contrast, saturation, color tone, and sharpness.
2. Color temperature: standard/cool/warm, adjustable red gain/green gain/blue gain again.



# Projection Settings



1. Projection mode: Click on the option to switch between upright projection and suspended projection;
2. Auto Fan Setting: Choose between On and Off. When Off, adjust the slider to control fan speed.
3. Brightness: Adjust the projector brightness by sliding the slider.



# Focus Settings

Settings > Projection Settings:

1. Auto Focus: On/Off; When Auto Focus is turned off, use the remote control's "Focus+" / "Focus-" to adjust the picture to a clear state.
2. Trapezoidal reference correction: When the trapezoidal correction is inaccurate, using the trapezoidal reference correction function can make the trapezoidal correction more accurate. Click on the trapezoidal benchmark calibration option to enter the trapezoidal benchmark calibration operation instruction interface, and follow the instructions to complete the trapezoidal benchmark calibration.
3. Auto Focus on Startup: On/Off; When this option is enabled, the projector will auto-focus at every startup.
4. Auto Focus on Movement: On/Off; When this option is enabled, the device will automatically calibrate focus after being moved.





# Keystone Correction Settings

## 1. Auto Keystone Correction: On/Off.

When this option is enabled, the projector will automatically adjust the image to be rectangular; when disabled, you can manually adjust the "Vertical Calibration," "Horizontal Calibration," and "Zoom" sliders to make the image rectangular, or select the "Four Corner Keystone" option, enter the four-corner keystone correction interface, choose a corner, and freely adjust the keystone angle using the up, down, left, and right keys. Press the OK button to switch to the next corner, and press the Menu button to restore default settings. If manual keystone correction is unsatisfactory, click the "Keystone Correction Reset" option to restore the keystone correction to default settings.



## 2. Obstacle Avoidance: On/Off. When this feature is enabled, the projection light will automatically avoid obstacles.

## 3. Auto Screen Fit: On/Off. When this feature is enabled, the projection image will automatically adjust to fit the screen ahead.





# Sound

1. Key Sound: On/Off;
2. Startup Music: On/Off;
3. Sound Effect: Standard/Vivid/Music.





# System Settings

1. Language: Choose the language for your region.
2. Reset to Factory Settings: Selecting this will reset the machine (use cautiously).
3. System Upgrade: USB Upgrade/Online Upgrade.
4. Time and Date: Automatically set the time and date or manually choose to set the date, time, and time zone.
5. Keyboard: Choose installed keyboards and input methods.
6. Screensaver: Set screensaver type and activation time.
7. Apps: Uninstall, upgrade, manage permissions, clear cache, etc., for installed apps.





# About

View device name, system version, memory information, storage space, and other related information.



# Input Source

1. Startup Input Source: Local/HDMI;
2. Consumer Electronics Control: HDMI Control/Device Auto Power Off/Projector Auto Power On/CEC.



# App Upgrade

When a red dot appears on the top status bar indicating an app upgrade, press the projector's "^" button to bring up the quick operation bar, select the app upgrade icon, and choose the app to upgrade. You can upgrade the app to the latest version.



# Bluetooth Speaker Mode

1. Turn on the Bluetooth function in the settings;
2. Return to the home screen, press the projector's "^" button to bring up the quick operation bar, select the "Bluetooth Speaker" icon, and proceed with Bluetooth pairing;
3. After entering Bluetooth Speaker Mode, the light engine will stop working. Re-press the remote control power button or the machine power button to wake up the light engine and automatically disconnect the Bluetooth connection.



# FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20cm between the radiator & your body.