

USER MANUAL 使用手册

产品简述及外观 <p>本产品是针对成人伴侣所研发的一款震动阳具套,可用遥控器进行操控。产品采用液态硅胶制造,柔软舒适,贴近人体肌肤的表面触感。仿真外形,一体成型;小兔子内置一个强力震动子弹,强震撩拨蜜豆。丰富爱情趣,轻易获取性高潮。</p>	使用方法 <p>取出绝缘片</p> <p>使用前,请先顺时针转开遥控器后盖,如上图所示取出绝缘片,再将纽扣电池扣到位,合上后盖,逆时针转紧,即可使用。</p> <p>使用方法1: 阳具套</p> <ol style="list-style-type: none">1. 长按子弹 $\textcircled{1}$ 键1.5秒进入待机状态2. 点按 $\textcircled{1}$ 键开启震动模式, 10种频率循环切换3. 长按子弹 $\textcircled{1}$ 键1.5秒关机 <p>使用方法2: 遥控器+阳具套</p> <ol style="list-style-type: none">1. 长按阳具套子弹 $\textcircled{1}$ 键1.5秒进入待机状态2. 点按遥控器 $\textcircled{1}$ 键开启震动模式3. 点按遥控器 $\textcircled{2}$ 键可切换震动频率, 10种频率循环切换4. 点按遥控器 $\textcircled{3}$ 键可使子弹回到待机状态5. 长按阳具套子弹 $\textcircled{1}$ 键1.5秒关机	充电 <p>阳具套子弹充电</p> <ol style="list-style-type: none">1. 充电前请确保充电口和充电线插针处未沾水或润滑油2. 将USB充电线连接充电口并接电源充电, 充电时灯光闪烁, 充满后灯光长亮3. 请勿在充电状态下使用本产品4. 请注意充电时间不要超过24小时5. 请使用原装充电配件 <p>遥控器更换电池</p> <p>遥控器使用一粒CR2032 3V纽扣电池, 旋开后盖更换。更换完成, 旋转上盖。</p>	产品信息 <table border="1"><tr><td>材 质</td><td>液态硅胶+ABS</td></tr><tr><td>电 池</td><td>子弹内置可充电聚合物锂电池 遥控器使用一粒CR2032 3V纽扣电池</td></tr><tr><td>充 电 压 电</td><td>5V</td></tr><tr><td>充 电 时 间</td><td>约1小时</td></tr><tr><td>使 用 时 间</td><td>充满电后可使用约1小时</td></tr><tr><td>工 作 模 式</td><td>10频震动</td></tr></table>	材 质	液态硅胶+ABS	电 池	子弹内置可充电聚合物锂电池 遥控器使用一粒CR2032 3V纽扣电池	充 电 压 电	5V	充 电 时 间	约1小时	使 用 时 间	充满电后可使用约1小时	工 作 模 式	10频震动	安全 <ol style="list-style-type: none">注意个人卫生健康, 请勿与他人共用此私密用品。请选择水溶性润滑液与本产品配合使用。请勿使用含有硅油成分的润滑液或以按摩油、护手霜或身体乳作为润滑液。如果您出现任何不适, 请立即停止使用。如果产品出现任何损坏, 请立即停止使用。请勿尝试拆开或拆解产品。如果USB充电线出现损坏, 请勿继续使用此线充电。请将本产品放在儿童和宠物接触不到的地方。
材 质	液态硅胶+ABS															
电 池	子弹内置可充电聚合物锂电池 遥控器使用一粒CR2032 3V纽扣电池															
充 电 压 电	5V															
充 电 时 间	约1小时															
使 用 时 间	充满电后可使用约1小时															
工 作 模 式	10频震动															

USER MANUAL	PRODUCT OVERVIEW <p>This product is a vibrating penis sleeve developed for adult partners, which can be controlled by a remote. The product is made of liquid silicone, which is soft and close to human skin feel. Not only with integrated molding and realistic appearance, but also the rabbit part has an inserted powerful vibrating bullet which can provide intense clitoral stimulation. It can help you release your lustful desires and achieve orgasm easily.</p>	USAGE <p>Remove the Tab</p>	CHARGING <p>Bullet Charging</p> <ol style="list-style-type: none">1. Before charging, please completely dry the charging port and charging pin.2. Plug charging pin into charging port and connect USB to power source. Light will flash while charging. Once fully charged, it will turn to solid light.3. Please don't use the toy when charging.4. Please don't charge over 24 hours.5. Use the original charger provided for charging the toy.	SPECIFICATIONS <table border="1"><tr><td>Material</td><td>Liquid silicone+ABS</td></tr><tr><td>Battery</td><td>Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery</td></tr><tr><td>Charging Voltage</td><td>5V</td></tr><tr><td>Charging Time</td><td>Approx. 1 hour</td></tr><tr><td>Run Time</td><td>Approx. 1 hour after fully charged</td></tr><tr><td>Working Mode</td><td>10 vibration modes</td></tr></table>	Material	Liquid silicone+ABS	Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery	Charging Voltage	5V	Charging Time	Approx. 1 hour	Run Time	Approx. 1 hour after fully charged	Working Mode	10 vibration modes	SAFETY <ol style="list-style-type: none">1. For personal health, do not share the toy with others.2. Always use water-based lubricant with the toy. Do not use silicone-based lubricant, or use massaging oil, hand cream or body lotion as lubricant.3. If you feel any discomfort, stop using immediately.4. If any part of the toy is damaged, stop using immediately. Do not attempt to take apart or disassemble the toy.5. Do not charge if the USB cord appears damaged.6. Keep out of reach of children and pets.
Material	Liquid silicone+ABS																
Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery																
Charging Voltage	5V																
Charging Time	Approx. 1 hour																
Run Time	Approx. 1 hour after fully charged																
Working Mode	10 vibration modes																
USER MANUAL	PRODUCT OVERVIEW <p>This product is a vibrating penis sleeve developed for adult partners, which can be controlled by a remote. The product is made of liquid silicone, which is soft and close to human skin feel. Not only with integrated molding and realistic appearance, but also the rabbit part has an inserted powerful vibrating bullet which can provide intense clitoral stimulation. It can help you release your lustful desires and achieve orgasm easily.</p>	USAGE <p>Remove the Tab</p>	CHARGING <p>Bullet Charging</p> <ol style="list-style-type: none">1. Before charging, please completely dry the charging port and charging pin.2. Plug charging pin into charging port and connect USB to power source. Light will flash while charging. Once fully charged, it will turn to solid light.3. Please don't use the toy when charging.4. Please don't charge over 24 hours.5. Use the original charger provided for charging the toy.	SPECIFICATIONS <table border="1"><tr><td>Material</td><td>Liquid silicone+ABS</td></tr><tr><td>Battery</td><td>Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery</td></tr><tr><td>Charging Voltage</td><td>5V</td></tr><tr><td>Charging Time</td><td>Approx. 1 hour</td></tr><tr><td>Run Time</td><td>Approx. 1 hour after fully charged</td></tr><tr><td>Working Mode</td><td>10 vibration modes</td></tr></table>	Material	Liquid silicone+ABS	Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery	Charging Voltage	5V	Charging Time	Approx. 1 hour	Run Time	Approx. 1 hour after fully charged	Working Mode	10 vibration modes	SAFETY <ol style="list-style-type: none">1. For personal health, do not share the toy with others.2. Always use water-based lubricant with the toy. Do not use silicone-based lubricant, or use massaging oil, hand cream or body lotion as lubricant.3. If you feel any discomfort, stop using immediately.4. If any part of the toy is damaged, stop using immediately. Do not attempt to take apart or disassemble the toy.5. Do not charge if the USB cord appears damaged.6. Keep out of reach of children and pets.
Material	Liquid silicone+ABS																
Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery																
Charging Voltage	5V																
Charging Time	Approx. 1 hour																
Run Time	Approx. 1 hour after fully charged																
Working Mode	10 vibration modes																
USER MANUAL	PRODUCT OVERVIEW <p>This product is a vibrating penis sleeve developed for adult partners, which can be controlled by a remote. The product is made of liquid silicone, which is soft and close to human skin feel. Not only with integrated molding and realistic appearance, but also the rabbit part has an inserted powerful vibrating bullet which can provide intense clitoral stimulation. It can help you release your lustful desires and achieve orgasm easily.</p>	USAGE <p>Remove the Tab</p>	CHARGING <p>Bullet Charging</p> <ol style="list-style-type: none">1. Before charging, please completely dry the charging port and charging pin.2. Plug charging pin into charging port and connect USB to power source. Light will flash while charging. Once fully charged, it will turn to solid light.3. Please don't use the toy when charging.4. Please don't charge over 24 hours.5. Use the original charger provided for charging the toy.	SPECIFICATIONS <table border="1"><tr><td>Material</td><td>Liquid silicone+ABS</td></tr><tr><td>Battery</td><td>Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery</td></tr><tr><td>Charging Voltage</td><td>5V</td></tr><tr><td>Charging Time</td><td>Approx. 1 hour</td></tr><tr><td>Run Time</td><td>Approx. 1 hour after fully charged</td></tr><tr><td>Working Mode</td><td>10 vibration modes</td></tr></table>	Material	Liquid silicone+ABS	Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery	Charging Voltage	5V	Charging Time	Approx. 1 hour	Run Time	Approx. 1 hour after fully charged	Working Mode	10 vibration modes	SAFETY <ol style="list-style-type: none">1. For personal health, do not share the toy with others.2. Always use water-based lubricant with the toy. Do not use silicone-based lubricant, or use massaging oil, hand cream or body lotion as lubricant.3. If you feel any discomfort, stop using immediately.4. If any part of the toy is damaged, stop using immediately. Do not attempt to take apart or disassemble the toy.5. Do not charge if the USB cord appears damaged.6. Keep out of reach of children and pets.
Material	Liquid silicone+ABS																
Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery																
Charging Voltage	5V																
Charging Time	Approx. 1 hour																
Run Time	Approx. 1 hour after fully charged																
Working Mode	10 vibration modes																

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.